

Sakura Filter				Sakura Number Cross Reference							
NO	SAKURA NO	ORIGINAL NO	MFR	NO	SAKURA NO	ORIGINAL NO	MFR	NO	SAKURA NO	ORIGINAL NO	MFR
1	A-1013	1-14214126-0	ISU	23	A-6007	1-14215078-0	ISU	72	AS-1010	9-14215175-0	ISU
		1-14215-075-0	ISU			1-14215078-1	ISU	73	AS-1014	1-14215135-0	ISU
		1-14215-182-0	ISU			1-14215111-0	ISU	74	AS-1024	9-14611150-0	ISU
		1-14215-210-0	ISU			1-14215119-0	ISU			1-87810067-0	ISU
		1-14215-210-1	ISU			1-14215145-0	ISU			9-14215153-1	ISU
		1-14215075-0	ISU			1-89961427-9	ISU			9-14215184-0	ISU
		1-14215103-0	ISU	24	A-6008	1-14215047-0	ISU	75	AS-1304	1-14215009-0	ISU
		1-14215126-0	ISU			1-1425-046-1	ISU			1-14215043-0	ISU
		1-14215152-0	ISU	25	A-6009	9-14215017-0	ISU			1-14215043-1	ISU
		1-14215182-0	ISU			9-14215170-0	ISU			1-14215045-0	ISU
		1-14215183-0	ISU	26	A-6010	1-14215116-0	ISU	76	AS-1502	1-14215187-0	ISU
		1-86750-310-0	ISU			1-14215117-0	ISU			5-14215007-0	ISU
		6-14215181-0	ISU	27	A-6011	1-14215128-0	ISU			5-14215033-0	ISU
		9-14215183-0	ISU			1-14215118-0	ISU			5-14215035-0	ISU
2	A-1019	8-94430250-0	ISU			1-14215127-0	ISU			8-94104273-0	ISU
3	A-1156	5-86500664-0	ISU	28	A-6012	14215-127	ISU			9-14215802-0	ISU
		5-86509144-0	ISU			5-87310455-0	ISU	77	AS-1824	15-14215007-0	ISU
4	A-1305	1-14215150-0	ISU			8-94156052-0	ISU			8970763960	ISU
5	A-1307	1-14215085-0	ISU			8-94336335-0	ISU	78	AS-1825	5-86102603-0	ISU
		1-14215085-1	ISU	29	A-6013	9-94156052-0	ISU	79	AS-2205	1-14215014-0	ISU
6	A-1313	1-14215084-0	ISU			5-14215006-0	ISU	80	AS-5412	5-14215002-0	ISU
7	A-1505	5-14215015-0	ISU			5-14215008-0	ISU	81	AS-5628	1-14215028-0	ISU
		5-14215032-0	ISU			5-14215030-0	ISU			1-14215032-0	ISU
		5-14215037-0	ISU			5-14215801-0	ISU			14215-196	ISU
		5-14215038-0	ISU			9-14215801-0	ISU			9-14215028-1	ISU
8	A-1510	8-94101769-0	ISU	30	A-6014	1-14215203-0	ISU	82	AS-5706	9-14215135-0	ISU
		8-97030325-0	ISU			1-14215203-0+1-14215217-0	ISU			9-14215135-1	ISU
		8-97173026-0	ISU	32	A-6014M	1-14215203-0	ISU			9-14215159-0	ISU
9	A-1516	8-97084323-0	ISU	33	A-6014M-S	1-14215203-0+1-14215217-0	ISU			9-14215195-0	ISU
		8-97084323-1	ISU	34	A-6015	1-14215156-0	ISU			9-14215196-0	ISU
		8-97184601-0	ISU			1-14215164-0	ISU			9-14215836-0	ISU
10	A-1826	5-86102605-0	ISU			142151560	ISU			9-14151144-1	ISU
11	A-1828	1-14215058-0	ISU	35	A-6015-S	1-14215164-0+1-14215157-0	ISU	83	AS-5707	9-14215129-0	ISU
		1-14215184-0	ISU			1-14215157-0	ISU			9-14215134-0	ISU
		6-14215184-0	ISU	36	A-6016	8-97190269-0	ISU	84	AS-5708	9-14215134-1	ISU
12	A-2210	1-14215007-0	ISU	37	A-6017	8-97190269-1	ISU			9-14215134-2	ISU
		1-14215007-2	ISU	38	A-6018	1-14215213-0	ISU			9-14215140-2	ISU
13	A-2709-S	8-98071421-0+8-98071422-0	ISU			1-14215213-0	ISU			9-14215193-1	ISU
14	A-5408	1-14215034-0	ISU	39	A-6018M	1-14215213-0	ISU	85	AS-5709	1-14215041-0	ISU
		1-14215036-0	ISU	40	A-6019	1-14215217-0	ISU			1-14215041-1	ISU
15	A-5538	8-98071422-0	ISU	41	A-6020M	8-97062294-0	ISU			9-14215012-1	ISU
		8-98071421-0	ISU	42	A-6023	1-14215220-0	ISU			9-14215019-1	ISU
16	A-5539	1-14125082-0	ISU	43	A-6024-S	1-14215213-0+1-14215220-0	ISU	86	AS-7805	9-14215140-0	ISU
17	A-5629	1-14215082-0	ISU	44	A-6024M-S	1-14215213-0+1-14215220-0	ISU			9-14215193-0	ISU
		1-14215081-0	ISU	45	A-6025-S	1-14215213-0+1-14215220-0	ISU			14215-166	ISU
18	A-5630	1-14215087-0	ISU	46	A-6026	1-14215220-0	ISU			14215166	ISU
19	A-5631	9-14215129-0	ISU	47	A-6031	1-899614279	ISU	87	AS-7813	9-14215166-1	ISU
20	A-5707	1-14215152	ISU	48	A-6036	8-98071423-0	ISU			14215166	ISU
21	A-5812	1-14214108-0	ISU	49	A-6037	8-98071424-0	ISU			9-14215166-1	ISU
22	A-6006	1-14214153-0	ISU	50	A-6038-S	8-98071423-0+8-98071424-0	ISU	88	C-1305	1-13240046-1	ISU
		1-14215060-0	ISU	51	A-6039	8-97941026-0	ISU			1-13240061-0	ISU
		1-14215067-0	ISU	52	A-60400	1-14215108-1	ISU			1-13240075-0	ISU
		1-14215077-0	ISU	53	A-60410	1-899614279	ISU			1-13240157-1	ISU
		1-14215078-0	ISU	54	A-60420	1-14215046-0	ISU	89	C-1306	2-90654-840-0	ISU
		1-14215108-1	ISU	55	A-6113	1-14215083-0	ISU			1-13240067-0	ISU
		1-14215108-2	ISU	56	A-6118-S	1-14215153-0+1-14215145-0	ISU			1-13240209-0	ISU
		1-14215112-0	ISU			1-899614278+1-899614279	ISU	90	C-1312	1-13200768-1	ISU
		1-14215134-0	ISU	57	A-61181-S	1-14215210-0	ISU			1-13240105-0	ISU
		1-14215134-1	ISU	58	A-6119M	1-3002B-182-0	ISU			X1.3201013	ISU
		1-14215153-0	ISU	59	A-6302	1-14215125-0	ISU	91	C-1316	5-86500376-0	ISU
		1-14215153-1	ISU	60	A-7607	1-14215031-0	ISU			5-86506950-0	ISU
		1-14215158-0	ISU	61	A-7608	9-14215166-1	ISU			1-132400112-0	ISU
		1-14215171-0	ISU	62	A-7805	14215-167	ISU			1-13240042-0	ISU
		1-14215172-0	ISU	63	A-7806	9-14215167-0	ISU	92	C-1319	1-13240042-1	ISU
		1-14215197-0	ISU	64	A-7967	1-14215089-0	ISU			1-13240066-0	ISU
		1-14215197-1	ISU			8-97231900-0	ISU			1-13240103-0	ISU
		1-86750124-0	ISU	65	A-8506	1142152210	ISU			1-13240131-0	ISU
		1-87310071-0	ISU	66	A-8527	1-85576450-0	ISU			1-13240162-1	ISU
		1-87310091-0	ISU	67	AC-60010	X14210031	ISU			1-13240163-0	ISU
		1-899614278	ISU	68	AH-5707	X14210031	ISU			1-13240163-1	ISU
		8-97387712-0	ISU	69	AH-6001	X14210047	ISU			1-13240163-2	ISU
		8-97520223-0	ISU	70	AH-7002	X14210048	ISU			1-87811639-0	ISU
		9-14215067-0	ISU	71	AH-7908	14215-132	ISU	93	C-1327	1-87811639-2	ISU
		1-14215061-0	ISU	72	AS-1010	9-14215132-0	ISU			8-94127546-0	ISU
23	A-6007							94	C-1501		

Sakura Filter				Sakura Number Cross Reference									
NO	SAKURA NO	ORIGINAL NO	MFR	NO	SAKURA NO	ORIGINAL NO	MFR	NO	SAKURA NO	ORIGINAL NO	MFR		
94	C-1501	8-94127546-1	ISU	109	C-1524	1-13240106-2	ISU	147	F-1303	1-87810045-0	ISU		
		8-94143205-0	ISU			1-13240106-3	ISU			1-87810124-0	ISU		
		8-94143205-3	ISU			5-87310503-0	ISU			1-87810224-0	ISU		
95	C-1502	5-13211018-0	ISU	110	C-1533	1-86750-121-0	ISU			1-87810381-0	ISU		
		5-13211018-1	ISU			1-86750-121-1	ISU			13240-029	ISU		
		5-87310337-0	ISU			8-94391049-2	ISU			5-13240012-0	ISU		
		8-94028863-0	ISU			8-97148270-1	ISU			5-13240029-0	ISU		
		8-94157399-0	ISU	8-97148270-2	ISU	7-88511119-1	ISU						
		8-94167399-0	ISU	8-97116126-0	ISU	9-13240029-0	ISU						
		8-94208863-0	ISU	113	C-1542	5-87310488-1	ISU			9-13240803-0	ISU		
96	C-1504	8-94325769-0	ISU	114	C-1548	8-97371334-0	ISU			9-88511137-0	ISU		
		8-94428931-0	ISU			5-13240041-0	ISU			9-88511137-1	ISU		
		8-94114585-0	ISU			9-13240088-0	ISU			9-88511191-1	ISU		
		8-94340259-0	ISU			9-13240093-0	ISU			9-88513111-1	ISU		
		8-94340259-1	ISU			9-13240804-0	ISU			9-88513116-0	ISU		
97	C-1505	1-13240122-0	ISU	115	C-1549	9-13240804-1	ISU	148	F-1503	1-87810207-0	ISU		
		1-13240136-0	ISU			8-9807567-6	ISU			1-87810207-1	ISU		
		1-13240160-0	ISU			8-98075676-0	ISU			1-87810207-2	ISU		
		1-13240160-1	ISU			1-13240047-0	ISU			1-87810976-0	ISU		
98	C-1506	1-13240168-1	ISU	116	C-1550	1-13240047-1	ISU	149	F-1504	1-13240008-0	ISU		
		X1.3201008	ISU			1-13240047-3	ISU			1-87810027-0	ISU		
		1-13240048-0	ISU			1-13240047-4	ISU			1-87810027-1	ISU		
		1-13240048-1	ISU	1-13240060-2	ISU	1-87810027-2	ISU						
		1-13240048-2	ISU	1-13240487-0	ISU	1-87810054-0	ISU						
		1-13240059-0	ISU	117	C-1561	8-94396375-0	ISU			1-87810071-0	ISU		
		1-13240059-1	ISU	118	C-1562	8-97096777-0	ISU			5-87810027-0	ISU		
99	C-1507	X1.3201012	ISU	119	C-15680	8-97148270-0	ISU	150	F-1505	X1.3204020	ISU		
		5-13211024-0	ISU			8-97026134-2	ISU			5-13240063-0	ISU		
		5-13211024-1	ISU			8-94456741-2	ISU			5-87810050-0	ISU		
		8-84428931-0	ISU	121	C-1701	8-94412815-0	ISU			9-13240063-0	ISU		
		8-94156455-0	ISU			8-94459700-0	ISU			151	F-1507	1-13240194-0	ISU
		8-94446750-1	ISU			8-94459700-1	ISU			152	F-15140	8-98099481-1	ISU
		8-97024607-1	ISU	122	C-1717	5-87310504-0	ISU			153	F-1805	1-13240020-0	ISU
100	C-1510	8-94338933-0	ISU			1-878121219-0	ISU			1-87810367-0	ISU		
		5-87610009-0	ISU			8-94321219-1	ISU	154	F-2604	6-11070-620-1	ISU		
101	C-1511	8-94217272-0	ISU	123	C-1802	5-13240017-0	ISU	155	F-5202	5-87810269-0	ISU		
		8-94360426-0	ISU			5-13240041-0	ISU			156	F-5214	5-87810874-0	ISU
		8-94430983-0	ISU			5-13240093-0	ISU			157	F-88040	8-98071401-0	ISU
		8-94430983-1	ISU			8-94243270-1	ISU			158	FC-1001	5-13240032-0	ISU
		8-97049708-0	ISU			8-94445272-0	ISU					8-94121431-0	ISU
		8-97049708-1	ISU			9-13240088-0	ISU					8-94177327-0	ISU
		8-94430983-1	ISU			9-13240093-0	ISU					8-94227418-0	ISU
102	C-1512	8-94152386-0	ISU			9-13240804-0	ISU			8-94238757-0	ISU		
		8-94360418-0	ISU	9-13240804-1	ISU			8-94248070-0	ISU				
		8-94360418-1	ISU	124	C-1803	5-86102409-0	ISU			8-94248070-2	ISU		
103	C-1513	8-94391049-0	ISU	125	C-2702	8-94160964-1	ISU			8-94332955-0	ISU		
		8-94391049-1	ISU			8-94321219-1	ISU			8-94369299-0	ISU		
		8-94393501-0	ISU			8-94416069-0	ISU			8-94483850-0	ISU		
		8-94396375-0	ISU			126	C-2705			1-13240232-1	ISU	159	FC-1006
104	C-1515	8-94396375-1	ISU	127	C-5101	8-97182282-0	ISU			8-94419532-0	ISU		
		8-94396375-4	ISU	128	C-5718	1-13240158-3	ISU			8-94419532-1	ISU		
		8-97520224-0	ISU			1-87310093-0	ISU			160	FC-1203	8-94369299-3	ISU
		8-94338181-0	ISU	129	C-6001	1-13240062-2	ISU			8-94369299-3A	ISU		
		8-94338181-1	ISU			1-87811638-0	ISU			8-94369929-3	ISU		
		8-97096777-0	ISU	130	C-6002	1-87409538-0	ISU			8-98002344-0	ISU		
		8-97096777-1	ISU	131	C-60030	2-90654820-0	ISU			8-98037480-0	ISU		
105	C-1518	8-97136470-0	ISU	132	C-6511	8-25171377-0	ISU			8-98037481-0	ISU		
		8-97148270-0	ISU	133	C-8019	1-32569-025-0	ISU			5-87310491-0	ISU		
		8-97247514-0	ISU	134	EF-15010	8-98147525-0	ISU			8-94393521-1	ISU		
		C-515	ISU	135	EF-1509	8-98037011-0	ISU			8-94394079-0	ISU		
106	C-1521	1-13240048-0	ISU	136	EF-15130	8-98162897-A	ISU			8-94394079-1	ISU		
		1-13240048-1	ISU			8-98092481-1	ISU			8-94394079-2	ISU		
		1-13240123-0	ISU			8-98008840-0	ISU			8-94399171-0	ISU		
		1-13240161-0	ISU			8-98143041-0	ISU			8-94399171-1	ISU		
		1-13240161-1	ISU			139	EF-2701			8-97324386-1	ISU	8-97166466-0	ISU
107	C-1522	1-13240161-2	ISU	140	EF-2702	8-98074288-0	ISU			8-97210884-0	ISU		
		2-90654600-0	ISU	8-98135462-0	ISU	8-97520227-0	ISU						
		8-97049282-0	ISU	141	EF-27050	8981527380	ISU			162	FC-1502	5-13240034-0	ISU
108	C-1523	8-97148280-0	ISU	142	EF-27060	8981527370	ISU	163	FC-1503	1-13240009-0	ISU		
		8-97019468-0	ISU	143	EFG-1001	8-97385919-0	ISU			1-13240041-0	ISU		
		8-97096778-0	ISU	144	EFG-1002	8-97606318-0	ISU			1-13240052-0	ISU		
109	C-1524	8-97148271-0	ISU	145	EFG-10030	8-97625725-0	ISU			1-13240069-0	ISU		
		1-13240106-0	ISU	146	EFG-15010	8-98002346-0	ISU			1-13240069-1	ISU		
		1-13240106-1	ISU	147	F-1303	1-87810020-0	ISU			1-13240073-0	ISU		

## Sakura Filter

## Sakura Number Cross Reference

NO	SAKURA NO	ORIGINAL NO	MFR	NO	SAKURA NO	ORIGINAL NO	MFR
163	FC-1503	1-13240074-0	ISU	177	O-1508	9-88513263-1	ISU
		1-13240079-0	ISU	178	O-1510	1-87810050-0	ISU
		1-13240674-0	ISU			1-87810050-1	ISU
164	FC-1510	8-97375981-1	ISU			1-87810050-2	ISU
165	FC-2701	1-13240068-0	ISU	179	O-1511	1-13240108-0	ISU
		1-13240069-1	ISU			1-13240239-0	ISU
		1-13240079-1	ISU			1-87802390-0	ISU
		8-94392474-0	ISU			1-87810239-0	ISU
		8-98036654-0	ISU			1-87810239-1	ISU
166	FC-2702	8-94453738-1	ISU			5-13240025-0	ISU
		8-94453738-2	ISU	180	O-1512	1-13240040-0	ISU
167	FC-5602	1-13240044-0	ISU			1-13240056-0	ISU
		X1.3240021	ISU			1132400560	ISU
168	H-5410	6630309	ISU			H32400560	ISU
169	O-1301	1-13240109-1	ISU	181	O-1514	1-87810314-0	ISU
		1-87810075-0	ISU			1-87810314-1	ISU
		1-87810075-1	ISU			1-87810314-2	ISU
		1-87810075-2	ISU			1-87810341-0	ISU
170	O-1308	1-13240116-0	ISU			1-87810358-0	ISU
		1-13240134-0	ISU	182	O-1519	1-87810372-0	ISU
		1-87810116-0	ISU			1-87810372-1	ISU
		1-87810777-0	ISU	183	O-1521	1-13240198-0	ISU
171	O-1501	5-13240036-0	ISU			1-13240198-1	ISU
		9-13240016-0	ISU			1-13240202-0	ISU
		9-13240022-0	ISU			1-13240206-0	ISU
		9-13240036-0	ISU			1-13240208-0	ISU
		9-13240801-0	ISU	184	O-1522	1-13240197-0	ISU
		9-88511166-0	ISU			1-13240200-0	ISU
		9-88512182-0	ISU			1-13240205-0	ISU
		9-88513107-0	ISU			1-13240207-0	ISU
		9-88513107-1	ISU			1-13240224-0	ISU
		9-88582151-0	ISU			1-13240241-0	ISU
172	O-1502	1-87810220-1	ISU			1-86750116-1	ISU
		113240085-0	ISU			1-87310100-1	ISU
		13240-085	ISU			8-98039914-0	ISU
		9-13240085-0	ISU	185	O-1523	1-13240077-1	ISU
		9-13240805-0	ISU	186	O-1526	1-13240114-0	ISU
		9-88511161-0	ISU	187	O-1532	1-13240-211-0	ISU
		9-88513106-0	ISU			1-13240-217-0	ISU
		9-88513106-1	ISU			1-13240-225-0	ISU
		9-88513106-2	ISU			1-13240233-0	ISU
173	O-1503	13240-085/1	ISU			1-86750-117-1	ISU
		5-87310336-0	ISU			1-87310-101-1	ISU
		5-87810239-0	ISU	188	O-1803	88513107	ISU
		5-87810293-0	ISU			9-85582125-0	ISU
		5-87810293-1	ISU			9-85582151-0	ISU
		9-13240094-0	ISU	189	SFC-5504-30	8-97605118-1	ISU
		9-88511194-0	ISU	190	SFC-5510-10	8-9802193-6	ISU
		9-88511194-1	ISU			8-98021936-0	ISU
		9-88511194-2	ISU	191	SFC-5705	1-13240044-1	ISU
		9-88511194-4	ISU				
174	O-1504	13240-045	ISU				
		9-88511116-0	ISU				
		9-88511125-0	ISU				
175	O-1505	9-13240098-0	ISU				
		9-13240106-0	ISU				
		9-13240106-1	ISU				
		9-88513264-0	ISU				
		9-88513264-1	ISU				
176	O-1506	1-87810059-0	ISU				
		1-87810059-1	ISU				
		1-87810065-0	ISU				
		8-88513265-2	ISU				
		9-13240048-0	ISU				
		9-13240067-0	ISU				
		9-13240070-0	ISU				
		9-13240107-0	ISU				
		9-88132265-1	ISU				
		9-88513265-0	ISU				
		9-88513265-2	ISU				
		9-88513265-3	ISU				
177	O-1508	9-13240058-0	ISU				
		9-13240080-0	ISU				
		9-88513263-0	ISU				

Sakura Filter				ENGINE APPLICATION				
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1	ISUZU	1971-1973/JOURNEY S	Engine: N/A			TRUCKS	C-1844	Oil Filter
2	ISUZU	330PS P-CXG19 - ISUZU 10PC1S 1983 -1986	Engine: N/A			TRUCKS	A-7967	Air Filter
3	ISUZU	330PS P-CXH19 - ISUZU 10PC1S 1983 -1986	Engine: N/A			TRUCKS	A-7967	Air Filter
4	ISUZU	330PS P-CXK19 - ISUZU 10PC1S 1983 -1986	Engine: N/A			TRUCKS	A-7967	Air Filter
5	ISUZU	330PS P-CXM19 - ISUZU 10PC1S 1983 -1986	Engine: N/A			TRUCKS	A-7967	Air Filter
6	ISUZU	330PS P-CXZ19 - ISUZU 10PC1S 1983 -1986	Engine: N/A			TRUCKS	A-7967	Air Filter
7	ISUZU	6BD1T/P-FRR11-((1984/1985))	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
8	ISUZU	810 CV-CX TRUCK-((1985/1990))	P-CVS19J			TRUCKS	A-7967	Air Filter
9	ISUZU	810 CV-CX TRUCK-((1985/1990))	P-CVS19J			TRUCKS	O-1512	Oil Filter
10	ISUZU	810 CV-CX TRUCK-((1985/1990))	P-CXW19P			TRUCKS	A-7967	Air Filter
11	ISUZU	810 CV-CX TRUCK-((1985/1990))	P-CXW19P			TRUCKS	O-1512	Oil Filter
12	ISUZU	810 CV-CX TRUCK-((1986/1987))	P-CXG19			TRUCKS	A-7967	Air Filter
13	ISUZU	810 CV-CX TRUCK-((1986/1987))	P-CXG19			TRUCKS	O-1512	Oil Filter
14	ISUZU	810 CV-CX TRUCK-((1986/1989))	P-CXH19			TRUCKS	A-7967	Air Filter
15	ISUZU	810 CV-CX TRUCK-((1986/1989))	P-CXH19			TRUCKS	O-1512	Oil Filter
16	ISUZU	810 CV-CX TRUCK-((1986/1989))	P-CXK19			TRUCKS	A-7967	Air Filter
17	ISUZU	810 CV-CX TRUCK-((1986/1989))	P-CXK19			TRUCKS	O-1512	Oil Filter
18	ISUZU	810 CV-CX TRUCK-((1986/1989))	P-CXM19			TRUCKS	A-7967	Air Filter
19	ISUZU	810 CV-CX TRUCK-((1986/1989))	P-CXM19			TRUCKS	O-1512	Oil Filter
20	ISUZU	810 CV-CX TRUCK-((1986/1989))	P-CXZ19			TRUCKS	A-7967	Air Filter
21	ISUZU	810 CV-CX TRUCK-((1986/1989))	P-CXZ19			TRUCKS	O-1512	Oil Filter
22	ISUZU	810 CV-CX TRUCK-((1987/1989))	P-CXL19			TRUCKS	A-7967	Air Filter
23	ISUZU	810 CV-CX TRUCK-((1987/1989))	P-CXL19			TRUCKS	O-1512	Oil Filter
24	ISUZU	810 CV-CX TRUCK-((1989/1994))	U-CXG71			TRUCKS	A-7967	Air Filter
25	ISUZU	810 CV-CX TRUCK-((1989/1994))	U-CXG71			TRUCKS	O-1308	Oil Filter
26	ISUZU	810 CV-CX TRUCK-((1989/1994))	U-CXH71			TRUCKS	A-7967	Air Filter
27	ISUZU	810 CV-CX TRUCK-((1989/1994))	U-CXH71			TRUCKS	O-1308	Oil Filter
28	ISUZU	810 CV-CX TRUCK-((1989/1994))	U-CXL71			TRUCKS	A-7967	Air Filter
29	ISUZU	810 CV-CX TRUCK-((1989/1994))	U-CXL71			TRUCKS	O-1308	Oil Filter
30	ISUZU	810 CV-CX TRUCK-((1989/1994))	U-CXM71			TRUCKS	A-7967	Air Filter
31	ISUZU	810 CV-CX TRUCK-((1989/1994))	U-CXM71			TRUCKS	O-1308	Oil Filter
32	ISUZU	810 CV-CX TRUCK-((1989/1994))	U-CXZ71			TRUCKS	A-7967	Air Filter
33	ISUZU	810 CV-CX TRUCK-((1989/1994))	U-CXZ71			TRUCKS	O-1308	Oil Filter
34	ISUZU	810 CV-CX TRUCK-((1989/1995))	U-CVZ71			TRUCKS	A-7967	Air Filter
35	ISUZU	810 CV-CX TRUCK-((1989/1995))	U-CVZ71			TRUCKS	O-1308	Oil Filter
36	ISUZU	810 CV-CX TRUCK-((1990/1994))	U-CXW71			TRUCKS	A-7967	Air Filter
37	ISUZU	810 CV-CX TRUCK-((1990/1994))	U-CXW71			TRUCKS	O-1308	Oil Filter
38	ISUZU	810 CV-CX TRUCK-((1990/1995))	U-CVS71J			TRUCKS	A-7967	Air Filter
39	ISUZU	810 CV-CX TRUCK-((1990/1995))	U-CVS71J			TRUCKS	O-1308	Oil Filter
40	ISUZU	810 CV-CX TRUCK-((1992/1994))	U-CXK71			TRUCKS	A-7967	Air Filter
41	ISUZU	810 CV-CX TRUCK-((1992/1994))	U-CXK71			TRUCKS	O-1308	Oil Filter
42	ISUZU	810 EX TRACTOR [ 83/08 - 86/01 ]	295PS P-EXR19 [ 10PC1-N ]	1983	1986	TRUCKS	A-1013	Air Filter
43	ISUZU	810 EX TRACTOR [ 83/08 - 86/01 ]	295PS P-EXR19 [ 10PC1-N ]	1983	1986	TRUCKS	O-1512	Oil Filter
44	ISUZU	810 EX TRACTOR [ 83/08 - 86/01 ]	295PS P-EXR19 [ 10PC1-N ]	1983	1986	TRUCKS	O-1513	Oil Filter
45	ISUZU	810 EX TRACTOR [ 83/08 - 86/01 ]	295PS P-EXZ19 [ 10PC1-N ]	1983	1986	TRUCKS	A-1013	Air Filter
46	ISUZU	810 EX TRACTOR [ 83/08 - 86/01 ]	295PS P-EXZ19 [ 10PC1-N ]	1983	1986	TRUCKS	O-1512	Oil Filter
47	ISUZU	810 EX TRACTOR [ 83/08 - 86/01 ]	295PS P-EXZ19 [ 10PC1-N ]	1983	1986	TRUCKS	O-1513	Oil Filter
48	ISUZU	810 EX TRACTOR [ 83/08 - 86/01 ]	330PS P-EXR19 [ 10PC1-S ]	1983	1986	TRUCKS	O-1512	Oil Filter
49	ISUZU	810 EX TRACTOR [ 83/08 - 86/01 ]	330PS P-EXR19 [ 10PC1-S ]	1983	1986	TRUCKS	O-1513	Oil Filter
50	ISUZU	810 EX TRACTOR [ 83/08 - 86/01 ]	330PS P-EXZ19 [ 10PC1-S ]	1983	1986	TRUCKS	O-1512	Oil Filter
51	ISUZU	810 EX TRACTOR [ 83/08 - 86/01 ]	330PS P-EXZ19 [ 10PC1-S ]	1983	1986	TRUCKS	O-1513	Oil Filter
52	ISUZU	810 EX TRACTOR [ 83/08 - 90/04 ]	P-EXR21 [ 12PC1 ]	1983	1990	TRUCKS	A-6010	Air Filter
53	ISUZU	810 EX TRACTOR [ 83/08 - 90/04 ]	P-EXR21 [ 12PC1 ]	1983	1990	TRUCKS	O-1512	Oil Filter
54	ISUZU	810 EX TRACTOR [ 83/08 - 90/04 ]	P-EXR21 [ 12PC1 ]	1983	1990	TRUCKS	O-1513	Oil Filter
55	ISUZU	810 EX TRACTOR [ 83/08 - 90/04 ]	P-EXZ71 [ 12PC1 ]	1983	1990	TRUCKS	A-6010	Air Filter
56	ISUZU	810 EX TRACTOR [ 83/08 - 90/04 ]	P-EXZ71 [ 12PC1 ]	1983	1990	TRUCKS	O-1512	Oil Filter
57	ISUZU	810 EX TRACTOR [ 83/08 - 90/04 ]	P-EXZ71 [ 12PC1 ]	1983	1990	TRUCKS	O-1513	Oil Filter

Sakura Filter					ENGINE APPLICATION			
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
58	ISUZU	810 EX TRACTOR [ 86/02 - 90/04 ]	P-EXR17 [ 8PC1 ]	1986	1990	TRUCKS	O-1512	Oil Filter
59	ISUZU	810 EX TRACTOR [ 86/02 - 90/04 ]	P-EXR17 [ 8PC1 ]	1986	1990	TRUCKS	O-1514	Oil Filter
60	ISUZU	810 EX TRACTOR [ 86/02 - 90/04 ]	P-EXR19 [ 10PC1 ]	1986	1990	TRUCKS	O-1512	Oil Filter
61	ISUZU	810 EX TRACTOR [ 86/02 - 90/04 ]	P-EXR19 [ 10PC1 ]	1986	1990	TRUCKS	O-1513	Oil Filter
62	ISUZU	810 EX TRACTOR [ 86/02 - 92/09 ]	P-EXZ19 [ 10PC1 ]	1986	1992	TRUCKS	O-1512	Oil Filter
63	ISUZU	810 EX TRACTOR [ 86/02 - 92/09 ]	P-EXZ19 [ 10PC1 ]	1986	1992	TRUCKS	O-1513	Oil Filter
64	ISUZU	810 EX TRACTOR [ 87/04 - 90/04 ]	295PS P-EXD19 [ 10PC1-N ]	1987	1990	TRUCKS	A-1013	Air Filter
65	ISUZU	810 EX TRACTOR [ 87/04 - 90/04 ]	295PS P-EXD19 [ 10PC1-N ]	1987	1990	TRUCKS	O-1512	Oil Filter
66	ISUZU	810 EX TRACTOR [ 87/04 - 90/04 ]	295PS P-EXD19 [ 10PC1-N ]	1987	1990	TRUCKS	O-1513	Oil Filter
67	ISUZU	810 EX TRACTOR [ 87/04 - 90/04 ]	330PS P-EXD19 [ 10PC1-S ]	1987	1990	TRUCKS	O-1512	Oil Filter
68	ISUZU	810 EX TRACTOR [ 87/04 - 90/04 ]	330PS P-EXD19 [ 10PC1-S ]	1987	1990	TRUCKS	O-1513	Oil Filter
69	ISUZU	810 EX TRACTOR [ 87/04 - 90/04 ]	P-EXD21 [ 12PC1 ]	1987	1990	TRUCKS	A-6010	Air Filter
70	ISUZU	810 EX TRACTOR [ 87/04 - 90/04 ]	P-EXD21 [ 12PC1 ]	1987	1990	TRUCKS	O-1512	Oil Filter
71	ISUZU	810 EX TRACTOR [ 87/04 - 90/04 ]	P-EXD21 [ 12PC1 ]	1987	1990	TRUCKS	O-1513	Oil Filter
72	ISUZU	810 EX TRACTOR [ 90/04 - 95/09 ]	W-EXD72 [ 12PD1 ]	1990	1995	TRUCKS	A-6010	Air Filter
73	ISUZU	810 EX TRACTOR [ 90/04 - 95/09 ]	W-EXD72 [ 12PD1 ]	1990	1995	TRUCKS	O-1521	Oil Filter
74	ISUZU	810 EX TRACTOR [ 90/04 - 95/09 ]	W-EXD72 [ 12PD1 ]	1990	1995	TRUCKS	O-1529	Oil Filter
75	ISUZU	810 EX TRACTOR [ 90/04 - 95/09 ]	W-EXR71 [ 10PD1 ]	1990	1995	TRUCKS	O-1522	Oil Filter
76	ISUZU	810 EX TRACTOR [ 90/04 - 95/09 ]	W-EXR71 [ 10PD1 ]	1990	1995	TRUCKS	O-1529	Oil Filter
77	ISUZU	810 EX TRACTOR [ 90/04 - 95/09 ]	W-EXR72 [ 12PD1 ]	1990	1995	TRUCKS	A-6010	Air Filter
78	ISUZU	810 EX TRACTOR [ 90/04 - 95/09 ]	W-EXR72 [ 12PD1 ]	1990	1995	TRUCKS	O-1521	Oil Filter
79	ISUZU	810 EX TRACTOR [ 90/04 - 95/09 ]	W-EXR72 [ 12PD1 ]	1990	1995	TRUCKS	O-1529	Oil Filter
80	ISUZU	810 EX TRACTOR [ 90/04 - 95/09 ]	W-EXZ71 [ 10PD1 ]	1990	1995	TRUCKS	O-1522	Oil Filter
81	ISUZU	810 EX TRACTOR [ 90/04 - 95/09 ]	W-EXZ71 [ 10PD1 ]	1990	1995	TRUCKS	O-1529	Oil Filter
82	ISUZU	810 EX TRACTOR [ 90/04 - 95/09 ]	W-EXZ72 [ 12PD1 ]	1990	1995	TRUCKS	A-6010	Air Filter
83	ISUZU	810 EX TRACTOR [ 90/04 - 95/09 ]	W-EXZ72 [ 12PD1 ]	1990	1995	TRUCKS	O-1521	Oil Filter
84	ISUZU	810 EX TRACTOR [ 90/04 - 95/09 ]	W-EXZ72 [ 12PD1 ]	1990	1995	TRUCKS	O-1529	Oil Filter
85	ISUZU	811 EX TRACTOR [ 86/02 - 90/04 ]	P-EXZ17 [ 8PC1 ]	1986	1990	TRUCKS	O-1512	Oil Filter
86	ISUZU	811 EX TRACTOR [ 86/02 - 90/04 ]	P-EXZ17 [ 8PC1 ]	1986	1990	TRUCKS	O-1514	Oil Filter
87	ISUZU	BUS	10PD1			BUSES	AS-1304	Air Filter
88	ISUZU	BUS	10PD1			BUSES	F-1503	Fuel Filter
89	ISUZU	BUS	10PD1			BUSES	O-1530	Oil Filter
90	ISUZU	BUS	10PD1			BUSES	O-1532	Oil Filter
91	ISUZU	BUS	10PE1			BUSES	A-6014	Air Filter
92	ISUZU	BUS	10PE1			BUSES	A-6014	Air Filter
93	ISUZU	BUS	10PE1			BUSES	AS-1304	Air Filter
94	ISUZU	BUS	10PE1			BUSES	F-1503	Fuel Filter
95	ISUZU	BUS	10PE1			BUSES	F-1503	Fuel Filter
96	ISUZU	BUS	10PE1			BUSES	F-1503	Fuel Filter
97	ISUZU	BUS	10PE1			BUSES	O-1530	Oil Filter
98	ISUZU	BUS	10PE1			BUSES	O-1530	Oil Filter
99	ISUZU	BUS	10PE1			BUSES	O-1530	Oil Filter
100	ISUZU	BUS	10PE1			BUSES	O-1532	Oil Filter
101	ISUZU	BUS	10PE1			BUSES	O-1532	Oil Filter
102	ISUZU	BUS	10PE1			BUSES	O-1532	Oil Filter
103	ISUZU	BUS	12PE1			BUSES	A-6014	Air Filter
104	ISUZU	BUS	12PE1			BUSES	F-1503	Fuel Filter
105	ISUZU	BUS	12PE1			BUSES	O-1530	Oil Filter
106	ISUZU	BUS	12PE1			BUSES	O-1532	Oil Filter
107	ISUZU	BUS	6HA1			BUSES	A-1013	Air Filter
108	ISUZU	BUS	6HA1			BUSES	O-1519	Oil Filter
109	ISUZU	BUS	6HA1			BUSES	O-1519	Oil Filter
110	ISUZU	BUS	6HA1			BUSES	O-1519	Oil Filter
111	ISUZU	BUS	6HA1			BUSES	O-1519	Oil Filter
112	ISUZU	BUS	6HA1			BUSES	O-1524	Oil Filter
113	ISUZU	BUS	6HA1			BUSES	O-1524	Oil Filter
114	ISUZU	BUS	6HA1			BUSES	O-1524	Oil Filter
115	ISUZU	BUS	6HA1			BUSES	O-1524	Oil Filter
116	ISUZU	BUS	6HE1			BUSES	F-1303	Fuel Filter
117	ISUZU	BUS	6HE1			BUSES	F-1303	Fuel Filter
118	ISUZU	BUS	6HE1			BUSES	O-1519	Oil Filter
119	ISUZU	BUS	6HE1			BUSES	O-1519	Oil Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
120	ISUZU	BUS	6HE1			BUSES	O-1524	Oil Filter
121	ISUZU	BUS	6HE1			BUSES	O-1524	Oil Filter
122	ISUZU	BUS	6HE1-T			BUSES	A-1013	Air Filter
123	ISUZU	BUS	6HE1-T			BUSES	FC-1301	Fuel Filter
124	ISUZU	BUS	6HE1-T			BUSES	O-1519	Oil Filter
125	ISUZU	BUS	6HE1-T			BUSES	O-1524	Oil Filter
126	ISUZU	BUS	6HF1			BUSES	A-1013	Air Filter
127	ISUZU	BUS	6HF1			BUSES	A-1013	Air Filter
128	ISUZU	BUS	6HF1			BUSES	A-1013	Air Filter
129	ISUZU	BUS	6HF1			BUSES	O-1519	Oil Filter
130	ISUZU	BUS	6HF1			BUSES	O-1519	Oil Filter
131	ISUZU	BUS	6HF1			BUSES	O-1519	Oil Filter
132	ISUZU	BUS	6HF1			BUSES	O-1524	Oil Filter
133	ISUZU	BUS	6HF1			BUSES	O-1524	Oil Filter
134	ISUZU	BUS	6HF1			BUSES	O-1524	Oil Filter
135	ISUZU	BUS	6HH1			BUSES	C-1533	Oil Filter
136	ISUZU	BUS	6HH1			BUSES	C-1533	Oil Filter
137	ISUZU	BUS	6HH1			BUSES	FC-1301	Fuel Filter
138	ISUZU	BUS	6HH1			BUSES	FC-1301	Fuel Filter
139	ISUZU	BUS	6HH1			BUSES	FC-1509	Fuel Filter
140	ISUZU	BUS	6HH1			BUSES	FC-1509	Fuel Filter
141	ISUZU	BUS	6HH1			BUSES	FC-1509	Fuel Filter
142	ISUZU	BUS	6HH1			BUSES	FC-1509	Fuel Filter
143	ISUZU	BUS	6HH1			BUSES	FC-1509	Fuel Filter
144	ISUZU	BUS	6HH1			BUSES	FC-1509	Fuel Filter
145	ISUZU	BUS	6HH1			BUSES	FC-1509	Fuel Filter
146	ISUZU	BUS	6HH1			BUSES	FC-1509	Fuel Filter
147	ISUZU	BUS	6HH1			BUSES	FC-1509	Fuel Filter
148	ISUZU	BUS	6HH1			BUSES	O-1519	Oil Filter
149	ISUZU	BUS	6HH1			BUSES	O-1519	Oil Filter
150	ISUZU	BUS	6HH1			BUSES	O-1519	Oil Filter
151	ISUZU	BUS	6HH1			BUSES	O-1519	Oil Filter
152	ISUZU	BUS	6HH1			BUSES	O-1519	Oil Filter
153	ISUZU	BUS	6HH1			BUSES	O-1519	Oil Filter
154	ISUZU	BUS	6HH1			BUSES	O-1519	Oil Filter
155	ISUZU	BUS	6HH1			BUSES	O-1519	Oil Filter
156	ISUZU	BUS	6HH1			BUSES	O-1519	Oil Filter
157	ISUZU	BUS	6HH1			BUSES	O-1524	Oil Filter
158	ISUZU	BUS	6HH1			BUSES	O-1524	Oil Filter
159	ISUZU	BUS	6HH1			BUSES	O-1524	Oil Filter
160	ISUZU	BUS	6HH1			BUSES	O-1524	Oil Filter
161	ISUZU	BUS	6HH1			BUSES	O-1524	Oil Filter
162	ISUZU	BUS	6HH1			BUSES	O-1524	Oil Filter
163	ISUZU	BUS	6HH1			BUSES	O-1524	Oil Filter
164	ISUZU	BUS	6HH1			BUSES	O-1524	Oil Filter
165	ISUZU	BUS	6HH1			BUSES	O-1524	Oil Filter
166	ISUZU	BUS	6HK1-T			BUSES	A-1013	Air Filter
167	ISUZU	BUS	6HK1-T			BUSES	A-1013	Air Filter
168	ISUZU	BUS	6HK1-T			BUSES	A-1013	Air Filter
169	ISUZU	BUS	6HK1-T			BUSES	A-1013	Air Filter
170	ISUZU	BUS	6HK1-T			BUSES	A-1013	Air Filter
171	ISUZU	BUS	6HK1-T			BUSES	A-1013	Air Filter
172	ISUZU	BUS	6HK1-T			BUSES	A-1013	Air Filter
173	ISUZU	BUS	6HK1-T			BUSES	A-1013	Air Filter
174	ISUZU	BUS	6HK1-T			BUSES	EF-1509	Fuel Filter
175	ISUZU	BUS	6HK1-T			BUSES	EF-1509	Fuel Filter
176	ISUZU	BUS	6HK1-T			BUSES	EF-1509	Fuel Filter
177	ISUZU	BUS	6HK1-T			BUSES	FC-1203	Fuel Filter
178	ISUZU	BUS	6HK1-T			BUSES	FC-1203	Fuel Filter
179	ISUZU	BUS	6HK1-T			BUSES	FC-1509	Fuel Filter
180	ISUZU	BUS	6HK1-T			BUSES	O-1519	Oil Filter
181	ISUZU	BUS	6HK1-T			BUSES	O-1519	Oil Filter
182	ISUZU	BUS	6HK1-T			BUSES	O-1519	Oil Filter
183	ISUZU	BUS	6HK1-T			BUSES	O-1519	Oil Filter



Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
184	ISUZU	BUS	6HK1-T			BUSES	O-1519	Oil Filter
185	ISUZU	BUS	6HK1-T			BUSES	O-1519	Oil Filter
186	ISUZU	BUS	6HK1-T			BUSES	O-1519	Oil Filter
187	ISUZU	BUS	6HK1-T			BUSES	O-1519	Oil Filter
188	ISUZU	BUS	6HK1-T			BUSES	O-1524	Oil Filter
189	ISUZU	BUS	6HK1-T			BUSES	O-1524	Oil Filter
190	ISUZU	BUS	6HK1-T			BUSES	O-1524	Oil Filter
191	ISUZU	BUS	6HK1-T			BUSES	O-1524	Oil Filter
192	ISUZU	BUS	6HK1-T			BUSES	O-1524	Oil Filter
193	ISUZU	BUS	6HK1-T			BUSES	O-1524	Oil Filter
194	ISUZU	BUS	6HK1-T			BUSES	O-1524	Oil Filter
195	ISUZU	BUS	6HK1-T			BUSES	O-1524	Oil Filter
196	ISUZU	BUS	6QB2			BUSES	O-1521	Oil Filter
197	ISUZU	BUS	6QB2			BUSES	O-1521	Oil Filter
198	ISUZU	BUS	6QB2			BUSES	O-1532	Oil Filter
199	ISUZU	BUS	6QB2			BUSES	O-1532	Oil Filter
200	ISUZU	BUS	6RB2			BUSES	F-1504	Fuel Filter
201	ISUZU	BUS	6RB2			BUSES	F-1504	Fuel Filter
202	ISUZU	BUS	6RB2			BUSES	O-1521	Oil Filter
203	ISUZU	BUS	6RB2			BUSES	O-1521	Oil Filter
204	ISUZU	BUS	6RB2			BUSES	O-1521	Oil Filter
205	ISUZU	BUS	6RB2			BUSES	O-1527	Oil Filter
206	ISUZU	BUS	6RB2			BUSES	O-1532	Oil Filter
207	ISUZU	BUS	6RB2			BUSES	O-1532	Oil Filter
208	ISUZU	BUS	8PD1			BUSES	AS-5707	Air Filter
209	ISUZU	BUS	8PD1			BUSES	AS-5707	Air Filter
210	ISUZU	BUS	8PD1			BUSES	F-1503	Fuel Filter
211	ISUZU	BUS	8PD1			BUSES	F-1503	Fuel Filter
212	ISUZU	BUS	8PD1			BUSES	O-1530	Oil Filter
213	ISUZU	BUS	8PD1			BUSES	O-1530	Oil Filter
214	ISUZU	BUS	8PD1			BUSES	O-1532	Oil Filter
215	ISUZU	BUS	8PD1			BUSES	O-1532	Oil Filter
216	ISUZU	BUS	8PE1			BUSES	A-1013	Air Filter
217	ISUZU	BUS	8PE1			BUSES	A-1013	Air Filter
218	ISUZU	BUS	8PE1			BUSES	A-1013	Air Filter
219	ISUZU	BUS	8PE1			BUSES	A-1013	Air Filter
220	ISUZU	BUS	8PE1			BUSES	A-1013	Air Filter
221	ISUZU	BUS	8PE1			BUSES	A-1013	Air Filter
222	ISUZU	BUS	8PE1			BUSES	A-1013	Air Filter
223	ISUZU	BUS	8PE1			BUSES	A-1013	Air Filter
224	ISUZU	BUS	8PE1			BUSES	A-6014	Air Filter
225	ISUZU	BUS	8PE1			BUSES	A-6014	Air Filter
226	ISUZU	BUS	8PE1			BUSES	AS-5707	Air Filter
227	ISUZU	BUS	8PE1			BUSES	F-1503	Fuel Filter
228	ISUZU	BUS	8PE1			BUSES	F-1503	Fuel Filter
229	ISUZU	BUS	8PE1			BUSES	F-1503	Fuel Filter
230	ISUZU	BUS	8PE1			BUSES	F-1503	Fuel Filter
231	ISUZU	BUS	8PE1			BUSES	F-1503	Fuel Filter
232	ISUZU	BUS	8PE1			BUSES	F-1503	Fuel Filter
233	ISUZU	BUS	8PE1			BUSES	F-1503	Fuel Filter
234	ISUZU	BUS	8PE1			BUSES	F-1503	Fuel Filter
235	ISUZU	BUS	8PE1			BUSES	F-1503	Fuel Filter
236	ISUZU	BUS	8PE1			BUSES	F-1503	Fuel Filter
237	ISUZU	BUS	8PE1			BUSES	F-1503	Fuel Filter
238	ISUZU	BUS	8PE1			BUSES	O-1521	Oil Filter
239	ISUZU	BUS	8PE1			BUSES	O-1521	Oil Filter
240	ISUZU	BUS	8PE1			BUSES	O-1521	Oil Filter
241	ISUZU	BUS	8PE1			BUSES	O-1521	Oil Filter
242	ISUZU	BUS	8PE1			BUSES	O-1521	Oil Filter
243	ISUZU	BUS	8PE1			BUSES	O-1521	Oil Filter
244	ISUZU	BUS	8PE1			BUSES	O-1521	Oil Filter
245	ISUZU	BUS	8PE1			BUSES	O-1521	Oil Filter
246	ISUZU	BUS	8PE1			BUSES	O-1532	Oil Filter
247	ISUZU	BUS	8PE1			BUSES	O-1532	Oil Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
248	ISUZU	BUS	8PE1			BUSES	O-1532	Oil Filter
249	ISUZU	BUS	8PE1			BUSES	O-1532	Oil Filter
250	ISUZU	BUS	8PE1			BUSES	O-1532	Oil Filter
251	ISUZU	BUS	8PE1			BUSES	O-1532	Oil Filter
252	ISUZU	BUS	8PE1			BUSES	O-1532	Oil Filter
253	ISUZU	BUS	8PE1			BUSES	O-1532	Oil Filter
254	ISUZU	BUS	8PE1			BUSES	O-1532	Oil Filter
255	ISUZU	BUS	8PE1			BUSES	O-1532	Oil Filter
256	ISUZU	BUS	8PE1			BUSES	O-1532	Oil Filter
257	ISUZU	BUS	8PE1			BUSES	O-1532	Oil Filter
258	ISUZU	BUS	8PF1			BUSES	A-1013	Air Filter
259	ISUZU	BUS	8PF1			BUSES	A-1013	Air Filter
260	ISUZU	BUS	8PF1			BUSES	A-1013	Air Filter
261	ISUZU	BUS	8PF1			BUSES	A-1013	Air Filter
262	ISUZU	BUS	8PF1			BUSES	A-1013	Air Filter
263	ISUZU	BUS	8PF1			BUSES	F-1503	Fuel Filter
264	ISUZU	BUS	8PF1			BUSES	O-1521	Oil Filter
265	ISUZU	BUS	8PF1			BUSES	O-1521	Oil Filter
266	ISUZU	BUS	8PF1			BUSES	O-1521	Oil Filter
267	ISUZU	BUS	8PF1			BUSES	O-1532	Oil Filter
268	ISUZU	BUS	8PF1			BUSES	O-1532	Oil Filter
269	ISUZU	BUS	8PF1			BUSES	O-1532	Oil Filter
270	ISUZU	BUS	8PF1			BUSES	O-1532	Oil Filter
271	ISUZU	BUS	8PF1			BUSES	O-1532	Oil Filter
272	ISUZU	BUS	8TD1			BUSES	A-6018	Air Filter
273	ISUZU	BUS	8TD1			BUSES	F-1503	Fuel Filter
274	ISUZU	BUS	8TD1			BUSES	O-1530	Oil Filter
275	ISUZU	BUS	8TD1			BUSES	O-1532	Oil Filter
276	ISUZU	BUS	J08E-T			BUSES	C-1316	Oil Filter
277	ISUZU	BUS	J08E-T			BUSES	C-1316	Oil Filter
278	ISUZU	BUS	J08E-T			BUSES	C-1316	Oil Filter
279	ISUZU	BUS	J08E-T			BUSES	C-1316	Oil Filter
280	ISUZU	BUS [ 00/05 - ]	KL-LV380 [ 8PE1 ]	2000		BUSES	A-1013	Air Filter
281	ISUZU	BUS [ 00/05 - ]	KL-LV380 [ 8PE1 ]	2000		BUSES	O-1521	Oil Filter
282	ISUZU	BUS [ 00/05 - ]	KL-LV380 [ 8PE1 ]	2000		BUSES	O-1529	Oil Filter
283	ISUZU	BUS [ 00/05 - ]	KL-LV774 [ 8TD1 ]	2000		BUSES	A-6018	Air Filter
284	ISUZU	BUS [ 00/05 - ]	KL-LV774 [ 8TD1 ]	2000		BUSES	O-1522	Oil Filter
285	ISUZU	BUS [ 00/05 - ]	KL-LV774 [ 8TD1 ]	2000		BUSES	O-1529	Oil Filter
286	ISUZU	BUS [ 00/05 - ]	KL-LV780 [ 8PE1 ]	2000		BUSES	A-6014	Air Filter
287	ISUZU	BUS [ 00/05 - ]	KL-LV780 [ 8PE1 ]	2000		BUSES	O-1529	Oil Filter
288	ISUZU	BUS [ 00/05 - ]	TURBO KL-LV834 [ 6HK1(T) ]	2000		BUSES	A-1013	Air Filter
289	ISUZU	BUS [ 00/05 - ]	TURBO KL-LV834 [ 6HK1(T) ]	2000		BUSES	FC-1509	Fuel Filter
290	ISUZU	BUS [ 00/05 - ]	TURBO KL-LV834 [ 6HK1(T) ]	2000		BUSES	O-1519	Oil Filter
291	ISUZU	BUS [ 00/05 - ]	TURBO KL-LV834 [ 6HK1(T) ]	2000		BUSES	O-1524	Oil Filter
292	ISUZU	BUS [ 00/06 - ]	KL-LV280 [ 8PE1 ]	2000		BUSES	A-1013	Air Filter
293	ISUZU	BUS [ 00/06 - ]	KL-LV280 [ 8PE1 ]	2000		BUSES	O-1521	Oil Filter
294	ISUZU	BUS [ 00/06 - ]	KL-LV280 [ 8PE1 ]	2000		BUSES	O-1529	Oil Filter
295	ISUZU	BUS [ 00/06 - ]	KL-LV781 [ 10PE1 ]	2000		BUSES	A-6014	Air Filter
296	ISUZU	BUS [ 00/06 - ]	KL-LV781 [ 10PE1 ]	2000		BUSES	O-1522	Oil Filter
297	ISUZU	BUS [ 00/06 - ]	KL-LV781 [ 10PE1 ]	2000		BUSES	O-1529	Oil Filter
298	ISUZU	BUS [ 05/01 ]	LR PA-LR234J1 [ 6HK1-T (TB) ]	2005		BUSES	C-1533	Oil Filter
299	ISUZU	BUS [ 84/04 - 89/10 ]	P-LV214 [ 6QA2 ]	1984	1989	BUSES	O-1512	Oil Filter
300	ISUZU	BUS [ 84/04 - 89/10 ]	P-LV214 [ 6QA2 ]	1984	1989	BUSES	O-1514	Oil Filter
301	ISUZU	BUS [ 84/04 - 89/10 ]	P-LV314 [ 6QA2 ]	1984	1989	BUSES	O-1512	Oil Filter
302	ISUZU	BUS [ 84/04 - 89/10 ]	P-LV314 [ 6QA2 ]	1984	1989	BUSES	O-1514	Oil Filter
303	ISUZU	BUS [ 84/04 - 89/10 ]	P-LV318 [ 6RB2 ]	1984	1989	BUSES	O-1512	Oil Filter
304	ISUZU	BUS [ 84/04 - 89/10 ]	P-LV318 [ 6RB2 ]	1984	1989	BUSES	O-1514	Oil Filter
305	ISUZU	BUS [ 84/04 - 89/10 ]	U(P)-LV218 [ 6RB2 ]	1984	1989	BUSES	O-1512	Oil Filter
306	ISUZU	BUS [ 84/04 - 89/10 ]	U(P)-LV218 [ 6RB2 ]	1984	1989	BUSES	O-1514	Oil Filter
307	ISUZU	BUS [ 84/04 - 90/05 ]	P-LV217 [ 8PC1-N ]	1984	1990	BUSES	AS-5707	Air Filter
308	ISUZU	BUS [ 84/04 - 90/05 ]	P-LV217 [ 8PC1-N ]	1984	1990	BUSES	O-1512	Oil Filter
309	ISUZU	BUS [ 84/04 - 90/05 ]	P-LV217 [ 8PC1-N ]	1984	1990	BUSES	O-1514	Oil Filter



Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
310	ISUZU	BUS [ 84/04 - 90/05 ]	P-LV219 [ 10PC1 ]	1984	1990	BUSES	AS-5707	Air Filter
311	ISUZU	BUS [ 84/04 - 90/05 ]	P-LV219 [ 10PC1 ]	1984	1990	BUSES	O-1512	Oil Filter
312	ISUZU	BUS [ 84/04 - 90/05 ]	P-LV219 [ 10PC1 ]	1984	1990	BUSES	O-1513	Oil Filter
313	ISUZU	BUS [ 84/04 - 90/05 ]	P-LV719 [ 10PC1 ]	1984	1990	BUSES	O-1512	Oil Filter
314	ISUZU	BUS [ 84/04 - 90/05 ]	P-LV719 [ 10PC1 ]	1984	1990	BUSES	O-1513	Oil Filter
315	ISUZU	BUS [ 84/04 - 90/06 ]	U(P)-LT312 [ 6BG1 ]	1984	1990	BUSES	O-1301	Oil Filter
316	ISUZU	BUS [ 84/04 - 90/06 ]	U(P)-LT312 [ 6BG1 ]	1984	1990	BUSES	O-1511	Oil Filter
317	ISUZU	BUS [ 88/01 - 90/06 ]	P-LR211 [ 6BD1 ]	1988	1990	BUSES	O-1301	Oil Filter
318	ISUZU	BUS [ 88/01 - 90/06 ]	P-LR211 [ 6BD1 ]	1988	1990	BUSES	O-1511	Oil Filter
319	ISUZU	BUS [ 89/11 - 95/05 ]	U(P)-LV218 [ 6RB2 ]	1989	1995	BUSES	O-1529	Oil Filter
320	ISUZU	BUS [ 89/11 - 95/05 ]	U-LV224 [ 6QB2 ]	1989	1995	BUSES	O-1529	Oil Filter
321	ISUZU	BUS [ 89/11 - 95/05 ]	U-LV318 [ 6RB2 ]	1989	1995	BUSES	O-1529	Oil Filter
322	ISUZU	BUS [ 89/11 - 95/05 ]	U-LV324 [ 6QB2 ]	1989	1995	BUSES	O-1529	Oil Filter
323	ISUZU	BUS [ 90/06 - 95/02 ]	U-LV771 [ 10PD1 ]	1990	1995	BUSES	O-1522	Oil Filter
324	ISUZU	BUS [ 90/06 - 95/02 ]	U-LV771 [ 10PD1 ]	1990	1995	BUSES	O-1529	Oil Filter
325	ISUZU	BUS [ 90/06 - 95/05 ]	U-LV270 [ 8PD1 ]	1990	1995	BUSES	AS-5707	Air Filter
326	ISUZU	BUS [ 90/06 - 95/05 ]	U-LV270 [ 8PD1 ]	1990	1995	BUSES	O-1522	Oil Filter
327	ISUZU	BUS [ 90/06 - 95/05 ]	U-LV270 [ 8PD1 ]	1990	1995	BUSES	O-1529	Oil Filter
328	ISUZU	BUS [ 90/07 - 95/07 ]	U-LR232 [ 6HE1 ]	1990	1995	BUSES	O-1519	Oil Filter
329	ISUZU	BUS [ 90/07 - 95/07 ]	U-LR232 [ 6HE1 ]	1990	1995	BUSES	O-1524	Oil Filter
330	ISUZU	BUS [ 90/07 - 95/07 ]	U-LT332 [ 6HE1 ]	1990	1995	BUSES	O-1519	Oil Filter
331	ISUZU	BUS [ 90/07 - 95/07 ]	U-LT332 [ 6HE1 ]	1990	1995	BUSES	O-1524	Oil Filter
332	ISUZU	BUS [ 92/09 - 95/03 ]	U-LV870 [ 8PD1 ]	1992	1995	BUSES	AS-5707	Air Filter
333	ISUZU	BUS [ 92/09 - 95/03 ]	U-LV870 [ 8PD1 ]	1992	1995	BUSES	O-1522	Oil Filter
334	ISUZU	BUS [ 92/09 - 95/03 ]	U-LV870 [ 8PD1 ]	1992	1995	BUSES	O-1529	Oil Filter
335	ISUZU	BUS [ 95/02 - 96/10 ]	KC-LV781 [ 10PE1 ]	1995	1996	BUSES	O-1522	Oil Filter
336	ISUZU	BUS [ 95/02 - 96/10 ]	KC-LV781 [ 10PE1 ]	1995	1996	BUSES	O-1529	Oil Filter
337	ISUZU	BUS [ 95/04 - 00/05 ]	KC-LV380 [ 8PE1 ]	1995	2000	BUSES	A-1013	Air Filter
338	ISUZU	BUS [ 95/04 - 00/05 ]	KC-LV380 [ 8PE1 ]	1995	2000	BUSES	O-1521	Oil Filter
339	ISUZU	BUS [ 95/04 - 00/05 ]	KC-LV380 [ 8PE1 ]	1995	2000	BUSES	O-1529	Oil Filter
340	ISUZU	BUS [ 95/04 - 00/06 ]	KC-LV280L [ 8PE1 ]	1995	2000	BUSES	A-1013	Air Filter
341	ISUZU	BUS [ 95/04 - 00/06 ]	KC-LV280L [ 8PE1 ]	1995	2000	BUSES	O-1521	Oil Filter
342	ISUZU	BUS [ 95/04 - 00/06 ]	KC-LV280L [ 8PE1 ]	1995	2000	BUSES	O-1529	Oil Filter
343	ISUZU	BUS [ 95/04 - 00/06 ]	KC-LV280N [ 8PE1 ]	1995	2000	BUSES	A-1013	Air Filter
344	ISUZU	BUS [ 95/04 - 00/06 ]	KC-LV280N [ 8PE1 ]	1995	2000	BUSES	O-1521	Oil Filter
345	ISUZU	BUS [ 95/04 - 00/06 ]	KC-LV280N [ 8PE1 ]	1995	2000	BUSES	O-1529	Oil Filter
346	ISUZU	BUS [ 95/04 - 00/06 ]	KC-LV280Q [ 8PE1 ]	1995	2000	BUSES	A-1013	Air Filter
347	ISUZU	BUS [ 95/04 - 00/06 ]	KC-LV280Q [ 8PE1 ]	1995	2000	BUSES	O-1521	Oil Filter
348	ISUZU	BUS [ 95/04 - 00/06 ]	KC-LV280Q [ 8PE1 ]	1995	2000	BUSES	O-1529	Oil Filter
349	ISUZU	BUS [ 95/06 - ]	KC-LV880 [ 8PE1 ]	1995		BUSES	A-1013	Air Filter
350	ISUZU	BUS [ 95/06 - ]	KC-LV880 [ 8PE1 ]	1995		BUSES	O-1521	Oil Filter
351	ISUZU	BUS [ 95/06 - ]	KC-LV880 [ 8PE1 ]	1995		BUSES	O-1529	Oil Filter
352	ISUZU	BUS [ 95/06 - 00/06 ]	KC-LV280H [ 8PE1 ]	1995	2000	BUSES	AS-5707	Air Filter
353	ISUZU	BUS [ 95/06 - 00/06 ]	KC-LV280H [ 8PE1 ]	1995	2000	BUSES	O-1529	Oil Filter
354	ISUZU	BUS [ 95/07 - 99/05 ]	KC-LT233 [ 6HH1 ]	1995	1999	BUSES	FC-1301	Fuel Filter
355	ISUZU	BUS [ 95/07 - 99/05 ]	KC-LT233 [ 6HH1 ]	1995	1999	BUSES	O-1519	Oil Filter
356	ISUZU	BUS [ 95/07 - 99/05 ]	KC-LT233 [ 6HH1 ]	1995	1999	BUSES	O-1524	Oil Filter
357	ISUZU	BUS [ 95/07 - 99/05 ]	KC-LT333 [ 6HH1 ]	1995	1999	BUSES	FC-1301	Fuel Filter
358	ISUZU	BUS [ 95/07 - 99/05 ]	KC-LT333 [ 6HH1 ]	1995	1999	BUSES	O-1519	Oil Filter
359	ISUZU	BUS [ 95/07 - 99/05 ]	KC-LT333 [ 6HH1 ]	1995	1999	BUSES	O-1524	Oil Filter
360	ISUZU	BUS [ 96/03 - ]	NATURAL GAS NE-LV288 [ 8PF1 ]	1996		BUSES	A-1013	Air Filter
361	ISUZU	BUS [ 96/03 - ]	NATURAL GAS NE-LV288 [ 8PF1 ]	1996		BUSES	O-1521	Oil Filter
362	ISUZU	BUS [ 96/03 - ]	NATURAL GAS NE-LV288 [ 8PF1 ]	1996		BUSES	O-1529	Oil Filter
363	ISUZU	BUS [ 96/10 - ]	KC-LV780 [ 8PE1 ]	1996		BUSES	A-6014	Air Filter
364	ISUZU	BUS [ 96/10 - ]	KC-LV780 [ 8PE1 ]	1996		BUSES	O-1529	Oil Filter
365	ISUZU	BUS [ 96/10 - ]	KC-LV781 [ 10PE1 ]	1996		BUSES	A-6014	Air Filter
366	ISUZU	BUS [ 96/10 - ]	KC-LV781 [ 10PE1 ]	1996		BUSES	O-1522	Oil Filter
367	ISUZU	BUS [ 96/10 - ]	KC-LV781 [ 10PE1 ]	1996		BUSES	O-1529	Oil Filter
368	ISUZU	BUS [ 96/10 - ]	KC-LV782 [ 12PE1 ]	1996		BUSES	A-6014	Air Filter
369	ISUZU	BUS [ 96/10 - ]	KC-LV782 [ 12PE1 ]	1996		BUSES	O-1522	Oil Filter
370	ISUZU	BUS [ 96/10 - ]	KC-LV782 [ 12PE1 ]	1996		BUSES	O-1529	Oil Filter
371	ISUZU	BUS [ 98/10 - ]	KC-LVB32 [ 6HE1 ]	1998		BUSES	A-1013	Air Filter
372	ISUZU	BUS [ 98/10 - ]	KC-LVB32 [ 6HE1 ]	1998		BUSES	FC-1301	Fuel Filter

Sakura Filter					ENGINE APPLICATION			
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
373	ISUZU	BUS [ 98/10 - ]	KC-LVB32 [ 6HE1 ]	1998		BUSES	O-1519	Oil Filter
374	ISUZU	BUS [ 98/10 - ]	KC-LVB32 [ 6HE1 ]	1998		BUSES	O-1524	Oil Filter
375	ISUZU	BUS [ 99/03 - ]	NATURAL GAS NE-LV388 [ 8PF1 ]	1999		BUSES	A-1013	Air Filter
376	ISUZU	BUS [ 99/03 - ]	NATURAL GAS NE-LV388 [ 8PF1 ]	1999		BUSES	O-1521	Oil Filter
377	ISUZU	BUS [ 99/03 - ]	NATURAL GAS NE-LV388 [ 8PF1 ]	1999		BUSES	O-1529	Oil Filter
378	ISUZU	BUS [ 99/05 - ]	KK-LR233E1 [ 6HH1 ]	1999		BUSES	C-1513	Oil Filter
379	ISUZU	BUS [ 99/05 - ]	KK-LR233E1 [ 6HH1 ]	1999		BUSES	FC-1509	Fuel Filter
380	ISUZU	BUS [ 99/05 - ]	KK-LR233F1 [ 6HH1 ]	1999		BUSES	FC-1509	Fuel Filter
381	ISUZU	BUS [ 99/05 - ]	KK-LR233F1 [ 6HH1 ]	1999		BUSES	O-1519	Oil Filter
382	ISUZU	BUS [ 99/05 - ]	KK-LR233F1 [ 6HH1 ]	1999		BUSES	O-1524	Oil Filter
383	ISUZU	BUS [ 99/05 - ]	KK-LR233J1 [ 6HH1 ]	1999		BUSES	FC-1509	Fuel Filter
384	ISUZU	BUS [ 99/05 - ]	KK-LR233J1 [ 6HH1 ]	1999		BUSES	O-1519	Oil Filter
385	ISUZU	BUS [ 99/05 - ]	KK-LR233J1 [ 6HH1 ]	1999		BUSES	O-1524	Oil Filter
386	ISUZU	BUS [ 99/05 - ]	KK-LR333EI [ 6HH1 ]	1999		BUSES	C-1513	Oil Filter
387	ISUZU	BUS [ 99/05 - ]	KK-LR333EI [ 6HH1 ]	1999		BUSES	FC-1509	Fuel Filter
388	ISUZU	BUS [ 99/05 - ]	KK-LR333F1 [ 6HH1 ]	1999		BUSES	FC-1509	Fuel Filter
389	ISUZU	BUS [ 99/05 - ]	KK-LR333F1 [ 6HH1 ]	1999		BUSES	O-1519	Oil Filter
390	ISUZU	BUS [ 99/05 - ]	KK-LR333F1 [ 6HH1 ]	1999		BUSES	O-1524	Oil Filter
391	ISUZU	BUS [ 99/05 - ]	KK-LR333J1 [ 6HH1 ]	1999		BUSES	FC-1509	Fuel Filter
392	ISUZU	BUS [ 99/05 - ]	KK-LR333J1 [ 6HH1 ]	1999		BUSES	O-1519	Oil Filter
393	ISUZU	BUS [ 99/05 - ]	KK-LR333J1 [ 6HH1 ]	1999		BUSES	O-1524	Oil Filter
394	ISUZU	BUS [ 99/05 - ]	NATURAL GAS KK-LR233?1 [ 6HA1 ]	1999		BUSES	O-1519	Oil Filter
395	ISUZU	BUS [ 99/05 - ]	NATURAL GAS KK-LR233?1 [ 6HA1 ]	1999		BUSES	O-1524	Oil Filter
396	ISUZU	BUS [ 99/05 - ]	NATURAL GAS KK-LR233F1 [ 6HA1 ]	1999		BUSES	O-1519	Oil Filter
397	ISUZU	BUS [ 99/05 - ]	NATURAL GAS KK-LR233F1 [ 6HA1 ]	1999		BUSES	O-1524	Oil Filter
398	ISUZU	BUS [ 99/05 - ]	NATURAL GAS KK-LR333J1 [ 6HA1 ]	1999		BUSES	O-1519	Oil Filter
399	ISUZU	BUS [ 99/05 - ]	NATURAL GAS KK-LR333J1 [ 6HA1 ]	1999		BUSES	O-1524	Oil Filter
400	ISUZU	BUS [ 99/06 - ]	KK-LT233 [ 6HH1 ]	1999		BUSES	FC-1509	Fuel Filter
401	ISUZU	BUS [ 99/06 - ]	KK-LT233 [ 6HH1 ]	1999		BUSES	O-1519	Oil Filter
402	ISUZU	BUS [ 99/06 - ]	KK-LT233 [ 6HH1 ]	1999		BUSES	O-1524	Oil Filter
403	ISUZU	BUS [ 99/06 - ]	KK-LT333 [ 6HH1 ]	1999		BUSES	FC-1509	Fuel Filter
404	ISUZU	BUS [ 99/06 - ]	KK-LT333 [ 6HH1 ]	1999		BUSES	O-1519	Oil Filter
405	ISUZU	BUS [ 99/06 - ]	KK-LT333 [ 6HH1 ]	1999		BUSES	O-1524	Oil Filter
406	ISUZU	CJA470 - ISUZU 6QA2 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
407	ISUZU	CJA500 - ISUZU 6QA2 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
408	ISUZU	CJA520 - ISUZU 6QA2 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
409	ISUZU	CJA550 - ISUZU 6QA2 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
410	ISUZU	CJA600 - ISUZU 6QA2 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
411	ISUZU	CJM470 - ISUZU 6QA2 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
412	ISUZU	CJM490 - ISUZU 6QA2 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
413	ISUZU	CJM500 - ISUZU 6QA2 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
414	ISUZU	CJM520 - ISUZU 6QA2 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
415	ISUZU	CJM600 - ISUZU 6QA2 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
416	ISUZU	CLA470 - ISUZU DH100H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
417	ISUZU	CLA500 - ISUZU DH100H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
418	ISUZU	CLM470 - ISUZU DH100H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
419	ISUZU	CLM490 - ISUZU DH100H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
420	ISUZU	CLM500 - ISUZU DH100H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
421	ISUZU	CLM520 - ISUZU DH100H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
422	ISUZU	CLM600 - ISUZU DH100H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
423	ISUZU	CPA470 - ISUZU E120H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
424	ISUZU	CPA500 - ISUZU E120H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
425	ISUZU	CPA520 - ISUZU E120H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
426	ISUZU	CPA550 - ISUZU E120H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
427	ISUZU	CPA600 - ISUZU E120H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
428	ISUZU	CPM470 - ISUZU E120H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
429	ISUZU	CPM500 - ISUZU E120H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
430	ISUZU	CPM520 - ISUZU E120H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
431	ISUZU	CPM550 - ISUZU E120H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
432	ISUZU	CPM600 - ISUZU E120H 1980 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter

Sakura Filter							ENGINE APPLICATION	
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
433	ISUZU	CQA500 - ISUZU 6RB2 1982 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
434	ISUZU	CQA520 - ISUZU 6RB2 1982 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
435	ISUZU	CQA550 - ISUZU 6RB2 1982 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
436	ISUZU	CQA600 - ISUZU 6RB2 1982 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
437	ISUZU	CQM470 - ISUZU 6RB2 1982 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
438	ISUZU	CQM500 - ISUZU 6RB2 1982 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
439	ISUZU	CQM520 - ISUZU 6RB2 1982 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
440	ISUZU	CQM550 - ISUZU 6RB2 1982 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
441	ISUZU	CRA580 - ISUZU 10PA1 1975 -1979	Engine: N/A			TRUCKS	O-1510	Oil Filter
442	ISUZU	CRA580 - ISUZU 10PA1 1979 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
443	ISUZU	CRA650 - ISUZU 10PA1 1975 -1979	Engine: N/A			TRUCKS	O-1510	Oil Filter
444	ISUZU	CRA650 - ISUZU 10PA1 1979 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
445	ISUZU	CREW CAB/NPR400 -([N/A])	N/A			TRUCKS	C-1515	Oil Filter
446	ISUZU	CREW CAB/NPR400 -([N/A])	N/A			TRUCKS	FC-1509	Fuel Filter
447	ISUZU	CSA580 - ISUZU 10PB1 1979 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
448	ISUZU	CSA650 - ISUZU 10PB1 1979 -1984	Engine: N/A			TRUCKS	O-1510	Oil Filter
449	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	F-1503	Fuel Filter
450	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	F-1503	Fuel Filter
451	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	F-1503	Fuel Filter
452	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	F-1503	Fuel Filter
453	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	F-1503	Fuel Filter
454	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	F-1503	Fuel Filter
455	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	F-1503	Fuel Filter
456	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	F-1503	Fuel Filter
457	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	F-1503	Fuel Filter
458	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1530	Oil Filter
459	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1530	Oil Filter
460	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1530	Oil Filter
461	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1530	Oil Filter
462	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1530	Oil Filter
463	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1530	Oil Filter
464	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1530	Oil Filter
465	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1530	Oil Filter
466	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1530	Oil Filter
467	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1532	Oil Filter
468	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1532	Oil Filter
469	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1532	Oil Filter
470	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1532	Oil Filter
471	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1532	Oil Filter
472	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1532	Oil Filter
473	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1532	Oil Filter
474	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1532	Oil Filter
475	ISUZU	CV#/CX# TRUCK	10PD1			TRUCKS	O-1532	Oil Filter
476	ISUZU	CV#/CX# TRUCK	12PD1			TRUCKS	F-1503	Fuel Filter
477	ISUZU	CV#/CX# TRUCK	12PD1			TRUCKS	F-1503	Fuel Filter
478	ISUZU	CV#/CX# TRUCK	12PD1			TRUCKS	O-1521	Oil Filter
479	ISUZU	CV#/CX# TRUCK	12PD1			TRUCKS	O-1530	Oil Filter
480	ISUZU	CV#/CX# TRUCK	12PD1			TRUCKS	O-1532	Oil Filter
481	ISUZU	CV#/CX# TRUCK	12PD1			TRUCKS	O-1532	Oil Filter
482	ISUZU	CV#/CX# TRUCK	2PD1			TRUCKS	F-1503	Fuel Filter
483	ISUZU	CV#/CX# TRUCK	2PD1			TRUCKS	O-1521	Oil Filter
484	ISUZU	CV#/CX# TRUCK	2PD1			TRUCKS	O-1532	Oil Filter
485	ISUZU	CV#/CX# TRUCK	6RB1-T			TRUCKS	F-1503	Fuel Filter
486	ISUZU	CV#/CX# TRUCK	6RB1-T			TRUCKS	F-1503	Fuel Filter
487	ISUZU	CV#/CX# TRUCK	6RB1-T			TRUCKS	O-1525	Oil Filter
488	ISUZU	CV#/CX# TRUCK	6RB1-T			TRUCKS	O-1525	Oil Filter
489	ISUZU	CV#/CX# TRUCK	6RB1-T			TRUCKS	O-1526	Oil Filter
490	ISUZU	CV#/CX# TRUCK	6RB1-T			TRUCKS	O-1526	Oil Filter
491	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
492	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
493	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
494	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
495	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
496	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter

Sakura Filter							ENGINE APPLICATION	
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
497	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
498	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
499	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	O-1526	Oil Filter
500	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	O-1526	Oil Filter
501	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	O-1526	Oil Filter
502	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	O-1526	Oil Filter
503	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	O-1526	Oil Filter
504	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	O-1530	Oil Filter
505	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	O-1530	Oil Filter
506	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	O-1530	Oil Filter
507	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	O-1532	Oil Filter
508	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	O-1532	Oil Filter
509	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	O-1532	Oil Filter
510	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	O-1532	Oil Filter
511	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	O-1532	Oil Filter
512	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	O-1532	Oil Filter
513	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	O-1532	Oil Filter
514	ISUZU	CV#/CX# TRUCK	6SD1-T			TRUCKS	O-1532	Oil Filter
515	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	A-6014	Air Filter
516	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	A-6014	Air Filter
517	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	A-6014	Air Filter
518	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	A-6014	Air Filter
519	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	A-6014	Air Filter
520	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	F-1503	Fuel Filter
521	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	F-1503	Fuel Filter
522	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	F-1503	Fuel Filter
523	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	F-1503	Fuel Filter
524	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	F-1503	Fuel Filter
525	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	O-1530	Oil Filter
526	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	O-1530	Oil Filter
527	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	O-1530	Oil Filter
528	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	O-1530	Oil Filter
529	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	O-1530	Oil Filter
530	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	O-1532	Oil Filter
531	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	O-1532	Oil Filter
532	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	O-1532	Oil Filter
533	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	O-1532	Oil Filter
534	ISUZU	CV#/CX# TRUCK	6WA1-T			TRUCKS	O-1532	Oil Filter
535	ISUZU	CV#/CX# TRUCK	8PD1			TRUCKS	F-1503	Fuel Filter
536	ISUZU	CV#/CX# TRUCK	8PD1			TRUCKS	F-1503	Fuel Filter
537	ISUZU	CV#/CX# TRUCK	8PD1			TRUCKS	F-1503	Fuel Filter
538	ISUZU	CV#/CX# TRUCK	8PD1			TRUCKS	F-1503	Fuel Filter
539	ISUZU	CV#/CX# TRUCK	8PD1			TRUCKS	F-1503	Fuel Filter
540	ISUZU	CV#/CX# TRUCK	8PD1			TRUCKS	O-1528	Oil Filter
541	ISUZU	CV#/CX# TRUCK	8PD1			TRUCKS	O-1530	Oil Filter
542	ISUZU	CV#/CX# TRUCK	8PD1			TRUCKS	O-1530	Oil Filter
543	ISUZU	CV#/CX# TRUCK	8PD1			TRUCKS	O-1530	Oil Filter
544	ISUZU	CV#/CX# TRUCK	8PD1			TRUCKS	O-1530	Oil Filter
545	ISUZU	CV#/CX# TRUCK	8PD1			TRUCKS	O-1532	Oil Filter
546	ISUZU	CV#/CX# TRUCK	8PD1			TRUCKS	O-1532	Oil Filter
547	ISUZU	CV#/CX# TRUCK	8PD1			TRUCKS	O-1532	Oil Filter
548	ISUZU	CV#/CX# TRUCK	8PD1			TRUCKS	O-1532	Oil Filter
549	ISUZU	CV#/CX# TRUCK	8PD1			TRUCKS	O-1532	Oil Filter
550	ISUZU	CVR - ISUZU 8PC1 1986 -1989	Engine: N/A			TRUCKS	A-7967	Air Filter
551	ISUZU	CVR6MF -	Engine: N/A			TRUCKS	A-7967	Air Filter
552	ISUZU	CXG - ISUZU 10PC1 1986 -1989	Engine: N/A			TRUCKS	A-7967	Air Filter
553	ISUZU	CXG - ISUZU 10PCS 1983 -1986	Engine: N/A			TRUCKS	A-7967	Air Filter
554	ISUZU	CXG - ISUZU 8PC1 1983 -1986	Engine: N/A			TRUCKS	A-7967	Air Filter
555	ISUZU	CXH - ISUZU 10PC1 1986 -1989	Engine: N/A			TRUCKS	A-7967	Air Filter
556	ISUZU	CXH - ISUZU 10PCS 1983 -1986	Engine: N/A			TRUCKS	A-7967	Air Filter
557	ISUZU	CKX - ISUZU 10PC1 1986 -1989	Engine: N/A			TRUCKS	A-7967	Air Filter
558	ISUZU	CKX - ISUZU 10PCS 1983 -1986	Engine: N/A			TRUCKS	A-7967	Air Filter
559	ISUZU	CKX - ISUZU 8PC1 1983 -1986	Engine: N/A			TRUCKS	A-7967	Air Filter
560	ISUZU	CXM - ISUZU 10PC1 1986 -1989	Engine: N/A			TRUCKS	A-7967	Air Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
561	ISUZU	CXM - ISUZU 10PCS 1983 -1986	Engine: N/A			TRUCKS	A-7967	Air Filter
562	ISUZU	CXM - ISUZU 8PC1 1983 -1986	Engine: N/A			TRUCKS	A-7967	Air Filter
563	ISUZU	CXZ - ISUZU 10PC1 1986 -1989	Engine: N/A			TRUCKS	A-7967	Air Filter
564	ISUZU	CXZ - ISUZU 10PCS 1983 -1986	Engine: N/A			TRUCKS	A-7967	Air Filter
565	ISUZU	CXZ51K	6WF1-TC, 6WA1-TC			TRUCKS	AC-60010	Air Filter
566	ISUZU	CXZ81K	6WF1-TC, 6WA1-TC			TRUCKS	AC-60010	Air Filter
567	ISUZU	CYZ51K	6WF1-TC			TRUCKS	AC-60010	Air Filter
568	ISUZU	ECR570S -	Engine: N/A			TRUCKS	A-6007	Air Filter
569	ISUZU	ELF (NKR) [ 04/05 ]	4300 PB-NKR81 [ 4HF1 ]	2004		TRUCKS	A-6017	Air Filter
570	ISUZU	ELF (NKR) [ 04/05 ]	4300 PB-NKR81 [ 4HF1 ]	2004		TRUCKS	C-1534	Oil Filter
571	ISUZU	ELF (NKR) [ 04/05 ]	4600 PB-NKR81 [ 4HG1 ]	2004		TRUCKS	A-6017	Air Filter
572	ISUZU	ELF (NKR) [ 04/05 ]	4600 PB-NKR81 [ 4HG1 ]	2004		TRUCKS	C-1534	Oil Filter
573	ISUZU	ELF (NKR) [ 04/05 ]	4800 PB-NKR81 [ 4HF1 ]	2004		TRUCKS	A-6017	Air Filter
574	ISUZU	ELF (NKR) [ 04/05 ]	4800 PB-NKR81 [ 4HF1 ]	2004		TRUCKS	C-1534	Oil Filter
575	ISUZU	ELF (NKR) [ 04/05 ]	4800 PB-NKR81 [ 4HF1 ]	2004		TRUCKS	FC-1203	Fuel Filter
576	ISUZU	ELF (NKS) [ 04/06 ]	4800 4WD PB-NKS81E [ 4HL1 ]	2004		TRUCKS	C-1534	Oil Filter
577	ISUZU	ELF (NKS) [ 04/06 ]	4800 4WD PB-NKS81E [ 4HL1 ]	2004		TRUCKS	FC-1203	Fuel Filter
578	ISUZU	ELF (NKS) [ 04/06 ]	4800 4WD PB-NKS81N<DC> [ 4HL1 ]	2004		TRUCKS	A-6012	Air Filter
579	ISUZU	ELF (NKS) [ 04/06 ]	4800 4WD PB-NKS81N<DC> [ 4HL1 ]	2004		TRUCKS	FC-1203	Fuel Filter
580	ISUZU	ELF (NKS) [ 04/06 ]	4800 4WD PB-NKS81N<SC> [ 4HL1 ]	2004		TRUCKS	A-6012	Air Filter
581	ISUZU	ELF (NKS) [ 04/06 ]	4800 4WD PB-NKS81N<SC> [ 4HL1 ]	2004		TRUCKS	FC-1203	Fuel Filter
582	ISUZU	ELF (NPR) [ 04/05 ]	4800 PB-NPR81A [ 4HL1 ]	2004		TRUCKS	C-1534	Oil Filter
583	ISUZU	ELF (NPR) [ 04/05 ]	4800 PB-NPR81A [ 4HL1 ]	2004		TRUCKS	FC-1203	Fuel Filter
584	ISUZU	ELF (NPR) [ 04/05 ]	4800 PB-NPR81D [ 4HL1-T (TB) ]	2004		TRUCKS	A-6020M	Air Filter
585	ISUZU	ELF (NPR) [ 04/05 ]	4800 PB-NPR81D [ 4HL1-T (TB) ]	2004		TRUCKS	C-1534	Oil Filter
586	ISUZU	ELF (NPR) [ 04/05 ]	4800 PB-NPR81D [ 4HL1-T (TB) ]	2004		TRUCKS	FC-1203	Fuel Filter
587	ISUZU	ELF (NPR) [ 04/05 ]	4800 PB-NPR81N [ 4HL1-T (TB) ]	2004		TRUCKS	A-6020M	Air Filter
588	ISUZU	ELF (NPR) [ 04/05 ]	4800 PB-NPR81N [ 4HL1-T (TB) ]	2004		TRUCKS	C-1534	Oil Filter
589	ISUZU	ELF (NPR) [ 04/05 ]	4800 PB-NPR81N [ 4HL1-T (TB) ]	2004		TRUCKS	FC-1203	Fuel Filter
590	ISUZU	ELF (NPR) [ 04/05 ]	4800 PB-NPR81R [ 4HL1-T (TB) ]	2004		TRUCKS	A-6020M	Air Filter
591	ISUZU	ELF (NPR) [ 04/05 ]	4800 PB-NPR81R [ 4HL1-T (TB) ]	2004		TRUCKS	C-1534	Oil Filter
592	ISUZU	ELF (NPR) [ 04/05 ]	4800 PB-NPR81R [ 4HL1-T (TB) ]	2004		TRUCKS	FC-1203	Fuel Filter
593	ISUZU	ELF (NPR) [ 04/06 ]	4300 PB-NPR81 [ 4HL1 ]	2004		TRUCKS	A-6017	Air Filter
594	ISUZU	ELF (NPR) [ 04/06 ]	4300 PB-NPR81 [ 4HL1 ]	2004		TRUCKS	C-1534	Oil Filter
595	ISUZU	ELF (NPR) [ 04/06 ]	4600 PB-NPR81 [ 4HL1 ]	2004		TRUCKS	A-6017	Air Filter
596	ISUZU	ELF (NPR) [ 04/06 ]	4600 PB-NPR81 [ 4HL1 ]	2004		TRUCKS	C-1534	Oil Filter
597	ISUZU	ELF (NPS) [ 04/06 ]	4800 4WD PB-NPS81A [ 4HL1 ]	2004		TRUCKS	C-1534	Oil Filter
598	ISUZU	ELF (NPS) [ 04/06 ]	4800 4WD PB-NPS81A [ 4HL1 ]	2004		TRUCKS	FC-1203	Fuel Filter
599	ISUZU	ELF (NPS) [ 04/06 ]	4800 4WD PB-NPS81N [ 4HL1 ]	2004		TRUCKS	A-6012	Air Filter
600	ISUZU	ELF (NPS) [ 04/06 ]	4800 4WD PB-NPS81N [ 4HL1 ]	2004		TRUCKS	FC-1203	Fuel Filter
601	ISUZU	ELF 100 [ 95/06 - ]	2500 (D) 4WD KC-ASN6F23 [ TD25 ]	1995		TRUCKS	C-1803	Oil Filter
602	ISUZU	ELF 100 [ 95/06 - ]	2500 (D) 4WD KC-ASN6F23 [ TD25 ]	1995		TRUCKS	FC-1803	Fuel Filter
603	ISUZU	ELF 100 [ 95/06 - ]	2500 (D) KC-ASN2F23 [ TD25 ]	1995		TRUCKS	C-1803	Oil Filter
604	ISUZU	ELF 100 [ 95/06 - ]	2500 (D) KC-ASN2F23 [ TD25 ]	1995		TRUCKS	FC-1803	Fuel Filter
605	ISUZU	ELF 100 [ 95/06 - 97/08 ]	2700 (D) 4WD KC-ASP8F23 [ TD27 ]	1995	1997	TRUCKS	C-1803	Oil Filter



Sakura Filter					ENGINE APPLICATION			
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
606	ISUZU	ELF 100 [ 95/06 - 97/08 ]	2700 (D) 4WD KC-ASP8F23 [ TD27 ]	1995	1997	TRUCKS	FC-1803	Fuel Filter
607	ISUZU	ELF 100 [ 95/06 - 99/05 ]	2000 GB-ASK2F23 [ NA20S ]	1995	1999	TRUCKS	A-1816	Air Filter
608	ISUZU	ELF 100 [ 97/08 - ]	3200 (D) 4WD KG-ASR8F23 [ QD32 ]	1997		TRUCKS	C-1803	Oil Filter
609	ISUZU	ELF 100 [ 97/08 - ]	3200 (D) 4WD KG-ASR8F23 [ QD32 ]	1997		TRUCKS	FC-1803	Fuel Filter
610	ISUZU	ELF 100 [ 97/08 - ]	3200 (D) 4WD KK-ASR8F23 [ QD32 ]	1997		TRUCKS	C-1803	Oil Filter
611	ISUZU	ELF 100 [ 97/08 - ]	3200 (D) 4WD KK-ASR8F23 [ QD32 ]	1997		TRUCKS	FC-1803	Fuel Filter
612	ISUZU	ELF 100 [ 97/08 - ]	3200 (D) KG-ASR2F23 [ QD32 ]	1997		TRUCKS	C-1803	Oil Filter
613	ISUZU	ELF 100 [ 97/08 - ]	3200 (D) KG-ASR2F23 [ QD32 ]	1997		TRUCKS	FC-1803	Fuel Filter
614	ISUZU	ELF 100 [ 97/08 - ]	3200 (D) KG-ASR4F23 [ QD32 ]	1997		TRUCKS	C-1803	Oil Filter
615	ISUZU	ELF 100 [ 97/08 - ]	3200 (D) KG-ASR4F23 [ QD32 ]	1997		TRUCKS	FC-1803	Fuel Filter
616	ISUZU	ELF 100 [ 97/08 - 99/05 ]	2000 GB-ASK4F23 [ NA20S ]	1997	1999	TRUCKS	A-1816	Air Filter
617	ISUZU	ELF 100 [ 99/06 - ]	2700 (D) 4WD KG-ASP6F23 [ TD27 ]	1999		TRUCKS	C-1803	Oil Filter
618	ISUZU	ELF 100 [ 99/06 - ]	2700 (D) 4WD KG-ASP6F23 [ TD27 ]	1999		TRUCKS	FC-1803	Fuel Filter
619	ISUZU	ELF 100 [ 99/06 - ]	2700 (D) KG-ASP2F23 [ TD27 ]	1999		TRUCKS	C-1803	Oil Filter
620	ISUZU	ELF 100 [ 99/06 - ]	2700 (D) KG-ASP2F23 [ TD27 ]	1999		TRUCKS	FC-1803	Fuel Filter
621	ISUZU	ELF 4jj1 06	Engine: N/A			TRUCKS	EO-1501	Oil Filter
622	ISUZU	ELF NHR NHS WHR WHS [ 84/07 - 88/04 ]	2500 (D) P-NHR54 [ 4JA1 ]	1984	1988	TRUCKS	A-1502	Air Filter
623	ISUZU	ELF NHR NHS WHR WHS [ 84/07 - 88/04 ]	2500 (D) P-NHR54 [ 4JA1 ]	1984	1988	TRUCKS	C-1502	Oil Filter
624	ISUZU	ELF NHR NHS WHR WHS [ 84/07 - 88/04 ]	2500 (D) P-NHR54 [ 4JA1 ]	1984	1988	TRUCKS	FC-1203	Fuel Filter
625	ISUZU	ELF NHR NHS WHR WHS [ 84/07 - 88/04 ]	2800 (D) P-NHR55 [ 4JB1 ]	1984	1988	TRUCKS	A-1502	Air Filter
626	ISUZU	ELF NHR NHS WHR WHS [ 84/07 - 88/04 ]	2800 (D) P-NHR55 [ 4JB1 ]	1984	1988	TRUCKS	C-1502	Oil Filter
627	ISUZU	ELF NHR NHS WHR WHS [ 84/07 - 88/04 ]	2800 (D) P-NHR55 [ 4JB1 ]	1984	1988	TRUCKS	FC-1203	Fuel Filter
628	ISUZU	ELF NHR NHS WHR WHS [ 85/03 - 88/07 ]	2800 (D) VAN P-WHR55 [ 4JB1 ]	1985	1988	TRUCKS	A-1502	Air Filter
629	ISUZU	ELF NHR NHS WHR WHS [ 85/03 - 88/07 ]	2800 (D) VAN P-WHR55 [ 4JB1 ]	1985	1988	TRUCKS	C-1502	Oil Filter
630	ISUZU	ELF NHR NHS WHR WHS [ 85/03 - 88/07 ]	2800 (D) VAN P-WHR55 [ 4JB1 ]	1985	1988	TRUCKS	FC-1203	Fuel Filter
631	ISUZU	ELF NHR NHS WHR WHS [ 88/05 - 93/05 ]	2500 (D) S-NHR54 [ 4JA1 ]	1988	1993	TRUCKS	A-1502	Air Filter
632	ISUZU	ELF NHR NHS WHR WHS [ 88/05 - 93/05 ]	2500 (D) S-NHR54 [ 4JA1 ]	1988	1993	TRUCKS	FC-1203	Fuel Filter
633	ISUZU	ELF NHR NHS WHR WHS [ 88/05 - 93/05 ]	2800 (D) U(S)-NHR55 [ 4JB1 ]	1988	1993	TRUCKS	A-1502	Air Filter
634	ISUZU	ELF NHR NHS WHR WHS [ 88/05 - 93/05 ]	2800 (D) U(S)-NHR55 [ 4JB1 ]	1988	1993	TRUCKS	FC-1203	Fuel Filter
635	ISUZU	ELF NHR NHS WHR WHS [ 88/07 - 93/12 ]	2800 (D) VAN S-WHR55 [ 4JB1 ]	1988	1993	TRUCKS	A-1502	Air Filter
636	ISUZU	ELF NHR NHS WHR WHS [ 88/07 - 93/12 ]	2800 (D) VAN S-WHR55 [ 4JB1 ]	1988	1993	TRUCKS	FC-1203	Fuel Filter
637	ISUZU	ELF NHR NHS WHR WHS [ 91/08 - 93/05 ]	2800 (D) 4WD U-NHS55 [ 4JB1 ]	1991	1993	TRUCKS	A-1502	Air Filter
638	ISUZU	ELF NHR NHS WHR WHS [ 91/08 - 93/05 ]	2800 (D) 4WD U-NHS55 [ 4JB1 ]	1991	1993	TRUCKS	FC-1203	Fuel Filter
639	ISUZU	ELF NHR NHS WHR WHS [ 93/06 - 95/04 ]	3100 (D) 4WD U-NHS69 [ 4JG2 ]	1993	1995	TRUCKS	A-1516	Air Filter
640	ISUZU	ELF NHR NHS WHR WHS [ 93/06 - 95/04 ]	3100 (D) 4WD U-NHS69 [ 4JG2 ]	1993	1995	TRUCKS	C-1516	Oil Filter
641	ISUZU	ELF NHR NHS WHR WHS [ 93/06 - 95/04 ]	3100 (D) 4WD U-NHS69 [ 4JG2 ]	1993	1995	TRUCKS	FC-1203	Fuel Filter
642	ISUZU	ELF NHR NHS WHR WHS [ 93/06 - 95/04 ]	3100 (D) U-NHR69 [ 4JG2 ]	1993	1995	TRUCKS	A-1516	Air Filter
643	ISUZU	ELF NHR NHS WHR WHS [ 93/06 - 95/04 ]	3100 (D) U-NHR69 [ 4JG2 ]	1993	1995	TRUCKS	C-1516	Oil Filter
644	ISUZU	ELF NHR NHS WHR WHS [ 93/06 - 95/04 ]	3100 (D) U-NHR69 [ 4JG2 ]	1993	1995	TRUCKS	FC-1203	Fuel Filter
645	ISUZU	ELF NHR NHS WHR WHS [ 94/01 - 95/04 ]	3100 (D) VAN 4WD U-WHS69 [ 4JG2 ]	1994	1995	TRUCKS	A-1516	Air Filter
646	ISUZU	ELF NHR NHS WHR WHS [ 94/01 - 95/04 ]	3100 (D) VAN 4WD U-WHS69 [ 4JG2 ]	1994	1995	TRUCKS	C-1516	Oil Filter
647	ISUZU	ELF NHR NHS WHR WHS [ 94/01 - 95/04 ]	3100 (D) VAN 4WD U-WHS69 [ 4JG2 ]	1994	1995	TRUCKS	FC-1203	Fuel Filter
648	ISUZU	ELF NHR NHS WHR WHS [ 94/01 - 95/04 ]	3100 (D) VAN U-WHR69 [ 4JG2 ]	1994	1995	TRUCKS	A-1516	Air Filter
649	ISUZU	ELF NHR NHS WHR WHS [ 94/01 - 95/04 ]	3100 (D) VAN U-WHR69 [ 4JG2 ]	1994	1995	TRUCKS	C-1516	Oil Filter
650	ISUZU	ELF NHR NHS WHR WHS [ 94/01 - 95/04 ]	3100 (D) VAN U-WHR69 [ 4JG2 ]	1994	1995	TRUCKS	FC-1203	Fuel Filter



Sakura Filter					ENGINE APPLICATION			
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
651	ISUZU	ELF NHR NHS WHR WHS [ 95/04 - ]	3100 (D) VAN KC-WHR69 [ 4JG2 ]	1995		TRUCKS	A-1516	Air Filter
652	ISUZU	ELF NHR NHS WHR WHS [ 95/04 - ]	3100 (D) VAN KC-WHR69 [ 4JG2 ]	1995		TRUCKS	C-1516	Oil Filter
653	ISUZU	ELF NHR NHS WHR WHS [ 95/04 - ]	3100 (D) VAN KC-WHR69 [ 4JG2 ]	1995		TRUCKS	FC-1203	Fuel Filter
654	ISUZU	ELF NHR NHS WHR WHS [ 95/04 - 97/05 ]	3100 (D) 4WD KC-NHS69 [ 4JG2 ]	1995	1997	TRUCKS	A-1516	Air Filter
655	ISUZU	ELF NHR NHS WHR WHS [ 95/04 - 97/05 ]	3100 (D) 4WD KC-NHS69 [ 4JG2 ]	1995	1997	TRUCKS	C-1516	Oil Filter
656	ISUZU	ELF NHR NHS WHR WHS [ 95/04 - 97/05 ]	3100 (D) 4WD KC-NHS69 [ 4JG2 ]	1995	1997	TRUCKS	FC-1203	Fuel Filter
657	ISUZU	ELF NHR NHS WHR WHS [ 95/04 - 97/05 ]	3100 (D) KC-NHR69 [ 4JG2 ]	1995	1997	TRUCKS	A-1516	Air Filter
658	ISUZU	ELF NHR NHS WHR WHS [ 95/04 - 97/05 ]	3100 (D) KC-NHR69 [ 4JG2 ]	1995	1997	TRUCKS	C-1516	Oil Filter
659	ISUZU	ELF NHR NHS WHR WHS [ 95/04 - 97/05 ]	3100 (D) KC-NHR69 [ 4JG2 ]	1995	1997	TRUCKS	FC-1203	Fuel Filter
660	ISUZU	ELF NHR NHS WHR WHS [ 97/05 - ]	3100 LPG 4WD KK-NHS69 [ 4JG2 ]	1997		TRUCKS	A-1516	Air Filter
661	ISUZU	ELF NHR NHS WHR WHS [ 97/05 - ]	3100 LPG 4WD KK-NHS69 [ 4JG2 ]	1997		TRUCKS	C-1516	Oil Filter
662	ISUZU	ELF NHR NHS WHR WHS [ 97/05 - 99/05 ]	3100 (D) 4WD KK-NHS69 [ 4JG2 ]	1997	1999	TRUCKS	A-1516	Air Filter
663	ISUZU	ELF NHR NHS WHR WHS [ 97/05 - 99/05 ]	3100 (D) 4WD KK-NHS69 [ 4JG2 ]	1997	1999	TRUCKS	C-1516	Oil Filter
664	ISUZU	ELF NHR NHS WHR WHS [ 97/05 - 99/05 ]	3100 (D) 4WD KK-NHS69 [ 4JG2 ]	1997	1999	TRUCKS	FC-1203	Fuel Filter
665	ISUZU	ELF NHR NHS WHR WHS [ 97/05 - 99/05 ]	3100 (D) KG-NHR69 [ 4JG2 ]	1997	1999	TRUCKS	A-1516	Air Filter
666	ISUZU	ELF NHR NHS WHR WHS [ 97/05 - 99/05 ]	3100 (D) KG-NHR69 [ 4JG2 ]	1997	1999	TRUCKS	C-1516	Oil Filter
667	ISUZU	ELF NHR NHS WHR WHS [ 97/05 - 99/05 ]	3100 (D) KG-NHR69 [ 4JG2 ]	1997	1999	TRUCKS	FC-1203	Fuel Filter
668	ISUZU	ELF NHR NHS WHR WHS [ 97/05 - 99/05 ]	3100 (D) KK-NHR69 [ 4JG2 ]	1997	1999	TRUCKS	A-1516	Air Filter
669	ISUZU	ELF NHR NHS WHR WHS [ 97/05 - 99/05 ]	3100 (D) KK-NHR69 [ 4JG2 ]	1997	1999	TRUCKS	C-1516	Oil Filter
670	ISUZU	ELF NHR NHS WHR WHS [ 97/05 - 99/05 ]	3100 (D) KK-NHR69 [ 4JG2 ]	1997	1999	TRUCKS	FC-1203	Fuel Filter
671	ISUZU	ELF NHR NHS WHR WHS [ 98/02 - ]	3100 LPG KK-NHR69 [ 4JG2 ]	1998		TRUCKS	A-1516	Air Filter
672	ISUZU	ELF NHR NHS WHR WHS [ 98/02 - ]	3100 LPG KK-NHR69 [ 4JG2 ]	1998		TRUCKS	C-1516	Oil Filter
673	ISUZU	ELF NHR NHS WHR WHS [ 98/02 - ]	3100 LPG KK-NHR69 [ 4JG2 ]	1998		TRUCKS	FC-1203	Fuel Filter
674	ISUZU	ELF NHR NHS WHR WHS [ 99/05 - ]	3100 (D) 4WD KK-NHS69 [ 4JG2 ]	1999		TRUCKS	A-6017	Air Filter
675	ISUZU	ELF NHR NHS WHR WHS [ 99/05 - ]	3100 (D) 4WD KK-NHS69 [ 4JG2 ]	1999		TRUCKS	C-1516	Oil Filter
676	ISUZU	ELF NHR NHS WHR WHS [ 99/05 - ]	3100 (D) 4WD KK-NHS69 [ 4JG2 ]	1999		TRUCKS	FC-1203	Fuel Filter
677	ISUZU	ELF NHR NHS WHR WHS [ 99/05 - ]	3100 (D) KG-NHR69 [ 4JG2 ]	1999		TRUCKS	A-6017	Air Filter
678	ISUZU	ELF NHR NHS WHR WHS [ 99/05 - ]	3100 (D) KG-NHR69 [ 4JG2 ]	1999		TRUCKS	C-1516	Oil Filter
679	ISUZU	ELF NHR NHS WHR WHS [ 99/05 - ]	3100 (D) KG-NHR69 [ 4JG2 ]	1999		TRUCKS	FC-1203	Fuel Filter
680	ISUZU	ELF NHR NHS WHR WHS [ 99/05 - ]	3100 (D) KK-NHR69 [ 4JG2 ]	1999		TRUCKS	A-6017	Air Filter
681	ISUZU	ELF NHR NHS WHR WHS [ 99/05 - ]	3100 (D) KK-NHR69 [ 4JG2 ]	1999		TRUCKS	C-1516	Oil Filter
682	ISUZU	ELF NHR NHS WHR WHS [ 99/05 - ]	3100 (D) KK-NHR69 [ 4JG2 ]	1999		TRUCKS	FC-1203	Fuel Filter
683	ISUZU	ELF NHR NHS WHR WHS [ 99/05 - ]	3100 (D) VAN KK-WHR69 [ 4JG2 ]	1999		TRUCKS	A-1516	Air Filter
684	ISUZU	ELF NHR NHS WHR WHS [ 99/05 - ]	3100 (D) VAN KK-WHR69 [ 4JG2 ]	1999		TRUCKS	C-1516	Oil Filter
685	ISUZU	ELF NHR NHS WHR WHS [ 99/05 - ]	3100 (D) VAN KK-WHR69 [ 4JG2 ]	1999		TRUCKS	FC-1203	Fuel Filter
686	ISUZU	ELF NKR NKS WKR [ 00/06 - ]	3100 LPG KK-NKR69 [ 4JG2 ]	2000		TRUCKS	A-1516	Air Filter
687	ISUZU	ELF NKR NKS WKR [ 00/06 - ]	3100 LPG KK-NKR69 [ 4JG2 ]	2000		TRUCKS	C-1516	Oil Filter
688	ISUZU	ELF NKR NKS WKR [ 00/06 - ]	4300 NATURAL GAS KK-NKR66 [ 4HF1 ]	2000		TRUCKS	A-6017	Air Filter
689	ISUZU	ELF NKR NKS WKR [ 00/06 - ]	4300 NATURAL GAS KK-NKR66 [ 4HF1 ]	2000		TRUCKS	C-1515	Oil Filter
690	ISUZU	ELF NKR NKS WKR [ 00/06 - ]	4600 LPG KK-NKR71 [ 4HG1 ]	2000		TRUCKS	A-6017	Air Filter
691	ISUZU	ELF NKR NKS WKR [ 00/06 - ]	4600 LPG KK-NKR71 [ 4HG1 ]	2000		TRUCKS	C-1515	Oil Filter
692	ISUZU	ELF NKR NKS WKR [ 02/05 - ]	4800 KR-NKR81 [ 4HL1 ]	2002		TRUCKS	A-6017	Air Filter
693	ISUZU	ELF NKR NKS WKR [ 02/05 - ]	4800 KR-NKR81 [ 4HL1 ]	2002		TRUCKS	C-1515	Oil Filter
694	ISUZU	ELF NKR NKS WKR [ 02/05 - ]	4800 KR-NKR81 [ 4HL1 ]	2002		TRUCKS	FC-1203	Fuel Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
695	ISUZU	ELF NKR NKS WKR [ 02/05 - ]	5000 (D) KR-NKR72 [ 4HJ1 ]	2002		TRUCKS	A-6017	Air Filter
696	ISUZU	ELF NKR NKS WKR [ 02/05 - ]	5000 (D) KR-NKR72 [ 4HJ1 ]	2002		TRUCKS	C-1515	Oil Filter
697	ISUZU	ELF NKR NKS WKR [ 02/05 - ]	5000 (D) KR-NKR72 [ 4HJ1 ]	2002		TRUCKS	FC-1203	Fuel Filter
698	ISUZU	ELF NKR NKS WKR [ 02/06 - ]	4300 CNG KR-NKR81 [ 4HF1 ]	2002		TRUCKS	A-6017	Air Filter
699	ISUZU	ELF NKR NKS WKR [ 02/06 - ]	4300 CNG KR-NKR81 [ 4HF1 ]	2002		TRUCKS	C-1515	Oil Filter
700	ISUZU	ELF NKR NKS WKR [ 02/06 - ]	4600 LPG KR-NKR81 [ 4HG1 ]	2002		TRUCKS	A-6017	Air Filter
701	ISUZU	ELF NKR NKS WKR [ 02/06 - ]	4600 LPG KR-NKR81 [ 4HG1 ]	2002		TRUCKS	C-1515	Oil Filter
702	ISUZU	ELF NKR NKS WKR [ 02/06 - ]	4800 CNG 4WD DOUBLE CAB KR-NKS81G [ 4HL1 ]	2002		TRUCKS	A-6017	Air Filter
703	ISUZU	ELF NKR NKS WKR [ 02/06 - ]	4800 CNG 4WD KR-NKS81E [ 4HL1 ]	2002		TRUCKS	A-6017	Air Filter
704	ISUZU	ELF NKR NKS WKR [ 02/06 - ]	4800 CNG 4WD KR-NKS81E [ 4HL1 ]	2002		TRUCKS	C-1515	Oil Filter
705	ISUZU	ELF NKR NKS WKR [ 02/06 - ]	4800 CNG 4WD KR-NKS81L [ 4HL1 ]	2002		TRUCKS	A-6012	Air Filter
706	ISUZU	ELF NKR NKS WKR [ 02/06 - ]	4800 CNG 4WD SINGLE CAB KR-NKS81G [ 4HL1 ]	2002		TRUCKS	A-6012	Air Filter
707	ISUZU	ELF NKR NKS WKR [ 84/01 - 88/05 ]	2800 (D) P-NKR55 [ 4JB1 ]	1984	1988	TRUCKS	A-1502	Air Filter
708	ISUZU	ELF NKR NKS WKR [ 84/01 - 88/05 ]	2800 (D) P-NKR55 [ 4JB1 ]	1984	1988	TRUCKS	C-1502	Oil Filter
709	ISUZU	ELF NKR NKS WKR [ 84/01 - 88/05 ]	2800 (D) P-NKR55 [ 4JB1 ]	1984	1988	TRUCKS	FC-1203	Fuel Filter
710	ISUZU	ELF NKR NKS WKR [ 84/07 - 90/06 ]	3300 (D) P-NKR57 [ 4BC2 ]	1984	1990	TRUCKS	A-1502	Air Filter
711	ISUZU	ELF NKR NKS WKR [ 84/07 - 90/06 ]	3300 (D) P-NKR57 [ 4BC2 ]	1984	1990	TRUCKS	C-1512	Oil Filter
712	ISUZU	ELF NKR NKS WKR [ 84/07 - 90/06 ]	3300 (D) P-NKR57 [ 4BC2 ]	1984	1990	TRUCKS	FC-1501	Fuel Filter
713	ISUZU	ELF NKR NKS WKR [ 85/03 - 88/07 ]	2800 CNG VAN P-WKR55 [ 4JB1 ]	1985	1988	TRUCKS	A-1502	Air Filter
714	ISUZU	ELF NKR NKS WKR [ 85/03 - 88/07 ]	2800 CNG VAN P-WKR55 [ 4JB1 ]	1985	1988	TRUCKS	C-1502	Oil Filter
715	ISUZU	ELF NKR NKS WKR [ 85/11 - 88/05 ]	2800 (D) P-NKR56 [ 4BA1 ]	1985	1988	TRUCKS	A-1502	Air Filter
716	ISUZU	ELF NKR NKS WKR [ 85/11 - 88/05 ]	2800 (D) P-NKR56 [ 4BA1 ]	1985	1988	TRUCKS	C-1512	Oil Filter
717	ISUZU	ELF NKR NKS WKR [ 85/11 - 88/05 ]	2800 (D) P-NKR56 [ 4BA1 ]	1985	1988	TRUCKS	FC-1501	Fuel Filter
718	ISUZU	ELF NKR NKS WKR [ 85/11 - 90/05 ]	3600 (D) P-NKR58 [ 4BE1 ]	1985	1990	TRUCKS	A-1502	Air Filter
719	ISUZU	ELF NKR NKS WKR [ 85/11 - 90/05 ]	3600 (D) P-NKR58 [ 4BE1 ]	1985	1990	TRUCKS	C-1512	Oil Filter
720	ISUZU	ELF NKR NKS WKR [ 85/11 - 90/05 ]	3600 (D) P-NKR58 [ 4BE1 ]	1985	1990	TRUCKS	FC-1203	Fuel Filter
721	ISUZU	ELF NKR NKS WKR [ 87/09 - 90/04 ]	3600 CNG 4WD P-NKS58 [ 4BE1 ]	1987	1990	TRUCKS	A-1502	Air Filter
722	ISUZU	ELF NKR NKS WKR [ 87/09 - 90/04 ]	3600 CNG 4WD P-NKS58 [ 4BE1 ]	1987	1990	TRUCKS	C-1512	Oil Filter
723	ISUZU	ELF NKR NKS WKR [ 87/09 - 90/04 ]	3600 CNG 4WD P-NKS58 [ 4BE1 ]	1987	1990	TRUCKS	FC-1203	Fuel Filter
724	ISUZU	ELF NKR NKS WKR [ 88/06 - 93/04 ]	2800 (D) U-NKR55 [ 4JB1 ]	1988	1993	TRUCKS	A-1502	Air Filter
725	ISUZU	ELF NKR NKS WKR [ 88/06 - 93/04 ]	2800 (D) U-NKR55 [ 4JB1 ]	1988	1993	TRUCKS	FC-1203	Fuel Filter
726	ISUZU	ELF NKR NKS WKR [ 88/07 - 93/12 ]	2800 CNG VAN U-WKR55 [ 4JB1 ]	1988	1993	TRUCKS	A-1502	Air Filter
727	ISUZU	ELF NKR NKS WKR [ 88/09 - 93/04 ]	3600 (D) U(P)-NKR63 [ 4BE2 ]	1988	1993	TRUCKS	A-1502	Air Filter
728	ISUZU	ELF NKR NKS WKR [ 88/09 - 93/04 ]	3600 (D) U(P)-NKR63 [ 4BE2 ]	1988	1993	TRUCKS	C-1512	Oil Filter
729	ISUZU	ELF NKR NKS WKR [ 88/09 - 93/04 ]	3600 (D) U(P)-NKR63 [ 4BE2 ]	1988	1993	TRUCKS	FC-1203	Fuel Filter
730	ISUZU	ELF NKR NKS WKR [ 89/07 - 90/08 ]	4300 (D) U-NKR61 [ 4BG1 ]	1989	1990	TRUCKS	A-1502	Air Filter
731	ISUZU	ELF NKR NKS WKR [ 89/07 - 90/08 ]	4300 (D) U-NKR61 [ 4BG1 ]	1989	1990	TRUCKS	C-1512	Oil Filter
732	ISUZU	ELF NKR NKS WKR [ 89/07 - 90/08 ]	4300 (D) U-NKR61 [ 4BG1 ]	1989	1990	TRUCKS	FC-1501	Fuel Filter
733	ISUZU	ELF NKR NKS WKR [ 90/05 - 93/04 ]	3600 (D) INDEPENDENCE SUS. U-NKR58 [ 4BE1 ]	1990	1993	TRUCKS	A-1502	Air Filter
734	ISUZU	ELF NKR NKS WKR [ 90/05 - 93/04 ]	3600 (D) INDEPENDENCE SUS. U-NKR58 [ 4BE1 ]	1990	1993	TRUCKS	C-1523	Oil Filter
735	ISUZU	ELF NKR NKS WKR [ 90/05 - 93/04 ]	3600 (D) INDEPENDENCE SUS. U-NKR58 [ 4BE1 ]	1990	1993	TRUCKS	FC-1501	Fuel Filter
736	ISUZU	ELF NKR NKS WKR [ 90/05 - 93/10 ]	3600 CNG 4WD U-NKS58 [ 4BE1 ]	1990	1993	TRUCKS	A-1502	Air Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
737	ISUZU	ELF NKR NKS WKR [ 90/05 - 93/10 ]	3600 CNG 4WD U-NKS58 [ 4BE1 ]	1990	1993	TRUCKS	C-1512	Oil Filter
738	ISUZU	ELF NKR NKS WKR [ 90/05 - 93/10 ]	3600 CNG 4WD U-NKS58 [ 4BE1 ]	1990	1993	TRUCKS	FC-1501	Fuel Filter
739	ISUZU	ELF NKR NKS WKR [ 90/05 - 95/04 ]	4300 (D) U-NKR66 [ 4HF1 ]	1990	1995	TRUCKS	A-1510	Air Filter
740	ISUZU	ELF NKR NKS WKR [ 90/05 - 95/04 ]	4300 (D) U-NKR66 [ 4HF1 ]	1990	1995	TRUCKS	C-1515	Oil Filter
741	ISUZU	ELF NKR NKS WKR [ 90/05 - 95/04 ]	4300 (D) U-NKR66 [ 4HF1 ]	1990	1995	TRUCKS	FC-1505	Fuel Filter
742	ISUZU	ELF NKR NKS WKR [ 90/06 - 93/07 ]	3600 (D) U-NKR58 [ 4BE1 ]	1990	1993	TRUCKS	A-1502	Air Filter
743	ISUZU	ELF NKR NKS WKR [ 90/06 - 93/07 ]	3600 (D) U-NKR58 [ 4BE1 ]	1990	1993	TRUCKS	C-1512	Oil Filter
744	ISUZU	ELF NKR NKS WKR [ 90/06 - 93/07 ]	3600 (D) U-NKR58 [ 4BE1 ]	1990	1993	TRUCKS	FC-1501	Fuel Filter
745	ISUZU	ELF NKR NKS WKR [ 93/04 - 95/02 ]	3600 (D) #7400001- U-NKR63 [ 4BE2 ]	1993	1995	TRUCKS	A-1510	Air Filter
746	ISUZU	ELF NKR NKS WKR [ 93/04 - 95/02 ]	3600 (D) #7400001- U-NKR63 [ 4BE2 ]	1993	1995	TRUCKS	C-1512	Oil Filter
747	ISUZU	ELF NKR NKS WKR [ 93/04 - 95/02 ]	3600 (D) #7400001- U-NKR63 [ 4BE2 ]	1993	1995	TRUCKS	FC-1203	Fuel Filter
748	ISUZU	ELF NKR NKS WKR [ 93/04 - 95/02 ]	3600 (D) INDEPENDENCE SUS. #7400001- U-NKR58 [ 4BE1 ]	1993	1995	TRUCKS	A-1510	Air Filter
749	ISUZU	ELF NKR NKS WKR [ 93/04 - 95/02 ]	3600 (D) INDEPENDENCE SUS. #7400001- U-NKR58 [ 4BE1 ]	1993	1995	TRUCKS	C-1523	Oil Filter
750	ISUZU	ELF NKR NKS WKR [ 93/04 - 95/02 ]	3600 (D) INDEPENDENCE SUS. #7400001- U-NKR58 [ 4BE1 ]	1993	1995	TRUCKS	FC-1501	Fuel Filter
751	ISUZU	ELF NKR NKS WKR [ 93/04 - 95/04 ]	3100 (D) U-NKR69 [ 4JG2 ]	1993	1995	TRUCKS	A-1516	Air Filter
752	ISUZU	ELF NKR NKS WKR [ 93/04 - 95/04 ]	3100 (D) U-NKR69 [ 4JG2 ]	1993	1995	TRUCKS	C-1516	Oil Filter
753	ISUZU	ELF NKR NKS WKR [ 93/04 - 95/04 ]	3100 (D) U-NKR69 [ 4JG2 ]	1993	1995	TRUCKS	FC-1203	Fuel Filter
754	ISUZU	ELF NKR NKS WKR [ 93/04 - 95/04 ]	3100 CNG VAN U-WKR69 [ 4JG2 ]	1993	1995	TRUCKS	A-1516	Air Filter
755	ISUZU	ELF NKR NKS WKR [ 93/04 - 95/04 ]	3100 CNG VAN U-WKR69 [ 4JG2 ]	1993	1995	TRUCKS	C-1516	Oil Filter
756	ISUZU	ELF NKR NKS WKR [ 93/11 - 95/02 ]	4300 CNG 4WD DOUBLE CAB U-NKS66 [ 4HF1 ]	1993	1995	TRUCKS	A-1510	Air Filter
757	ISUZU	ELF NKR NKS WKR [ 93/11 - 95/02 ]	4300 CNG 4WD DOUBLE CAB U-NKS66 [ 4HF1 ]	1993	1995	TRUCKS	C-1523	Oil Filter
758	ISUZU	ELF NKR NKS WKR [ 93/11 - 95/02 ]	4300 CNG 4WD DOUBLE CAB U-NKS66 [ 4HF1 ]	1993	1995	TRUCKS	FC-1505	Fuel Filter
759	ISUZU	ELF NKR NKS WKR [ 93/11 - 95/02 ]	4300 CNG 4WD SINGLE CAB U-NKS66 [ 4HF1 ]	1993	1995	TRUCKS	A-6012	Air Filter
760	ISUZU	ELF NKR NKS WKR [ 93/11 - 95/02 ]	4300 CNG 4WD SINGLE CAB U-NKS66 [ 4HF1 ]	1993	1995	TRUCKS	C-1523	Oil Filter
761	ISUZU	ELF NKR NKS WKR [ 93/11 - 95/02 ]	4300 CNG 4WD SINGLE CAB U-NKS66 [ 4HF1 ]	1993	1995	TRUCKS	FC-1505	Fuel Filter
762	ISUZU	ELF NKR NKS WKR [ 95/04 - ]	3100 CNG VAN KC-WKR69 [ 4JG2 ]	1995		TRUCKS	A-1516	Air Filter
763	ISUZU	ELF NKR NKS WKR [ 95/04 - ]	3100 CNG VAN KC-WKR69 [ 4JG2 ]	1995		TRUCKS	C-1516	Oil Filter
764	ISUZU	ELF NKR NKS WKR [ 95/04 - ]	4600 CNG 4WD KL-NKS71L [ 4HG1 ]	1995		TRUCKS	C-1523	Oil Filter
765	ISUZU	ELF NKR NKS WKR [ 95/04 - ]	4600 CNG 4WD KL-NKS71L [ 4HG1 ]	1995		TRUCKS	FC-1505	Fuel Filter
766	ISUZU	ELF NKR NKS WKR [ 95/04 - 97/03 ]	3100 (D) KC-NKR69 [ 4JG2 ]	1995	1997	TRUCKS	A-1516	Air Filter
767	ISUZU	ELF NKR NKS WKR [ 95/04 - 97/03 ]	3100 (D) KC-NKR69 [ 4JG2 ]	1995	1997	TRUCKS	C-1516	Oil Filter
768	ISUZU	ELF NKR NKS WKR [ 95/04 - 97/03 ]	3100 (D) KC-NKR69 [ 4JG2 ]	1995	1997	TRUCKS	FC-1203	Fuel Filter
769	ISUZU	ELF NKR NKS WKR [ 95/04 - 99/04 ]	4300 (D) KC-NKR66 [ 4HF1 ]	1995	1999	TRUCKS	A-1510	Air Filter
770	ISUZU	ELF NKR NKS WKR [ 95/04 - 99/04 ]	4300 (D) KC-NKR66 [ 4HF1 ]	1995	1999	TRUCKS	C-1515	Oil Filter
771	ISUZU	ELF NKR NKS WKR [ 95/04 - 99/04 ]	4300 (D) KC-NKR66 [ 4HF1 ]	1995	1999	TRUCKS	FC-1505	Fuel Filter
772	ISUZU	ELF NKR NKS WKR [ 95/04 - 99/04 ]	4600 (D) KC-NKR71 [ 4HG1 ]	1995	1999	TRUCKS	A-1510	Air Filter
773	ISUZU	ELF NKR NKS WKR [ 95/04 - 99/04 ]	4600 (D) KC-NKR71 [ 4HG1 ]	1995	1999	TRUCKS	C-1515	Oil Filter
774	ISUZU	ELF NKR NKS WKR [ 95/04 - 99/04 ]	4600 (D) KC-NKR71 [ 4HG1 ]	1995	1999	TRUCKS	FC-1505	Fuel Filter
775	ISUZU	ELF NKR NKS WKR [ 95/04 - 99/04 ]	4600 CNG 4WD DOUBLE CAB KC-NKS71G [ 4HG1 ]	1995	1999	TRUCKS	A-1510	Air Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
776	ISUZU	ELF NKR NKS WKR [ 95/04 - 99/04 ]	4600 CNG 4WD DOUBLE CAB KC-NKS71G [ 4HG1 ]	1995	1999	TRUCKS	C-1523	Oil Filter
777	ISUZU	ELF NKR NKS WKR [ 95/04 - 99/04 ]	4600 CNG 4WD DOUBLE CAB KC-NKS71G [ 4HG1 ]	1995	1999	TRUCKS	FC-1505	Fuel Filter
778	ISUZU	ELF NKR NKS WKR [ 95/04 - 99/04 ]	4600 CNG 4WD SINGLE CAB KC-NKS71G [ 4HG1 ]	1995	1999	TRUCKS	A-6012	Air Filter
779	ISUZU	ELF NKR NKS WKR [ 95/04 - 99/04 ]	4600 CNG 4WD SINGLE CAB KC-NKS71G [ 4HG1 ]	1995	1999	TRUCKS	C-1523	Oil Filter
780	ISUZU	ELF NKR NKS WKR [ 95/04 - 99/04 ]	4600 CNG 4WD SINGLE CAB KC-NKS71G [ 4HG1 ]	1995	1999	TRUCKS	FC-1505	Fuel Filter
781	ISUZU	ELF NKR NKS WKR [ 95/08 - 99/04 ]	4300 CNG 4WD DOUBLE CAB KC-NKS66 [ 4HF1 ]	1995	1999	TRUCKS	A-1510	Air Filter
782	ISUZU	ELF NKR NKS WKR [ 95/08 - 99/04 ]	4300 CNG 4WD DOUBLE CAB KC-NKS66 [ 4HF1 ]	1995	1999	TRUCKS	C-1523	Oil Filter
783	ISUZU	ELF NKR NKS WKR [ 95/08 - 99/04 ]	4300 CNG 4WD DOUBLE CAB KC-NKS66 [ 4HF1 ]	1995	1999	TRUCKS	FC-1505	Fuel Filter
784	ISUZU	ELF NKR NKS WKR [ 95/08 - 99/04 ]	4300 CNG 4WD SINGLE CAB KC-NKS66 [ 4HF1 ]	1995	1999	TRUCKS	A-6012	Air Filter
785	ISUZU	ELF NKR NKS WKR [ 95/08 - 99/04 ]	4300 CNG 4WD SINGLE CAB KC-NKS66 [ 4HF1 ]	1995	1999	TRUCKS	C-1523	Oil Filter
786	ISUZU	ELF NKR NKS WKR [ 95/08 - 99/04 ]	4300 CNG 4WD SINGLE CAB KC-NKS66 [ 4HF1 ]	1995	1999	TRUCKS	FC-1505	Fuel Filter
787	ISUZU	ELF NKR NKS WKR [ 97/05 - 99/04 ]	3100 (D) KK-NKR69 [ 4JG2 ]	1997	1999	TRUCKS	A-1516	Air Filter
788	ISUZU	ELF NKR NKS WKR [ 97/05 - 99/04 ]	3100 (D) KK-NKR69 [ 4JG2 ]	1997	1999	TRUCKS	C-1516	Oil Filter
789	ISUZU	ELF NKR NKS WKR [ 97/05 - 99/04 ]	3100 (D) KK-NKR69 [ 4JG2 ]	1997	1999	TRUCKS	FC-1203	Fuel Filter
790	ISUZU	ELF NKR NKS WKR [ 97/05 - 99/04 ]	4300 (D) LOW POWER TYPE KC-NKR66 [ 4HF1-N ]	1997	1999	TRUCKS	A-1510	Air Filter
791	ISUZU	ELF NKR NKS WKR [ 97/05 - 99/04 ]	4300 (D) LOW POWER TYPE KC-NKR66 [ 4HF1-N ]	1997	1999	TRUCKS	C-1515	Oil Filter
792	ISUZU	ELF NKR NKS WKR [ 97/05 - 99/04 ]	4300 (D) LOW POWER TYPE KC-NKR66 [ 4HF1-N ]	1997	1999	TRUCKS	FC-1203	Fuel Filter
793	ISUZU	ELF NKR NKS WKR [ 98/07 - 99/04 ]	4300 NATURAL GAS KC-NKR66 [ 4HF1 ]	1998	1999	TRUCKS	A-1510	Air Filter
794	ISUZU	ELF NKR NKS WKR [ 98/07 - 99/04 ]	4300 NATURAL GAS KC-NKR66 [ 4HF1 ]	1998	1999	TRUCKS	C-1515	Oil Filter
795	ISUZU	ELF NKR NKS WKR [ 99/04 - ]	4300 (D) KK-NKR66 [ 4HF1 ]	1999		TRUCKS	A-6017	Air Filter
796	ISUZU	ELF NKR NKS WKR [ 99/04 - ]	4300 (D) KK-NKR66 [ 4HF1 ]	1999		TRUCKS	C-1515	Oil Filter
797	ISUZU	ELF NKR NKS WKR [ 99/04 - ]	4300 (D) KK-NKR66 [ 4HF1 ]	1999		TRUCKS	FC-1203	Fuel Filter
798	ISUZU	ELF NKR NKS WKR [ 99/04 - ]	4600 (D) KK-NKR71 [ 4HG1 ]	1999		TRUCKS	A-6017	Air Filter
799	ISUZU	ELF NKR NKS WKR [ 99/04 - ]	4600 (D) KK-NKR71 [ 4HG1 ]	1999		TRUCKS	C-1515	Oil Filter
800	ISUZU	ELF NKR NKS WKR [ 99/04 - ]	4600 (D) KK-NKR71 [ 4HG1 ]	1999		TRUCKS	FC-1203	Fuel Filter
801	ISUZU	ELF NKR NKS WKR [ 99/04 - 00/05 ]	4300 NATURAL GAS KC-NKR66 [ 4HF1 ]	1999	2000	TRUCKS	C-1515	Oil Filter
802	ISUZU	ELF NKR NKS WKR [ 99/05 - ]	3100 (D) KK-NKR69 [ 4JG2 ]	1999		TRUCKS	A-6017	Air Filter
803	ISUZU	ELF NKR NKS WKR [ 99/05 - ]	3100 (D) KK-NKR69 [ 4JG2 ]	1999		TRUCKS	C-1516	Oil Filter
804	ISUZU	ELF NKR NKS WKR [ 99/05 - ]	3100 (D) KK-NKR69 [ 4JG2 ]	1999		TRUCKS	FC-1203	Fuel Filter
805	ISUZU	ELF NKR NKS WKR [ 99/05 - ]	4600 CNG 4WD DOUBLE CAB KC-NKS71G [ 4HG1 ]	1999		TRUCKS	A-6017	Air Filter
806	ISUZU	ELF NKR NKS WKR [ 99/05 - ]	4600 CNG 4WD DOUBLE CAB KC-NKS71G [ 4HG1 ]	1999		TRUCKS	C-1523	Oil Filter
807	ISUZU	ELF NKR NKS WKR [ 99/05 - ]	4600 CNG 4WD DOUBLE CAB KC-NKS71G [ 4HG1 ]	1999		TRUCKS	FC-1203	Fuel Filter
808	ISUZU	ELF NKR NKS WKR [ 99/05 - ]	4600 CNG 4WD KC-NKS71E [ 4HG1 ]	1999		TRUCKS	A-6017	Air Filter
809	ISUZU	ELF NKR NKS WKR [ 99/05 - ]	4600 CNG 4WD KC-NKS71E [ 4HG1 ]	1999		TRUCKS	C-1515	Oil Filter
810	ISUZU	ELF NKR NKS WKR [ 99/05 - ]	4600 CNG 4WD KC-NKS71E [ 4HG1 ]	1999		TRUCKS	FC-1203	Fuel Filter
811	ISUZU	ELF NKR NKS WKR [ 99/05 - ]	4600 CNG 4WD KC-NKS71L [ 4HG1 ]	1999		TRUCKS	C-1523	Oil Filter
812	ISUZU	ELF NKR NKS WKR [ 99/05 - ]	4600 CNG 4WD SINGLE CAB KC-NKS71G [ 4HG1 ]	1999		TRUCKS	A-6012	Air Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
813	ISUZU	ELF NKR NKS WKR [ 99/05 - ]	4600 CNG 4WD SINGLE CAB KK-NKS71G [ 4HG1 ]	1999		TRUCKS	C-1523	Oil Filter
814	ISUZU	ELF NKR NKS WKR [ 99/05 - ]	4600 CNG 4WD SINGLE CAB KK-NKS71G [ 4HG1 ]	1999		TRUCKS	FC-1203	Fuel Filter
815	ISUZU	ELF NKR NKS WKR [ 99/07 - ]	4600 (D) TURBO KK-NKR75 [ 4HK1T ]	1999		TRUCKS	A-6020M	Air Filter
816	ISUZU	ELF NKR NKS WKR [ 99/07 - ]	4600 (D) TURBO KK-NKR75 [ 4HK1T ]	1999		TRUCKS	C-1515	Oil Filter
817	ISUZU	ELF NKR NKS WKR [ 99/07 - ]	4600 (D) TURBO KK-NKR75 [ 4HK1T ]	1999		TRUCKS	FC-1203	Fuel Filter
818	ISUZU	ELF NKR NKS WKR [ 99/08 - ]	3100 CNG VAN KK-WKR69 [ 4JG2 ]	1999		TRUCKS	A-1516	Air Filter
819	ISUZU	ELF NKR NKS WKR [ 99/08 - ]	3100 CNG VAN KK-WKR69 [ 4JG2 ]	1999		TRUCKS	C-1516	Oil Filter
820	ISUZU	ELF NKR NKS WKR [ 99/12 - ]	5000 (D) KK-NKR72 [ 4HJ1 ]	1999		TRUCKS	A-6017	Air Filter
821	ISUZU	ELF NKR NKS WKR [ 99/12 - ]	5000 (D) KK-NKR72 [ 4HJ1 ]	1999		TRUCKS	C-1515	Oil Filter
822	ISUZU	ELF NKR NKS WKR [ 99/12 - ]	5000 (D) KK-NKR72 [ 4HJ1 ]	1999		TRUCKS	FC-1203	Fuel Filter
823	ISUZU	ELF NPR NPS [ 00/06 - ]	4600 NATURAL GAS KK-NPR71 [ 4HG1 ]	2000		TRUCKS	A-6017	Air Filter
824	ISUZU	ELF NPR NPS [ 00/06 - ]	4600 NATURAL GAS KK-NPR71 [ 4HG1 ]	2000		TRUCKS	C-1515	Oil Filter
825	ISUZU	ELF NPR NPS [ 01/03 - ]	5000 NATURAL GAS KK-NPR72 [ 4HJ1 ]	2001		TRUCKS	A-6017	Air Filter
826	ISUZU	ELF NPR NPS [ 01/03 - ]	5000 NATURAL GAS KK-NPR72 [ 4HJ1 ]	2001		TRUCKS	C-1515	Oil Filter
827	ISUZU	ELF NPR NPS [ 02/05 - ]	4800 (D) KR-NPR81 [ 4HL1 ]	2002		TRUCKS	A-6017	Air Filter
828	ISUZU	ELF NPR NPS [ 02/05 - ]	4800 (D) KR-NPR81 [ 4HL1 ]	2002		TRUCKS	C-1515	Oil Filter
829	ISUZU	ELF NPR NPS [ 02/05 - ]	4800 (D) KR-NPR81 [ 4HL1 ]	2002		TRUCKS	FC-1203	Fuel Filter
830	ISUZU	ELF NPR NPS [ 02/05 - ]	5000 (D) KR-NPR72 [ 4HJ1 ]	2002		TRUCKS	A-6017	Air Filter
831	ISUZU	ELF NPR NPS [ 02/05 - ]	5000 (D) KR-NPR72 [ 4HJ1 ]	2002		TRUCKS	C-1515	Oil Filter
832	ISUZU	ELF NPR NPS [ 02/05 - ]	5000 (D) KR-NPR72 [ 4HJ1 ]	2002		TRUCKS	FC-1203	Fuel Filter
833	ISUZU	ELF NPR NPS [ 02/06 - ]	5000 (D) 4WD KR-NPS72 [ 4HJ1 ]	2002		TRUCKS	A-6012	Air Filter
834	ISUZU	ELF NPR NPS [ 02/06 - ]	5000 (D) 4WD KR-NPS72 [ 4HJ1 ]	2002		TRUCKS	C-1515	Oil Filter
835	ISUZU	ELF NPR NPS [ 02/06 - ]	5000 (D) 4WD KR-NPS72 [ 4HJ1 ]	2002		TRUCKS	FC-1203	Fuel Filter
836	ISUZU	ELF NPR NPS [ 84/06 - 88/05 ]	3300 (D) P-NPR57 [ 4BC2 ]	1984	1988	TRUCKS	C-1512	Oil Filter
837	ISUZU	ELF NPR NPS [ 84/06 - 88/05 ]	3300 (D) P-NPR57 [ 4BC2 ]	1984	1988	TRUCKS	FC-1501	Fuel Filter
838	ISUZU	ELF NPR NPS [ 84/07 - 93/05 ]	3900 (D) TURBO U(P)-NPR59 [ 4BD1(T) ]	1984	1993	TRUCKS	A-6012	Air Filter
839	ISUZU	ELF NPR NPS [ 84/07 - 93/05 ]	3900 (D) TURBO U(P)-NPR59 [ 4BD1(T) ]	1984	1993	TRUCKS	C-1512	Oil Filter
840	ISUZU	ELF NPR NPS [ 84/07 - 93/05 ]	3900 (D) TURBO U(P)-NPR59 [ 4BD1(T) ]	1984	1993	TRUCKS	FC-1501	Fuel Filter
841	ISUZU	ELF NPR NPS [ 84/07 - 93/06 ]	3900 (D) U(P)-NPR59 [ 4BD1 ]	1984	1993	TRUCKS	C-1512	Oil Filter
842	ISUZU	ELF NPR NPS [ 84/07 - 93/06 ]	3900 (D) U(P)-NPR59 [ 4BD1 ]	1984	1993	TRUCKS	FC-1501	Fuel Filter
843	ISUZU	ELF NPR NPS [ 87/02 - 90/04 ]	3600 (D) P-NPR58 [ 4BE1 ]	1987	1990	TRUCKS	C-1512	Oil Filter
844	ISUZU	ELF NPR NPS [ 87/02 - 90/04 ]	3600 (D) P-NPR58 [ 4BE1 ]	1987	1990	TRUCKS	FC-1203	Fuel Filter
845	ISUZU	ELF NPR NPS [ 88/02 - 93/12 ]	3900 (D) 4WD U(P)-NPS59 [ 4BD1 ]	1988	1993	TRUCKS	A-6012	Air Filter
846	ISUZU	ELF NPR NPS [ 88/02 - 93/12 ]	3900 (D) 4WD U(P)-NPS59 [ 4BD1 ]	1988	1993	TRUCKS	C-1512	Oil Filter
847	ISUZU	ELF NPR NPS [ 88/02 - 93/12 ]	3900 (D) 4WD U(P)-NPS59 [ 4BD1 ]	1988	1993	TRUCKS	FC-1501	Fuel Filter
848	ISUZU	ELF NPR NPS [ 88/06 - 90/04 ]	3600 (D) 4WD P-NPS58 [ 4BE1 ]	1988	1990	TRUCKS	A-6012	Air Filter
849	ISUZU	ELF NPR NPS [ 88/06 - 90/04 ]	3600 (D) 4WD P-NPS58 [ 4BE1 ]	1988	1990	TRUCKS	C-1512	Oil Filter
850	ISUZU	ELF NPR NPS [ 88/06 - 90/04 ]	3600 (D) 4WD P-NPS58 [ 4BE1 ]	1988	1990	TRUCKS	FC-1203	Fuel Filter
851	ISUZU	ELF NPR NPS [ 88/06 - 90/04 ]	4300 (D) AIR INTAKE U-NPR61 [ 4BG1 ]	1988	1990	TRUCKS	C-1512	Oil Filter
852	ISUZU	ELF NPR NPS [ 88/06 - 90/04 ]	4300 (D) AIR INTAKE U-NPR61 [ 4BG1 ]	1988	1990	TRUCKS	FC-1501	Fuel Filter
853	ISUZU	ELF NPR NPS [ 88/06 - 90/04 ]	4300 (D) U-NPR61 [ 4BG1 ]	1988	1990	TRUCKS	A-6012	Air Filter
854	ISUZU	ELF NPR NPS [ 88/06 - 90/04 ]	4300 (D) U-NPR61 [ 4BG1 ]	1988	1990	TRUCKS	C-1512	Oil Filter
855	ISUZU	ELF NPR NPS [ 88/06 - 90/04 ]	4300 (D) U-NPR61 [ 4BG1 ]	1988	1990	TRUCKS	FC-1501	Fuel Filter
856	ISUZU	ELF NPR NPS [ 88/06 - 93/06 ]	3300 (D) U(P)-NPR57 [ 4BC2 ]	1988	1993	TRUCKS	C-1512	Oil Filter



Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
857	ISUZU	ELF NPR NPS [ 88/06 - 93/06 ]	3300 (D) U(P)-NPR57 [ 4BC2 ]	1988	1993	TRUCKS	FC-1203	Fuel Filter
858	ISUZU	ELF NPR NPS [ 88/07 - 93/12 ]	3900 (D) 4WD TURBO U(P)-NPR59 [ 4BD1(T) ]	1988	1993	TRUCKS	A-6012	Air Filter
859	ISUZU	ELF NPR NPS [ 88/07 - 93/12 ]	3900 (D) 4WD TURBO U(P)-NPR59 [ 4BD1(T) ]	1988	1993	TRUCKS	C-1512	Oil Filter
860	ISUZU	ELF NPR NPS [ 88/07 - 93/12 ]	3900 (D) 4WD TURBO U(P)-NPR59 [ 4BD1(T) ]	1988	1993	TRUCKS	FC-1501	Fuel Filter
861	ISUZU	ELF NPR NPS [ 90/05 - 93/07 ]	3600 (D) U-NPR58 [ 4BE1 ]	1990	1993	TRUCKS	C-1512	Oil Filter
862	ISUZU	ELF NPR NPS [ 90/05 - 93/07 ]	3600 (D) U-NPR58 [ 4BE1 ]	1990	1993	TRUCKS	FC-1501	Fuel Filter
863	ISUZU	ELF NPR NPS [ 90/05 - 93/12 ]	3600 (D) 4WD U-NPS58 [ 4BE1 ]	1990	1993	TRUCKS	A-6012	Air Filter
864	ISUZU	ELF NPR NPS [ 90/05 - 93/12 ]	3600 (D) 4WD U-NPS58 [ 4BE1 ]	1990	1993	TRUCKS	C-1512	Oil Filter
865	ISUZU	ELF NPR NPS [ 90/05 - 93/12 ]	3600 (D) 4WD U-NPS58 [ 4BE1 ]	1990	1993	TRUCKS	FC-1501	Fuel Filter
866	ISUZU	ELF NPR NPS [ 90/05 - 95/04 ]	4300 (D) U-NPR66 [ 4HF1 ]	1990	1995	TRUCKS	A-1510	Air Filter
867	ISUZU	ELF NPR NPS [ 90/05 - 95/04 ]	4300 (D) U-NPR66 [ 4HF1 ]	1990	1995	TRUCKS	C-1515	Oil Filter
868	ISUZU	ELF NPR NPS [ 90/05 - 95/04 ]	4300 (D) U-NPR66 [ 4HF1 ]	1990	1995	TRUCKS	FC-1505	Fuel Filter
869	ISUZU	ELF NPR NPS [ 93/05 - 95/04 ]	4800 (D) TURBO U-NPR70 [ 4HE1(T) ]	1993	1995	TRUCKS	A-6020M	Air Filter
870	ISUZU	ELF NPR NPS [ 93/05 - 95/04 ]	4800 (D) TURBO U-NPR70 [ 4HE1(T) ]	1993	1995	TRUCKS	C-1515	Oil Filter
871	ISUZU	ELF NPR NPS [ 93/05 - 95/04 ]	4800 (D) TURBO U-NPR70 [ 4HE1(T) ]	1993	1995	TRUCKS	FC-1505	Fuel Filter
872	ISUZU	ELF NPR NPS [ 93/12 - 95/02 ]	4300 (D) 4WD U-NPS66 [ 4HF1 ]	1993	1995	TRUCKS	A-6012	Air Filter
873	ISUZU	ELF NPR NPS [ 93/12 - 95/02 ]	4300 (D) 4WD U-NPS66 [ 4HF1 ]	1993	1995	TRUCKS	C-1523	Oil Filter
874	ISUZU	ELF NPR NPS [ 93/12 - 95/02 ]	4300 (D) 4WD U-NPS66 [ 4HF1 ]	1993	1995	TRUCKS	FC-1505	Fuel Filter
875	ISUZU	ELF NPR NPS [ 95/03 - 99/04 ]	4600 (D) KC-NPR71 [ 4HG1 ]	1995	1999	TRUCKS	A-1510	Air Filter
876	ISUZU	ELF NPR NPS [ 95/03 - 99/04 ]	4600 (D) KC-NPR71 [ 4HG1 ]	1995	1999	TRUCKS	C-1515	Oil Filter
877	ISUZU	ELF NPR NPS [ 95/03 - 99/04 ]	4600 (D) KC-NPR71 [ 4HG1 ]	1995	1999	TRUCKS	FC-1505	Fuel Filter
878	ISUZU	ELF NPR NPS [ 95/04 - 97/03 ]	4600 (D) 4WD KC-NPS71 [ 4HG1 ]	1995	1997	TRUCKS	A-6012	Air Filter
879	ISUZU	ELF NPR NPS [ 95/04 - 97/03 ]	4600 (D) 4WD KC-NPS71 [ 4HG1 ]	1995	1997	TRUCKS	C-1523	Oil Filter
880	ISUZU	ELF NPR NPS [ 95/04 - 97/03 ]	4600 (D) 4WD KC-NPS71 [ 4HG1 ]	1995	1997	TRUCKS	FC-1505	Fuel Filter
881	ISUZU	ELF NPR NPS [ 95/04 - 99/04 ]	4300 (D) KC-NPR66 [ 4HF1 ]	1995	1999	TRUCKS	A-1510	Air Filter
882	ISUZU	ELF NPR NPS [ 95/04 - 99/04 ]	4300 (D) KC-NPR66 [ 4HF1 ]	1995	1999	TRUCKS	C-1515	Oil Filter
883	ISUZU	ELF NPR NPS [ 95/04 - 99/04 ]	4300 (D) KC-NPR66 [ 4HF1 ]	1995	1999	TRUCKS	FC-1505	Fuel Filter
884	ISUZU	ELF NPR NPS [ 95/04 - 99/04 ]	4800 (D) TURBO KC-NPR70 [ 4HE1(T) ]	1995	1999	TRUCKS	A-6020M	Air Filter
885	ISUZU	ELF NPR NPS [ 95/04 - 99/04 ]	4800 (D) TURBO KC-NPR70 [ 4HE1(T) ]	1995	1999	TRUCKS	C-1515	Oil Filter
886	ISUZU	ELF NPR NPS [ 95/04 - 99/04 ]	4800 (D) TURBO KC-NPR70 [ 4HE1(T) ]	1995	1999	TRUCKS	FC-1505	Fuel Filter
887	ISUZU	ELF NPR NPS [ 97/04 - 99/08 ]	5000 (D) 4WD KC-NPS72 [ 4HJ1 ]	1997	1999	TRUCKS	A-6012	Air Filter
888	ISUZU	ELF NPR NPS [ 97/04 - 99/08 ]	5000 (D) 4WD KC-NPS72 [ 4HJ1 ]	1997	1999	TRUCKS	C-1515	Oil Filter
889	ISUZU	ELF NPR NPS [ 97/04 - 99/08 ]	5000 (D) 4WD KC-NPS72 [ 4HJ1 ]	1997	1999	TRUCKS	FC-1505	Fuel Filter
890	ISUZU	ELF NPR NPS [ 97/04 - 99/08 ]	5000 (D) KC-NPR72 [ 4HJ1 ]	1997	1999	TRUCKS	A-1510	Air Filter
891	ISUZU	ELF NPR NPS [ 97/04 - 99/08 ]	5000 (D) KC-NPR72 [ 4HJ1 ]	1997	1999	TRUCKS	C-1515	Oil Filter
892	ISUZU	ELF NPR NPS [ 97/04 - 99/08 ]	5000 (D) KC-NPR72 [ 4HJ1 ]	1997	1999	TRUCKS	FC-1505	Fuel Filter
893	ISUZU	ELF NPR NPS [ 98/07 - 00/05 ]	4600 NATURAL GAS KK-NPR71 [ 4HG1 ]	1998	2000	TRUCKS	C-1515	Oil Filter
894	ISUZU	ELF NPR NPS [ 99/04 - ]	4300 (D) KK-NPR66 [ 4HF1 ]	1999		TRUCKS	A-6017	Air Filter
895	ISUZU	ELF NPR NPS [ 99/04 - ]	4300 (D) KK-NPR66 [ 4HF1 ]	1999		TRUCKS	C-1515	Oil Filter
896	ISUZU	ELF NPR NPS [ 99/04 - ]	4300 (D) KK-NPR66 [ 4HF1 ]	1999		TRUCKS	FC-1203	Fuel Filter
897	ISUZU	ELF NPR NPS [ 99/04 - ]	4600 (D) KK-NPR71 [ 4HG1 ]	1999		TRUCKS	A-6017	Air Filter
898	ISUZU	ELF NPR NPS [ 99/04 - ]	4600 (D) KK-NPR71 [ 4HG1 ]	1999		TRUCKS	C-1515	Oil Filter
899	ISUZU	ELF NPR NPS [ 99/04 - ]	4600 (D) KK-NPR71 [ 4HG1 ]	1999		TRUCKS	FC-1203	Fuel Filter
900	ISUZU	ELF NPR NPS [ 99/05 - ]	5200 (D) TURBO KK-NPR75 [ 4HK1(T) ]	1999		TRUCKS	A-6020M	Air Filter



Sakura Filter					ENGINE APPLICATION			
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
901	ISUZU	ELF NPR NPS [ 99/05 - ]	5200 (D) TURBO KK-NPR75 [ 4HK1(T) ]	1999		TRUCKS	C-1515	Oil Filter
902	ISUZU	ELF NPR NPS [ 99/05 - ]	5200 (D) TURBO KK-NPR75 [ 4HK1(T) ]	1999		TRUCKS	FC-1203	Fuel Filter
903	ISUZU	ELF NPR NPS [ 99/08 - ]	5000 (D) 4WD KK-NPS72 [ 4HJ1 ]	1999		TRUCKS	A-6012	Air Filter
904	ISUZU	ELF NPR NPS [ 99/08 - ]	5000 (D) 4WD KK-NPS72 [ 4HJ1 ]	1999		TRUCKS	C-1515	Oil Filter
905	ISUZU	ELF NPR NPS [ 99/08 - ]	5000 (D) 4WD KK-NPS72 [ 4HJ1 ]	1999		TRUCKS	FC-1203	Fuel Filter
906	ISUZU	ELF NPR NPS [ 99/08 - ]	5000 (D) KK-NPR72 [ 4HJ1 ]	1999		TRUCKS	A-6017	Air Filter
907	ISUZU	ELF NPR NPS [ 99/08 - ]	5000 (D) KK-NPR72 [ 4HJ1 ]	1999		TRUCKS	C-1515	Oil Filter
908	ISUZU	ELF NPR NPS [ 99/08 - ]	5000 (D) KK-NPR72 [ 4HJ1 ]	1999		TRUCKS	FC-1203	Fuel Filter
909	ISUZU	ELF UT [ 96/11 - 99/06 ]	3100 (D) PANEL VAN KC-VHR69K [ 4JG2 ]	1996	1999	TRUCKS	A-1516	Air Filter
910	ISUZU	ELF UT [ 96/11 - 99/06 ]	3100 (D) PANEL VAN KC-VHR69K [ 4JG2 ]	1996	1999	TRUCKS	C-1516	Oil Filter
911	ISUZU	ELF UT [ 96/11 - 99/06 ]	3100 (D) PANEL VAN KC-VHR69K [ 4JG2 ]	1996	1999	TRUCKS	FC-1203	Fuel Filter
912	ISUZU	ELF UT [ 96/11 - 99/06 ]	4300 (D) PANEL VAN KC-VKR66K [ 4HF1 ]	1996	1999	TRUCKS	A-1510	Air Filter
913	ISUZU	ELF UT [ 96/11 - 99/06 ]	4300 (D) PANEL VAN KC-VKR66K [ 4HF1 ]	1996	1999	TRUCKS	C-1515	Oil Filter
914	ISUZU	ELF UT [ 96/11 - 99/06 ]	4300 (D) PANEL VAN KC-VKR66K [ 4HF1 ]	1996	1999	TRUCKS	FC-1505	Fuel Filter
915	ISUZU	ELF UT [ 99/07 - ]	3100 (D) PANEL VAN KK-VHR69K [ 4JG2 ]	1999		TRUCKS	A-1516	Air Filter
916	ISUZU	ELF UT [ 99/07 - ]	3100 (D) PANEL VAN KK-VHR69K [ 4JG2 ]	1999		TRUCKS	C-1516	Oil Filter
917	ISUZU	ELF UT [ 99/07 - ]	3100 (D) PANEL VAN KK-VHR69K [ 4JG2 ]	1999		TRUCKS	FC-1203	Fuel Filter
918	ISUZU	ELF UT [ 99/07 - ]	4300 (D) PANEL VAN KK-VKR66K [ 4HF1 ]	1999		TRUCKS	A-1510	Air Filter
919	ISUZU	ELF UT [ 99/07 - ]	4300 (D) PANEL VAN KK-VKR66K [ 4HF1 ]	1999		TRUCKS	C-1515	Oil Filter
920	ISUZU	ELF UT [ 99/07 - ]	4300 (D) PANEL VAN KK-VKR66K [ 4HF1 ]	1999		TRUCKS	FC-1203	Fuel Filter
921	ISUZU	ELF(NHR)	4JG2			TRUCKS	A-1516	Air Filter
922	ISUZU	ELF(NHR)	4JG2			TRUCKS	A-1516	Air Filter
923	ISUZU	ELF(NHR)	4JG2			TRUCKS	A-1516	Air Filter
924	ISUZU	ELF(NHR)	4JG2			TRUCKS	A-1516	Air Filter
925	ISUZU	ELF(NHR)	4JG2			TRUCKS	A-1516	Air Filter
926	ISUZU	ELF(NHR)	4JG2			TRUCKS	A-6017	Air Filter
927	ISUZU	ELF(NHR)	4JG2			TRUCKS	A-6017	Air Filter
928	ISUZU	ELF(NHR)	4JG2			TRUCKS	A-6017	Air Filter
929	ISUZU	ELF(NHR)	4JG2			TRUCKS	A-6017	Air Filter
930	ISUZU	ELF(NHR)	4JG2			TRUCKS	A-6017	Air Filter
931	ISUZU	ELF(NHR)	4JG2			TRUCKS	FC-1203	Fuel Filter
932	ISUZU	ELF(NHR)	4JG2			TRUCKS	FC-1203	Fuel Filter
933	ISUZU	ELF(NHR)	4JG2			TRUCKS	FC-1203	Fuel Filter
934	ISUZU	ELF(NHR)	4JG2			TRUCKS	FC-1203	Fuel Filter
935	ISUZU	ELF(NHR)	4JJ1-T			TRUCKS	A-1521	Air Filter
936	ISUZU	ELF(NHR)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
937	ISUZU	ELF(NHR)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
938	ISUZU	ELF(NHR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
939	ISUZU	ELF(NHR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
940	ISUZU	ELF(NHS)	4JB1			TRUCKS	A-1502	Air Filter
941	ISUZU	ELF(NHS)	4JB1			TRUCKS	C-1511	Oil Filter
942	ISUZU	ELF(NHS)	4JG2			TRUCKS	A-1516	Air Filter
943	ISUZU	ELF(NHS)	4JG2			TRUCKS	A-1516	Air Filter
944	ISUZU	ELF(NHS)	4JG2			TRUCKS	A-1516	Air Filter
945	ISUZU	ELF(NHS)	4JG2			TRUCKS	A-1516	Air Filter
946	ISUZU	ELF(NHS)	4JG2			TRUCKS	A-6017	Air Filter
947	ISUZU	ELF(NHS)	4JG2			TRUCKS	A-6017	Air Filter
948	ISUZU	ELF(NHS)	4JG2			TRUCKS	A-6017	Air Filter
949	ISUZU	ELF(NHS)	4JG2			TRUCKS	A-6017	Air Filter
950	ISUZU	ELF(NHS)	4JG2			TRUCKS	FC-1203	Fuel Filter
951	ISUZU	ELF(NHS)	4JG2			TRUCKS	FC-1203	Fuel Filter
952	ISUZU	ELF(NHS)	4JG2			TRUCKS	FC-1203	Fuel Filter
953	ISUZU	ELF(NHS)	4JG2			TRUCKS	FC-1203	Fuel Filter
954	ISUZU	ELF(NHS)	4JG2			TRUCKS	FC-1203	Fuel Filter
955	ISUZU	ELF(NHS)	4JJ1-T			TRUCKS	A-1521	Air Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
956	ISUZU	ELF(NHS)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
957	ISUZU	ELF(NHS)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
958	ISUZU	ELF(NHS)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
959	ISUZU	ELF(NHS)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
960	ISUZU	ELF(NJR)	4HV1			TRUCKS	A-1521	Air Filter
961	ISUZU	ELF(NJR)	4HV1			TRUCKS	A-1521	Air Filter
962	ISUZU	ELF(NJR)	4HV1			TRUCKS	C-1542	Oil Filter
963	ISUZU	ELF(NJR)	4HV1			TRUCKS	C-1542	Oil Filter
964	ISUZU	ELF(NJR)	4JJ1			TRUCKS	A-1521	Air Filter
965	ISUZU	ELF(NJR)	4JJ1			TRUCKS	EF-1509	Fuel Filter
966	ISUZU	ELF(NJR)	4JJ1			TRUCKS	EO-1501	Oil Filter
967	ISUZU	ELF(NJR)	4JJ1-T			TRUCKS	A-1521	Air Filter
968	ISUZU	ELF(NJR)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
969	ISUZU	ELF(NJR)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
970	ISUZU	ELF(NJR)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
971	ISUZU	ELF(NJR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
972	ISUZU	ELF(NJR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
973	ISUZU	ELF(NJR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
974	ISUZU	ELF(NJS)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
975	ISUZU	ELF(NJS)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
976	ISUZU	ELF(NJS)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
977	ISUZU	ELF(NJS)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
978	ISUZU	ELF(NKR)	4BE1			TRUCKS	A-1502	Air Filter
979	ISUZU	ELF(NKR)	4BE1			TRUCKS	A-1502	Air Filter
980	ISUZU	ELF(NKR)	4BE1			TRUCKS	A-1502	Air Filter
981	ISUZU	ELF(NKR)	4BE1			TRUCKS	A-1510	Air Filter
982	ISUZU	ELF(NKR)	4BE1			TRUCKS	A-1510	Air Filter
983	ISUZU	ELF(NKR)	4BE1			TRUCKS	C-1504	Oil Filter
984	ISUZU	ELF(NKR)	4BE1			TRUCKS	C-1504	Oil Filter
985	ISUZU	ELF(NKR)	4BE1			TRUCKS	C-1508	Oil Filter
986	ISUZU	ELF(NKR)	4BE1			TRUCKS	C-1508	Oil Filter
987	ISUZU	ELF(NKR)	4BE1			TRUCKS	C-1523	Oil Filter
988	ISUZU	ELF(NKR)	4BE1			TRUCKS	C-1523	Oil Filter
989	ISUZU	ELF(NKR)	4BE1			TRUCKS	C-1523	Oil Filter
990	ISUZU	ELF(NKR)	4HF1			TRUCKS	A-1510	Air Filter
991	ISUZU	ELF(NKR)	4HF1			TRUCKS	A-1510	Air Filter
992	ISUZU	ELF(NKR)	4HF1			TRUCKS	A-1510	Air Filter
993	ISUZU	ELF(NKR)	4HF1			TRUCKS	A-6017	Air Filter
994	ISUZU	ELF(NKR)	4HF1			TRUCKS	A-6017	Air Filter
995	ISUZU	ELF(NKR)	4HF1			TRUCKS	A-6017	Air Filter
996	ISUZU	ELF(NKR)	4HF1			TRUCKS	A-6017	Air Filter
997	ISUZU	ELF(NKR)	4HF1			TRUCKS	C-1542	Oil Filter
998	ISUZU	ELF(NKR)	4HF1			TRUCKS	C-1542	Oil Filter
999	ISUZU	ELF(NKR)	4HF1			TRUCKS	C-1542	Oil Filter
1000	ISUZU	ELF(NKR)	4HF1			TRUCKS	C-1542	Oil Filter
1001	ISUZU	ELF(NKR)	4HF1			TRUCKS	C-1542	Oil Filter
1002	ISUZU	ELF(NKR)	4HF1			TRUCKS	C-1542	Oil Filter
1003	ISUZU	ELF(NKR)	4HF1			TRUCKS	C-1542	Oil Filter
1004	ISUZU	ELF(NKR)	4HF1			TRUCKS	C-1542	Oil Filter
1005	ISUZU	ELF(NKR)	4HF1			TRUCKS	FC-1203	Fuel Filter
1006	ISUZU	ELF(NKR)	4HF1			TRUCKS	FC-1203	Fuel Filter
1007	ISUZU	ELF(NKR)	4HG1			TRUCKS	A-1510	Air Filter
1008	ISUZU	ELF(NKR)	4HG1			TRUCKS	A-6017	Air Filter
1009	ISUZU	ELF(NKR)	4HG1			TRUCKS	A-6017	Air Filter
1010	ISUZU	ELF(NKR)	4HG1			TRUCKS	A-6017	Air Filter
1011	ISUZU	ELF(NKR)	4HG1			TRUCKS	A-6017	Air Filter
1012	ISUZU	ELF(NKR)	4HG1			TRUCKS	C-1542	Oil Filter
1013	ISUZU	ELF(NKR)	4HG1			TRUCKS	C-1542	Oil Filter
1014	ISUZU	ELF(NKR)	4HG1			TRUCKS	C-1542	Oil Filter
1015	ISUZU	ELF(NKR)	4HG1			TRUCKS	C-1542	Oil Filter
1016	ISUZU	ELF(NKR)	4HG1			TRUCKS	C-1542	Oil Filter
1017	ISUZU	ELF(NKR)	4HG1			TRUCKS	FC-1203	Fuel Filter
1018	ISUZU	ELF(NKR)	4HJ1			TRUCKS	A-6017	Air Filter
1019	ISUZU	ELF(NKR)	4HJ1			TRUCKS	C-1542	Oil Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1020	ISUZU	ELF(NKR)	4HJ1			TRUCKS	FC-1203	Fuel Filter
1021	ISUZU	ELF(NKR)	4HL1			TRUCKS	A-6017	Air Filter
1022	ISUZU	ELF(NKR)	4HL1			TRUCKS	C-1542	Oil Filter
1023	ISUZU	ELF(NKR)	4HL1			TRUCKS	C-1542	Oil Filter
1024	ISUZU	ELF(NKR)	4HL1			TRUCKS	C-1542	Oil Filter
1025	ISUZU	ELF(NKR)	4HL1			TRUCKS	FC-1203	Fuel Filter
1026	ISUZU	ELF(NKR)	4HL1			TRUCKS	FC-1203	Fuel Filter
1027	ISUZU	ELF(NKR)	4HL1			TRUCKS	FC-1203	Fuel Filter
1028	ISUZU	ELF(NKR)	4HV1			TRUCKS	A-1521	Air Filter
1029	ISUZU	ELF(NKR)	4HV1			TRUCKS	A-1521	Air Filter
1030	ISUZU	ELF(NKR)	4HV1			TRUCKS	A-6017	Air Filter
1031	ISUZU	ELF(NKR)	4HV1			TRUCKS	C-1542	Oil Filter
1032	ISUZU	ELF(NKR)	4HV1			TRUCKS	C-1542	Oil Filter
1033	ISUZU	ELF(NKR)	4HV1			TRUCKS	C-1542	Oil Filter
1034	ISUZU	ELF(NKR)	4JG2			TRUCKS	A-1516	Air Filter
1035	ISUZU	ELF(NKR)	4JG2			TRUCKS	A-1516	Air Filter
1036	ISUZU	ELF(NKR)	4JG2			TRUCKS	A-1516	Air Filter
1037	ISUZU	ELF(NKR)	4JG2			TRUCKS	A-1516	Air Filter
1038	ISUZU	ELF(NKR)	4JG2			TRUCKS	A-6017	Air Filter
1039	ISUZU	ELF(NKR)	4JG2			TRUCKS	FC-1203	Fuel Filter
1040	ISUZU	ELF(NKR)	4JG2			TRUCKS	FC-1203	Fuel Filter
1041	ISUZU	ELF(NKR)	4JG2			TRUCKS	FC-1203	Fuel Filter
1042	ISUZU	ELF(NKR)	4JG2			TRUCKS	FC-1203	Fuel Filter
1043	ISUZU	ELF(NKR)	4JJ1-T			TRUCKS	A-1521	Air Filter
1044	ISUZU	ELF(NKR)	4JJ1-T			TRUCKS	A-1521	Air Filter
1045	ISUZU	ELF(NKR)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
1046	ISUZU	ELF(NKR)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
1047	ISUZU	ELF(NKR)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
1048	ISUZU	ELF(NKR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1049	ISUZU	ELF(NKR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1050	ISUZU	ELF(NKR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1051	ISUZU	ELF(NKS)	4HF1			TRUCKS	A-1510	Air Filter
1052	ISUZU	ELF(NKS)	4HF1			TRUCKS	A-6012	Air Filter
1053	ISUZU	ELF(NKS)	4HF1			TRUCKS	A-6012	Air Filter
1054	ISUZU	ELF(NKS)	4HF1			TRUCKS	C-1523	Oil Filter
1055	ISUZU	ELF(NKS)	4HF1			TRUCKS	C-1523	Oil Filter
1056	ISUZU	ELF(NKS)	4HF1			TRUCKS	C-1523	Oil Filter
1057	ISUZU	ELF(NKS)	4HG1			TRUCKS	A-1510	Air Filter
1058	ISUZU	ELF(NKS)	4HG1			TRUCKS	A-6012	Air Filter
1059	ISUZU	ELF(NKS)	4HG1			TRUCKS	A-6012	Air Filter
1060	ISUZU	ELF(NKS)	4HG1			TRUCKS	A-6012	Air Filter
1061	ISUZU	ELF(NKS)	4HG1			TRUCKS	A-6012	Air Filter
1062	ISUZU	ELF(NKS)	4HG1			TRUCKS	A-6017	Air Filter
1063	ISUZU	ELF(NKS)	4HG1			TRUCKS	A-6017	Air Filter
1064	ISUZU	ELF(NKS)	4HG1			TRUCKS	C-1523	Oil Filter
1065	ISUZU	ELF(NKS)	4HG1			TRUCKS	C-1523	Oil Filter
1066	ISUZU	ELF(NKS)	4HG1			TRUCKS	C-1523	Oil Filter
1067	ISUZU	ELF(NKS)	4HG1			TRUCKS	C-1523	Oil Filter
1068	ISUZU	ELF(NKS)	4HG1			TRUCKS	C-1523	Oil Filter
1069	ISUZU	ELF(NKS)	4HG1			TRUCKS	C-1523	Oil Filter
1070	ISUZU	ELF(NKS)	4HG1			TRUCKS	C-1542	Oil Filter
1071	ISUZU	ELF(NKS)	4HG1			TRUCKS	FC-1203	Fuel Filter
1072	ISUZU	ELF(NKS)	4HG1			TRUCKS	FC-1203	Fuel Filter
1073	ISUZU	ELF(NKS)	4HG1			TRUCKS	FC-1203	Fuel Filter
1074	ISUZU	ELF(NKS)	4HG1			TRUCKS	FC-1203	Fuel Filter
1075	ISUZU	ELF(NKS)	4HL1			TRUCKS	A-6012	Air Filter
1076	ISUZU	ELF(NKS)	4HL1			TRUCKS	A-6012	Air Filter
1077	ISUZU	ELF(NKS)	4HL1			TRUCKS	A-6012	Air Filter
1078	ISUZU	ELF(NKS)	4HL1			TRUCKS	A-6017	Air Filter
1079	ISUZU	ELF(NKS)	4HL1			TRUCKS	A-6017	Air Filter
1080	ISUZU	ELF(NKS)	4HL1			TRUCKS	C-1717	Oil Filter
1081	ISUZU	ELF(NKS)	4HL1			TRUCKS	C-1717	Oil Filter
1082	ISUZU	ELF(NKS)	4HL1			TRUCKS	C-1717	Oil Filter
1083	ISUZU	ELF(NKS)	4HL1			TRUCKS	C-1717	Oil Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1084	ISUZU	ELF(NKS)	4HL1			TRUCKS	C-1717	Oil Filter
1085	ISUZU	ELF(NKS)	4HL1			TRUCKS	FC-1203	Fuel Filter
1086	ISUZU	ELF(NKS)	4HL1			TRUCKS	FC-1203	Fuel Filter
1087	ISUZU	ELF(NKS)	4HL1			TRUCKS	FC-1203	Fuel Filter
1088	ISUZU	ELF(NKS)	4HL1			TRUCKS	FC-1203	Fuel Filter
1089	ISUZU	ELF(NKS)	4HL1			TRUCKS	FC-1203	Fuel Filter
1090	ISUZU	ELF(NKS)	4HL1			TRUCKS	FC-1203	Fuel Filter
1091	ISUZU	ELF(NKS)	4HL1			TRUCKS	FC-1203	Fuel Filter
1092	ISUZU	ELF(NKS)	4JJ1-T			TRUCKS	A-1521	Air Filter
1093	ISUZU	ELF(NKS)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
1094	ISUZU	ELF(NKS)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
1095	ISUZU	ELF(NKS)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1096	ISUZU	ELF(NKS)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1097	ISUZU	ELF(NLR)	4HV1			TRUCKS	A-1521	Air Filter
1098	ISUZU	ELF(NLR)	4HV1			TRUCKS	A-1521	Air Filter
1099	ISUZU	ELF(NLR)	4HV1			TRUCKS	C-1542	Oil Filter
1100	ISUZU	ELF(NLR)	4HV1			TRUCKS	C-1542	Oil Filter
1101	ISUZU	ELF(NLR)	4JJ1-T			TRUCKS	A-1521	Air Filter
1102	ISUZU	ELF(NLR)	4JJ1-T			TRUCKS	A-1521	Air Filter
1103	ISUZU	ELF(NLR)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
1104	ISUZU	ELF(NLR)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
1105	ISUZU	ELF(NLR)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
1106	ISUZU	ELF(NLR)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
1107	ISUZU	ELF(NLR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1108	ISUZU	ELF(NLR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1109	ISUZU	ELF(NLR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1110	ISUZU	ELF(NLR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1111	ISUZU	ELF(NLS)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
1112	ISUZU	ELF(NMR)	4HV1			TRUCKS	A-1521	Air Filter
1113	ISUZU	ELF(NMR)	4HV1			TRUCKS	A-1521	Air Filter
1114	ISUZU	ELF(NMR)	4HV1			TRUCKS	C-1542	Oil Filter
1115	ISUZU	ELF(NMR)	4HV1			TRUCKS	C-1542	Oil Filter
1116	ISUZU	ELF(NMR)	4JJ1			TRUCKS	A-1521	Air Filter
1117	ISUZU	ELF(NMR)	4JJ1			TRUCKS	EF-1509	Fuel Filter
1118	ISUZU	ELF(NMR)	4JJ1			TRUCKS	EO-1501	Oil Filter
1119	ISUZU	ELF(NMR)	4JJ1-T			TRUCKS	A-1521	Air Filter
1120	ISUZU	ELF(NMR)	4JJ1-T			TRUCKS	A-1521	Air Filter
1121	ISUZU	ELF(NMR)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
1122	ISUZU	ELF(NMR)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
1123	ISUZU	ELF(NMR)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
1124	ISUZU	ELF(NMR)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
1125	ISUZU	ELF(NMR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1126	ISUZU	ELF(NMR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1127	ISUZU	ELF(NMR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1128	ISUZU	ELF(NMR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1129	ISUZU	ELF(NMS)	4JJ1-T			TRUCKS	A-1521	Air Filter
1130	ISUZU	ELF(NMS)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
1131	ISUZU	ELF(NMS)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
1132	ISUZU	ELF(NMS)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1133	ISUZU	ELF(NMS)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1134	ISUZU	ELF(NNR)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
1135	ISUZU	ELF(NNR)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
1136	ISUZU	ELF(NNR)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
1137	ISUZU	ELF(NNR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1138	ISUZU	ELF(NNR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1139	ISUZU	ELF(NNR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1140	ISUZU	ELF(NNS)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
1141	ISUZU	ELF(NNS)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
1142	ISUZU	ELF(NNS)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1143	ISUZU	ELF(NNS)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1144	ISUZU	ELF(NPR)	4BD1-T			TRUCKS	A-6012	Air Filter
1145	ISUZU	ELF(NPR)	4BD1-T			TRUCKS	C-1504	Oil Filter
1146	ISUZU	ELF(NPR)	4BD1-T			TRUCKS	C-1508	Oil Filter
1147	ISUZU	ELF(NPR)	4BE1			TRUCKS	A-1505	Air Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1148	ISUZU	ELF(NPR)	4BE1			TRUCKS	C-1504	Oil Filter
1149	ISUZU	ELF(NPR)	4BE1			TRUCKS	C-1508	Oil Filter
1150	ISUZU	ELF(NPR)	4HE1-T			TRUCKS	C-1542	Oil Filter
1151	ISUZU	ELF(NPR)	4HE1-T			TRUCKS	C-1542	Oil Filter
1152	ISUZU	ELF(NPR)	4HF1			TRUCKS	A-1510	Air Filter
1153	ISUZU	ELF(NPR)	4HF1			TRUCKS	A-1510	Air Filter
1154	ISUZU	ELF(NPR)	4HF1			TRUCKS	A-6017	Air Filter
1155	ISUZU	ELF(NPR)	4HF1			TRUCKS	A-6017	Air Filter
1156	ISUZU	ELF(NPR)	4HF1			TRUCKS	A-6017	Air Filter
1157	ISUZU	ELF(NPR)	4HF1			TRUCKS	C-1542	Oil Filter
1158	ISUZU	ELF(NPR)	4HF1			TRUCKS	C-1542	Oil Filter
1159	ISUZU	ELF(NPR)	4HF1			TRUCKS	C-1542	Oil Filter
1160	ISUZU	ELF(NPR)	4HF1			TRUCKS	C-1542	Oil Filter
1161	ISUZU	ELF(NPR)	4HF1			TRUCKS	C-1542	Oil Filter
1162	ISUZU	ELF(NPR)	4HF1			TRUCKS	FC-1203	Fuel Filter
1163	ISUZU	ELF(NPR)	4HG1			TRUCKS	A-1510	Air Filter
1164	ISUZU	ELF(NPR)	4HG1			TRUCKS	A-6017	Air Filter
1165	ISUZU	ELF(NPR)	4HG1			TRUCKS	A-6017	Air Filter
1166	ISUZU	ELF(NPR)	4HG1			TRUCKS	A-6017	Air Filter
1167	ISUZU	ELF(NPR)	4HG1			TRUCKS	A-6017	Air Filter
1168	ISUZU	ELF(NPR)	4HG1			TRUCKS	C-1542	Oil Filter
1169	ISUZU	ELF(NPR)	4HG1			TRUCKS	C-1542	Oil Filter
1170	ISUZU	ELF(NPR)	4HG1			TRUCKS	C-1542	Oil Filter
1171	ISUZU	ELF(NPR)	4HG1			TRUCKS	C-1542	Oil Filter
1172	ISUZU	ELF(NPR)	4HG1			TRUCKS	C-1542	Oil Filter
1173	ISUZU	ELF(NPR)	4HG1			TRUCKS	C-1542	Oil Filter
1174	ISUZU	ELF(NPR)	4HG1			TRUCKS	FC-1203	Fuel Filter
1175	ISUZU	ELF(NPR)	4HJ1			TRUCKS	A-1510	Air Filter
1176	ISUZU	ELF(NPR)	4HJ1			TRUCKS	A-6017	Air Filter
1177	ISUZU	ELF(NPR)	4HJ1			TRUCKS	A-6017	Air Filter
1178	ISUZU	ELF(NPR)	4HJ1			TRUCKS	A-6017	Air Filter
1179	ISUZU	ELF(NPR)	4HJ1			TRUCKS	C-1542	Oil Filter
1180	ISUZU	ELF(NPR)	4HJ1			TRUCKS	C-1542	Oil Filter
1181	ISUZU	ELF(NPR)	4HJ1			TRUCKS	C-1542	Oil Filter
1182	ISUZU	ELF(NPR)	4HJ1			TRUCKS	C-1542	Oil Filter
1183	ISUZU	ELF(NPR)	4HJ1			TRUCKS	FC-1203	Fuel Filter
1184	ISUZU	ELF(NPR)	4HJ1			TRUCKS	FC-1203	Fuel Filter
1185	ISUZU	ELF(NPR)	4HK1-T			TRUCKS	C-1542	Oil Filter
1186	ISUZU	ELF(NPR)	4HK1-T			TRUCKS	C-1542	Oil Filter
1187	ISUZU	ELF(NPR)	4HK1-T			TRUCKS	C-1542	Oil Filter
1188	ISUZU	ELF(NPR)	4HK1-T			TRUCKS	EF-1509	Fuel Filter
1189	ISUZU	ELF(NPR)	4HK1-T			TRUCKS	EF-1509	Fuel Filter
1190	ISUZU	ELF(NPR)	4HK1-T			TRUCKS	FC-1203	Fuel Filter
1191	ISUZU	ELF(NPR)	4HL1			TRUCKS	A-6017	Air Filter
1192	ISUZU	ELF(NPR)	4HL1			TRUCKS	C-1542	Oil Filter
1193	ISUZU	ELF(NPR)	4HL1			TRUCKS	C-1542	Oil Filter
1194	ISUZU	ELF(NPR)	4HL1			TRUCKS	C-1542	Oil Filter
1195	ISUZU	ELF(NPR)	4HL1			TRUCKS	FC-1203	Fuel Filter
1196	ISUZU	ELF(NPR)	4HL1			TRUCKS	FC-1203	Fuel Filter
1197	ISUZU	ELF(NPR)	4HL1			TRUCKS	FC-1203	Fuel Filter
1198	ISUZU	ELF(NPR)	4HL1-T			TRUCKS	C-1542	Oil Filter
1199	ISUZU	ELF(NPR)	4HL1-T			TRUCKS	FC-1203	Fuel Filter
1200	ISUZU	ELF(NPR)	4HV1			TRUCKS	A-6017	Air Filter
1201	ISUZU	ELF(NPR)	4HV1			TRUCKS	C-1542	Oil Filter
1202	ISUZU	ELF(NPR)	4HV1			TRUCKS	C-1542	Oil Filter
1203	ISUZU	ELF(NPR)	4HV1			TRUCKS	C-1542	Oil Filter
1204	ISUZU	ELF(NPR)	4JJ1			TRUCKS	EF-1509	Fuel Filter
1205	ISUZU	ELF(NPR)	4JJ1			TRUCKS	EO-1501	Oil Filter
1206	ISUZU	ELF(NPR)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
1207	ISUZU	ELF(NPR)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
1208	ISUZU	ELF(NPR)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
1209	ISUZU	ELF(NPR)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
1210	ISUZU	ELF(NPR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1211	ISUZU	ELF(NPR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter



Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1212	ISUZU	ELF(NPR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1213	ISUZU	ELF(NPR)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1214	ISUZU	ELF(NPS)	4BD1-T			TRUCKS	A-6012	Air Filter
1215	ISUZU	ELF(NPS)	4BD1-T			TRUCKS	C-1504	Oil Filter
1216	ISUZU	ELF(NPS)	4BD1-T			TRUCKS	C-1508	Oil Filter
1217	ISUZU	ELF(NPS)	4BE1			TRUCKS	A-1505	Air Filter
1218	ISUZU	ELF(NPS)	4BE1			TRUCKS	C-1504	Oil Filter
1219	ISUZU	ELF(NPS)	4BE1			TRUCKS	C-1508	Oil Filter
1220	ISUZU	ELF(NPS)	4HF1			TRUCKS	A-6012	Air Filter
1221	ISUZU	ELF(NPS)	4HF1			TRUCKS	C-1523	Oil Filter
1222	ISUZU	ELF(NPS)	4HG1			TRUCKS	A-6012	Air Filter
1223	ISUZU	ELF(NPS)	4HG1			TRUCKS	C-1523	Oil Filter
1224	ISUZU	ELF(NPS)	4HJ1			TRUCKS	A-6012	Air Filter
1225	ISUZU	ELF(NPS)	4HJ1			TRUCKS	A-6012	Air Filter
1226	ISUZU	ELF(NPS)	4HJ1			TRUCKS	A-6012	Air Filter
1227	ISUZU	ELF(NPS)	4HJ1			TRUCKS	A-6012	Air Filter
1228	ISUZU	ELF(NPS)	4HJ1			TRUCKS	A-6017	Air Filter
1229	ISUZU	ELF(NPS)	4HJ1			TRUCKS	A-6017	Air Filter
1230	ISUZU	ELF(NPS)	4HJ1			TRUCKS	C-1542	Oil Filter
1231	ISUZU	ELF(NPS)	4HJ1			TRUCKS	C-1542	Oil Filter
1232	ISUZU	ELF(NPS)	4HJ1			TRUCKS	C-1542	Oil Filter
1233	ISUZU	ELF(NPS)	4HJ1			TRUCKS	C-1542	Oil Filter
1234	ISUZU	ELF(NPS)	4HJ1			TRUCKS	C-1542	Oil Filter
1235	ISUZU	ELF(NPS)	4HJ1			TRUCKS	C-1542	Oil Filter
1236	ISUZU	ELF(NPS)	4HJ1			TRUCKS	FC-1203	Fuel Filter
1237	ISUZU	ELF(NPS)	4HJ1			TRUCKS	FC-1203	Fuel Filter
1238	ISUZU	ELF(NPS)	4HJ1			TRUCKS	FC-1203	Fuel Filter
1239	ISUZU	ELF(NPS)	4HJ1			TRUCKS	FC-1203	Fuel Filter
1240	ISUZU	ELF(NPS)	4HJ1			TRUCKS	FC-1203	Fuel Filter
1241	ISUZU	ELF(NPS)	4HL1			TRUCKS	A-6012	Air Filter
1242	ISUZU	ELF(NPS)	4HL1			TRUCKS	C-1542	Oil Filter
1243	ISUZU	ELF(NPS)	4HL1			TRUCKS	C-1717	Oil Filter
1244	ISUZU	ELF(NPS)	4HL1			TRUCKS	FC-1203	Fuel Filter
1245	ISUZU	ELF(NPS)	4HL1			TRUCKS	FC-1203	Fuel Filter
1246	ISUZU	ELF(NPS)	4JJ1-T			TRUCKS	EF-15010	Fuel Filter
1247	ISUZU	ELF(NPS)	4JJ1-T			TRUCKS	EF-1509	Fuel Filter
1248	ISUZU	ELF(NPS)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1249	ISUZU	ELF(NPS)	4JJ1-T			TRUCKS	EO-1501	Oil Filter
1250	ISUZU	ELF(NQR)	4HJ1			TRUCKS	A-6017	Air Filter
1251	ISUZU	ELF(NQR)	4HJ1			TRUCKS	C-1542	Oil Filter
1252	ISUZU	ELF(NQR)	4HJ1			TRUCKS	FC-1203	Fuel Filter
1253	ISUZU	ELF(NQR)	4HK1-T			TRUCKS	C-1542	Oil Filter
1254	ISUZU	ELF(NQR)	4HK1-T			TRUCKS	FC-1203	Fuel Filter
1255	ISUZU	ELF(UT)	4HF1			TRUCKS	A-1510	Air Filter
1256	ISUZU	ELF(UT)	4HF1			TRUCKS	A-1510	Air Filter
1257	ISUZU	ELF(UT)	4HF1			TRUCKS	C-1542	Oil Filter
1258	ISUZU	ELF(UT)	4HF1			TRUCKS	C-1542	Oil Filter
1259	ISUZU	ELF(UT)	4HF1			TRUCKS	FC-1203	Fuel Filter
1260	ISUZU	ELF(UT)	4JG2			TRUCKS	A-1516	Air Filter
1261	ISUZU	ELF(UT)	4JG2			TRUCKS	A-1516	Air Filter
1262	ISUZU	ELF(UT)	4JG2			TRUCKS	FC-1203	Fuel Filter
1263	ISUZU	ELF(UT)	4JG2			TRUCKS	FC-1203	Fuel Filter
1264	ISUZU	ELF(WHR)	4JG2			TRUCKS	A-1516	Air Filter
1265	ISUZU	ELF(WHR)	4JG2			TRUCKS	A-1516	Air Filter
1266	ISUZU	ELF(WHR)	4JG2			TRUCKS	A-1516	Air Filter
1267	ISUZU	ELF(WHR)	4JG2			TRUCKS	FC-1203	Fuel Filter
1268	ISUZU	ELF(WHR)	4JG2			TRUCKS	FC-1203	Fuel Filter
1269	ISUZU	ELF(WHR)	4JG2			TRUCKS	FC-1203	Fuel Filter
1270	ISUZU	ELF(WKR)	4JB1			TRUCKS	A-1502	Air Filter
1271	ISUZU	ELF(WKR)	4JB1			TRUCKS	C-1511	Oil Filter
1272	ISUZU	ELF(WKR)	4JG2			TRUCKS	A-1516	Air Filter
1273	ISUZU	ELF(WKR)	4JG2			TRUCKS	A-1516	Air Filter
1274	ISUZU	ELF(WKR)	4JG2			TRUCKS	A-1516	Air Filter
1275	ISUZU	ELF(WKR)	4JG2			TRUCKS	FC-1203	Fuel Filter



Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1276	ISUZU	ELF(WKR)	4JG2			TRUCKS	FC-1203	Fuel Filter
1277	ISUZU	ELF(WKR)	4JG2			TRUCKS	FC-1203	Fuel Filter
1278	ISUZU	ELF100	NA20S			TRUCKS	FS-1806	Fuel Filter
1279	ISUZU	ELF100	NA20S			TRUCKS	FS-1806	Fuel Filter
1280	ISUZU	ELF100	ZD30DDTi			TRUCKS	EF-1801	Fuel Filter
1281	ISUZU	ELF100	ZD30DDTi			TRUCKS	EF-1801	Fuel Filter
1282	ISUZU	ELF100	ZD30DDTi			TRUCKS	EF-1801	Fuel Filter
1283	ISUZU	ELF100	ZD30DDTi			TRUCKS	EF-1801	Fuel Filter
1284	ISUZU	ELF100	ZD30DDTi			TRUCKS	EF-1801	Fuel Filter
1285	ISUZU	ELF100	ZD30DDTi			TRUCKS	EF-1801	Fuel Filter
1286	ISUZU	ELF100	ZD30DDTi			TRUCKS	EF-1801	Fuel Filter
1287	ISUZU	ELF100	ZD30DDTi			TRUCKS	EF-1801	Fuel Filter
1288	ISUZU	ELF100	ZD30DDTi			TRUCKS	EF-1801	Fuel Filter
1289	ISUZU	ELF100	ZD30DDTi			TRUCKS	EF-1801	Fuel Filter
1290	ISUZU	ELF100 [ 05/01 ]	3200 4WD KR-ASR8F23 [ QD32 ]	2005		TRUCKS	C-1803	Oil Filter
1291	ISUZU	ELF100 [ 05/01 ]	3200 4WD KR-ASR8F23 [ QD32 ]	2005		TRUCKS	FC-1803	Fuel Filter
1292	ISUZU	ELF150	4JA1			TRUCKS	A-1502	Air Filter
1293	ISUZU	ELF150	4JA1			TRUCKS	C-1511	Oil Filter
1294	ISUZU	ELF150	4JA1			TRUCKS	FC-1203	Fuel Filter
1295	ISUZU	ELF150	4JB1			TRUCKS	A-1502	Air Filter
1296	ISUZU	ELF150	4JB1			TRUCKS	A-1502	Air Filter
1297	ISUZU	ELF150	4JB1			TRUCKS	A-1502	Air Filter
1298	ISUZU	ELF150	4JB1			TRUCKS	C-1511	Oil Filter
1299	ISUZU	ELF150	4JB1			TRUCKS	C-1511	Oil Filter
1300	ISUZU	ELF150	4JB1			TRUCKS	C-1511	Oil Filter
1301	ISUZU	ELF150 [ 05/01 ]	3100 4WD KR-NHS69A [ 4JG2 ]	2005		TRUCKS	A-6017	Air Filter
1302	ISUZU	ELF150 [ 05/01 ]	3100 4WD KR-NHS69A [ 4JG2 ]	2005		TRUCKS	C-1546	Oil Filter
1303	ISUZU	ELF150 [ 05/01 ]	3100 4WD KR-NHS69A [ 4JG2 ]	2005		TRUCKS	FC-1203	Fuel Filter
1304	ISUZU	ELF150 [ 99/05 - 05/01 ]	3100 4WD KK-NHS69 [ 4JG2 ]	1999	2005	TRUCKS	A-6017	Air Filter
1305	ISUZU	ELF150 [ 99/05 - 05/01 ]	3100 4WD KK-NHS69 [ 4JG2 ]	1999	2005	TRUCKS	C-1546	Oil Filter
1306	ISUZU	ELF150 [ 99/05 - 05/01 ]	3100 4WD KK-NHS69 [ 4JG2 ]	1999	2005	TRUCKS	FC-1203	Fuel Filter
1307	ISUZU	ELF250	4BC2			TRUCKS	A-1505	Air Filter
1308	ISUZU	ELF250	4BC2			TRUCKS	A-1505	Air Filter
1309	ISUZU	ELF250	4BC2			TRUCKS	C-1504	Oil Filter
1310	ISUZU	ELF250	4BC2			TRUCKS	C-1504	Oil Filter
1311	ISUZU	ELF250	4BC2			TRUCKS	C-1508	Oil Filter
1312	ISUZU	ELF250	4BC2			TRUCKS	C-1508	Oil Filter
1313	ISUZU	ELF250	4BE1			TRUCKS	A-1502	Air Filter
1314	ISUZU	ELF250	4BE1			TRUCKS	A-1502	Air Filter
1315	ISUZU	ELF250	4BE1			TRUCKS	A-1502	Air Filter
1316	ISUZU	ELF250	4BE1			TRUCKS	C-1504	Oil Filter
1317	ISUZU	ELF250	4BE1			TRUCKS	C-1504	Oil Filter
1318	ISUZU	ELF250	4BE1			TRUCKS	C-1504	Oil Filter
1319	ISUZU	ELF250	4BE1			TRUCKS	C-1508	Oil Filter
1320	ISUZU	ELF250	4BE1			TRUCKS	C-1508	Oil Filter
1321	ISUZU	ELF250	4BE1			TRUCKS	C-1508	Oil Filter
1322	ISUZU	ELF250	4BE2			TRUCKS	A-1502	Air Filter
1323	ISUZU	ELF250	4BE2			TRUCKS	A-1502	Air Filter
1324	ISUZU	ELF250	4BE2			TRUCKS	A-1510	Air Filter
1325	ISUZU	ELF250	4BE2			TRUCKS	C-1504	Oil Filter
1326	ISUZU	ELF250	4BE2			TRUCKS	C-1504	Oil Filter
1327	ISUZU	ELF250	4BE2			TRUCKS	C-1504	Oil Filter
1328	ISUZU	ELF250	4BE2			TRUCKS	C-1508	Oil Filter
1329	ISUZU	ELF250	4BE2			TRUCKS	C-1508	Oil Filter
1330	ISUZU	ELF250	4BE2			TRUCKS	C-1508	Oil Filter
1331	ISUZU	ELF250	4BE2			TRUCKS	FC-1203	Fuel Filter
1332	ISUZU	ELF250	4JB1			TRUCKS	A-1502	Air Filter
1333	ISUZU	ELF250	4JB1			TRUCKS	C-1511	Oil Filter
1334	ISUZU	ELF250 2800 SERIES P-NKR55 - ISUZU 4JB1	Engine: N/A			TRUCKS	A-1817	Air Filter
1335	ISUZU	ELF250 2800 SERIES P-NKR56 - ISUZU 4BA1	Engine: N/A			TRUCKS	A-1817	Air Filter

Sakura Filter			ENGINE APPLICATION					
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1336	ISUZU	ELF250 2800 SERIES U-NKR55 - ISUZU 4BA1	Engine: N/A			TRUCKS	A-1817	Air Filter
1337	ISUZU	ELF250 3300 SERIES P-NKR57 - ISUZU 4BC2	Engine: N/A			TRUCKS	A-1817	Air Filter
1338	ISUZU	ELF250 3300 SERIES P-NPR57 - ISUZU 4BC2	Engine: N/A			TRUCKS	A-1505	Air Filter
1339	ISUZU	ELF250 3600 SERIES P-NKR58 - ISUZU 4BE1	Engine: N/A			TRUCKS	A-1817	Air Filter
1340	ISUZU	ELF250 3600 SERIES P-NPR58 - ISUZU 4BE1	Engine: N/A			TRUCKS	A-1817	Air Filter
1341	ISUZU	ELF250 3600 SERIES U-NKR58 - ISUZU 4BE1	Engine: N/A			TRUCKS	A-1817	Air Filter
1342	ISUZU	ELF250 4300 SERIES U-NKR61 - ISUZU 4BG1	Engine: N/A			TRUCKS	A-1817	Air Filter
1343	ISUZU	ELF250 NKR58 4WD - ISUZU 4BE1	Engine: N/A			TRUCKS	A-1505	Air Filter
1344	ISUZU	ESR12 - ISUZU 6BG1T 1990	Engine: N/A			TRUCKS	C-1009	Oil Filter
1345	ISUZU	ESR12 - ISUZU 6BG1T 1990	Engine: N/A			TRUCKS	C-5505	Oil Filter
1346	ISUZU	ESR12 - ISUZU 6BG1T 1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1347	ISUZU	EVR - ISUZU 6BD1-T DIESEL 1986 - 1991	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1348	ISUZU	EVR - ISUZU 6SA1-T 513 CID 1988	Engine: N/A			TRUCKS	C-5505	Oil Filter
1349	ISUZU	EVR - ISUZU 6SA1-T 513 CID 1988	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1350	ISUZU	EVR - ISUZU 8.413L DIESEL 1988	Engine: N/A			TRUCKS	C-5505	Oil Filter
1351	ISUZU	EVR - ISUZU 8.413L DIESEL 1988	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1352	ISUZU	EX# TRACTOR	10PC1			TRUCKS	F-1503	Fuel Filter
1353	ISUZU	EX# TRACTOR	10PC1			TRUCKS	F-1503	Fuel Filter
1354	ISUZU	EX# TRACTOR	10PC1			TRUCKS	O-1512	Oil Filter
1355	ISUZU	EX# TRACTOR	10PC1			TRUCKS	O-1512	Oil Filter
1356	ISUZU	EX# TRACTOR	10PD1			TRUCKS	F-1503	Fuel Filter
1357	ISUZU	EX# TRACTOR	10PD1			TRUCKS	F-1503	Fuel Filter
1358	ISUZU	EX# TRACTOR	10PD1			TRUCKS	F-1503	Fuel Filter
1359	ISUZU	EX# TRACTOR	10PD1			TRUCKS	O-1530	Oil Filter
1360	ISUZU	EX# TRACTOR	10PD1			TRUCKS	O-1530	Oil Filter
1361	ISUZU	EX# TRACTOR	10PD1			TRUCKS	O-1530	Oil Filter
1362	ISUZU	EX# TRACTOR	10PD1			TRUCKS	O-1532	Oil Filter
1363	ISUZU	EX# TRACTOR	10PD1			TRUCKS	O-1532	Oil Filter
1364	ISUZU	EX# TRACTOR	10PD1			TRUCKS	O-1532	Oil Filter
1365	ISUZU	EX# TRACTOR	12PC1			TRUCKS	A-6010	Air Filter
1366	ISUZU	EX# TRACTOR	12PC1			TRUCKS	A-6010	Air Filter
1367	ISUZU	EX# TRACTOR	12PC1			TRUCKS	F-1503	Fuel Filter
1368	ISUZU	EX# TRACTOR	12PC1			TRUCKS	F-1503	Fuel Filter
1369	ISUZU	EX# TRACTOR	12PC1			TRUCKS	O-1512	Oil Filter
1370	ISUZU	EX# TRACTOR	12PC1			TRUCKS	O-1512	Oil Filter
1371	ISUZU	EX# TRACTOR	12PD1			TRUCKS	A-6010	Air Filter
1372	ISUZU	EX# TRACTOR	12PD1			TRUCKS	A-6010	Air Filter
1373	ISUZU	EX# TRACTOR	12PD1			TRUCKS	A-6010	Air Filter
1374	ISUZU	EX# TRACTOR	12PD1			TRUCKS	F-1503	Fuel Filter
1375	ISUZU	EX# TRACTOR	12PD1			TRUCKS	F-1503	Fuel Filter
1376	ISUZU	EX# TRACTOR	12PD1			TRUCKS	F-1503	Fuel Filter
1377	ISUZU	EX# TRACTOR	12PD1			TRUCKS	O-1521	Oil Filter
1378	ISUZU	EX# TRACTOR	12PD1			TRUCKS	O-1521	Oil Filter
1379	ISUZU	EX# TRACTOR	12PD1			TRUCKS	O-1521	Oil Filter
1380	ISUZU	EX# TRACTOR	12PD1			TRUCKS	O-1532	Oil Filter
1381	ISUZU	EX# TRACTOR	12PD1			TRUCKS	O-1532	Oil Filter
1382	ISUZU	EX# TRACTOR	12PD1			TRUCKS	O-1532	Oil Filter
1383	ISUZU	EXR12 - ISUZU 6BG1 1990	Engine: N/A			TRUCKS	C-1009	Oil Filter
1384	ISUZU	EXR12 - ISUZU 6BG1 1990	Engine: N/A			TRUCKS	C-5505	Oil Filter
1385	ISUZU	EXR12 - ISUZU 6BG1 1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1386	ISUZU	F SERIES P-FSR11 - ISUZU 6BD1T	Engine: N/A			TRUCKS	C-1009	Oil Filter
1387	ISUZU	F SERIES P-FSR11 - ISUZU 6BD1T	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1388	ISUZU	F SERIES P-FTR11 - ISUZU 6BD1T	Engine: N/A			TRUCKS	C-1009	Oil Filter
1389	ISUZU	F SERIES P-FTR11 - ISUZU 6BD1T	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1390	ISUZU	F SERIES U-FTR12 4WD - ISUZU 6BG1T	Engine: N/A			TRUCKS	C-1009	Oil Filter
1391	ISUZU	F SERIES U-FTR12 4WD - ISUZU 6BG1T	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1392	ISUZU	FARGO [ 88/09 - 90/11 ]	2400 (D) TRUCK (A/T) U-NFR62 [ 4FG1 ]	1988	1990	TRUCKS	A-1504	Air Filter
1393	ISUZU	FARGO [ 88/09 - 90/11 ]	2400 (D) TRUCK (A/T) U-NFR62 [ 4FG1 ]	1988	1990	TRUCKS	C-1525	Oil Filter
1394	ISUZU	FARGO [ 88/09 - 90/11 ]	2400 (D) TRUCK (A/T) U-NFR62 [ 4FG1 ]	1988	1990	TRUCKS	C-1605	Oil Filter

Sakura Filter				ENGINE APPLICATION				
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1395	ISUZU	FARGO [ 88/09 - 90/11 ]	2400 (D) TRUCK (M/T) U-NFR62 [ 4FG1 ]	1988	1990	TRUCKS	A-1504	Air Filter
1396	ISUZU	FARGO [ 88/09 - 90/11 ]	2400 (D) TRUCK (M/T) U-NFR62 [ 4FG1 ]	1988	1990	TRUCKS	C-1605	Oil Filter
1397	ISUZU	FARGO [ 88/09 - 90/11 ]	2400 (D) TRUCK 4WD (A/T) U-NFS62 [ 4FG1 ]	1988	1990	TRUCKS	A-1504	Air Filter
1398	ISUZU	FARGO [ 88/09 - 90/11 ]	2400 (D) TRUCK 4WD (A/T) U-NFS62 [ 4FG1 ]	1988	1990	TRUCKS	C-1525	Oil Filter
1399	ISUZU	FARGO [ 88/09 - 90/11 ]	2400 (D) TRUCK 4WD (A/T) U-NFS62 [ 4FG1 ]	1988	1990	TRUCKS	C-1605	Oil Filter
1400	ISUZU	FARGO [ 88/09 - 90/11 ]	2400 (D) TRUCK 4WD (M/T) U-NFS62 [ 4FG1 ]	1988	1990	TRUCKS	A-1504	Air Filter
1401	ISUZU	FARGO [ 88/09 - 90/11 ]	2400 (D) TRUCK 4WD (M/T) U-NFS62 [ 4FG1 ]	1988	1990	TRUCKS	C-1605	Oil Filter
1402	ISUZU	FARGO [ 88/09 - 95/08 ]	2000 TRUCK 4WD T(L)-NFS12 [ 4ZC1 ]	1988	1995	TRUCKS	A-1116	Air Filter
1403	ISUZU	FARGO [ 88/09 - 95/08 ]	2000 TRUCK 4WD T(L)-NFS12 [ 4ZC1 ]	1988	1995	TRUCKS	C-1605	Oil Filter
1404	ISUZU	FARGO [ 88/10 - 95/08 ]	2000 TRUCK T(L)-NFR12 [ 4ZC1 ]	1988	1995	TRUCKS	A-1116	Air Filter
1405	ISUZU	FARGO [ 88/10 - 95/08 ]	2000 TRUCK T(L)-NFR12 [ 4ZC1 ]	1988	1995	TRUCKS	C-1605	Oil Filter
1406	ISUZU	FARGO [ 90/12 - 95/08 ]	2400 (D) TRUCK 4WD U-NFS62 [ 4FG1 ]	1990	1995	TRUCKS	A-1502	Air Filter
1407	ISUZU	FARGO [ 90/12 - 95/08 ]	2400 (D) TRUCK 4WD U-NFS62 [ 4FG1 ]	1990	1995	TRUCKS	C-1525	Oil Filter
1408	ISUZU	FARGO [ 90/12 - 95/08 ]	2400 (D) TRUCK 4WD U-NFS62 [ 4FG1 ]	1990	1995	TRUCKS	C-1605	Oil Filter
1409	ISUZU	FARGO [ 90/12 - 95/08 ]	2400 (D) TRUCK U-NFR62 [ 4FG1 ]	1990	1995	TRUCKS	A-1502	Air Filter
1410	ISUZU	FARGO [ 90/12 - 95/08 ]	2400 (D) TRUCK U-NFR62 [ 4FG1 ]	1990	1995	TRUCKS	C-1525	Oil Filter
1411	ISUZU	FARGO [ 90/12 - 95/08 ]	2400 (D) TRUCK U-NFR62 [ 4FG1 ]	1990	1995	TRUCKS	C-1605	Oil Filter
1412	ISUZU	FGMJ5 - ISUZU D16A 1999 -2000	Engine: N/A			TRUCKS	C-1605	Oil Filter
1413	ISUZU	FORWARD	4HK1-T			TRUCKS	A-5539	Air Filter
1414	ISUZU	FORWARD	4HK1-T			TRUCKS	A-5539	Air Filter
1415	ISUZU	FORWARD	4HK1-T			TRUCKS	A-5539	Air Filter
1416	ISUZU	FORWARD	4HK1-T			TRUCKS	A-5539	Air Filter
1417	ISUZU	FORWARD	4HK1-T			TRUCKS	A-5539	Air Filter
1418	ISUZU	FORWARD	4HK1-T			TRUCKS	A-5539	Air Filter
1419	ISUZU	FORWARD	4HK1-T			TRUCKS	A-5539	Air Filter
1420	ISUZU	FORWARD	4HK1-T			TRUCKS	A-5539	Air Filter
1421	ISUZU	FORWARD	4HK1-T			TRUCKS	A-5539	Air Filter
1422	ISUZU	FORWARD	4HK1-T			TRUCKS	A-5539	Air Filter
1423	ISUZU	FORWARD	4HK1-T			TRUCKS	A-5539	Air Filter
1424	ISUZU	FORWARD	4HK1-T			TRUCKS	A-5539	Air Filter
1425	ISUZU	FORWARD	4HK1-T			TRUCKS	A-5539	Air Filter
1426	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1427	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1428	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1429	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1430	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1431	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1432	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1433	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1434	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1435	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1436	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1437	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1438	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1439	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1440	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1441	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1442	ISUZU	FORWARD	4HK1-T			TRUCKS	C-1542	Oil Filter
1443	ISUZU	FORWARD	4HK1-T			TRUCKS	EF-15010	Fuel Filter
1444	ISUZU	FORWARD	4HK1-T			TRUCKS	EF-15010	Fuel Filter
1445	ISUZU	FORWARD	4HK1-T			TRUCKS	EF-15010	Fuel Filter
1446	ISUZU	FORWARD	4HK1-T			TRUCKS	EF-15010	Fuel Filter
1447	ISUZU	FORWARD	4HK1-T			TRUCKS	EF-15010	Fuel Filter
1448	ISUZU	FORWARD	4HK1-T			TRUCKS	EF-15010	Fuel Filter
1449	ISUZU	FORWARD	4HK1-T			TRUCKS	EF-15010	Fuel Filter
1450	ISUZU	FORWARD	4HK1-T			TRUCKS	EF-15010	Fuel Filter
1451	ISUZU	FORWARD	4HK1-T			TRUCKS	EF-1509	Fuel Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1452	ISUZU	FORWARD	4HK1-T			TRUCKS	EF-1509	Fuel Filter
1453	ISUZU	FORWARD	4HK1-T			TRUCKS	EF-1509	Fuel Filter
1454	ISUZU	FORWARD	4HK1-T			TRUCKS	EF-1509	Fuel Filter
1455	ISUZU	FORWARD	4HK1-T			TRUCKS	EF-1509	Fuel Filter
1456	ISUZU	FORWARD	4HK1-T			TRUCKS	FC-1203	Fuel Filter
1457	ISUZU	FORWARD	4HK1-T			TRUCKS	FC-1203	Fuel Filter
1458	ISUZU	FORWARD	4HK1-T			TRUCKS	FC-1203	Fuel Filter
1459	ISUZU	FORWARD	4HK1-T			TRUCKS	FC-1203	Fuel Filter
1460	ISUZU	FORWARD	6BG1			TRUCKS	A-1305	Air Filter
1461	ISUZU	FORWARD	6BG1			TRUCKS	A-1305	Air Filter
1462	ISUZU	FORWARD	6BG1			TRUCKS	A-6006	Air Filter
1463	ISUZU	FORWARD	6BG1			TRUCKS	C-1521	Oil Filter
1464	ISUZU	FORWARD	6BG1			TRUCKS	FC-1509	Fuel Filter
1465	ISUZU	FORWARD	6BG1			TRUCKS	FC-1509	Fuel Filter
1466	ISUZU	FORWARD	6BG1			TRUCKS	FC-1509	Fuel Filter
1467	ISUZU	FORWARD	6BG1			TRUCKS	FC-1509	Fuel Filter
1468	ISUZU	FORWARD	6BG1			TRUCKS	FC-1509	Fuel Filter
1469	ISUZU	FORWARD	6BG1			TRUCKS	FC-1509	Fuel Filter
1470	ISUZU	FORWARD	6BG1			TRUCKS	O-1519	Oil Filter
1471	ISUZU	FORWARD	6BG1			TRUCKS	O-1519	Oil Filter
1472	ISUZU	FORWARD	6BG1			TRUCKS	O-1519	Oil Filter
1473	ISUZU	FORWARD	6BG1			TRUCKS	O-1519	Oil Filter
1474	ISUZU	FORWARD	6BG1			TRUCKS	O-1519	Oil Filter
1475	ISUZU	FORWARD	6BG1-T			TRUCKS	C-1524	Oil Filter
1476	ISUZU	FORWARD	6BG1-T			TRUCKS	C-1524	Oil Filter
1477	ISUZU	FORWARD	6BG1-T			TRUCKS	C-1524	Oil Filter
1478	ISUZU	FORWARD	6BG1-T			TRUCKS	C-1524	Oil Filter
1479	ISUZU	FORWARD	6BG1-T			TRUCKS	FC-1509	Fuel Filter
1480	ISUZU	FORWARD	6BG1-T			TRUCKS	FC-1509	Fuel Filter
1481	ISUZU	FORWARD	6BG1-T			TRUCKS	FC-1509	Fuel Filter
1482	ISUZU	FORWARD	6BG1-T			TRUCKS	FC-1509	Fuel Filter
1483	ISUZU	FORWARD	6HA1			TRUCKS	A-5539	Air Filter
1484	ISUZU	FORWARD	6HA1			TRUCKS	A-5539	Air Filter
1485	ISUZU	FORWARD	6HA1			TRUCKS	A-5539	Air Filter
1486	ISUZU	FORWARD	6HA1			TRUCKS	A-5539	Air Filter
1487	ISUZU	FORWARD	6HA1			TRUCKS	A-5539	Air Filter
1488	ISUZU	FORWARD	6HA1			TRUCKS	A-6006	Air Filter
1489	ISUZU	FORWARD	6HA1			TRUCKS	C-1533	Oil Filter
1490	ISUZU	FORWARD	6HA1			TRUCKS	C-1533	Oil Filter
1491	ISUZU	FORWARD	6HA1			TRUCKS	C-1533	Oil Filter
1492	ISUZU	FORWARD	6HA1			TRUCKS	C-1533	Oil Filter
1493	ISUZU	FORWARD	6HA1			TRUCKS	C-1533	Oil Filter
1494	ISUZU	FORWARD	6HA1			TRUCKS	C-1533	Oil Filter
1495	ISUZU	FORWARD	6HA1			TRUCKS	C-1533	Oil Filter
1496	ISUZU	FORWARD	6HA1			TRUCKS	C-1533	Oil Filter
1497	ISUZU	FORWARD	6HA1			TRUCKS	C-1533	Oil Filter
1498	ISUZU	FORWARD	6HE1			TRUCKS	A-1013	Air Filter
1499	ISUZU	FORWARD	6HE1			TRUCKS	A-5539	Air Filter
1500	ISUZU	FORWARD	6HE1			TRUCKS	A-5539	Air Filter
1501	ISUZU	FORWARD	6HE1			TRUCKS	A-6006	Air Filter
1502	ISUZU	FORWARD	6HE1			TRUCKS	C-1533	Oil Filter
1503	ISUZU	FORWARD	6HE1			TRUCKS	C-1533	Oil Filter
1504	ISUZU	FORWARD	6HE1			TRUCKS	C-1533	Oil Filter
1505	ISUZU	FORWARD	6HE1			TRUCKS	C-1533	Oil Filter
1506	ISUZU	FORWARD	6HE1			TRUCKS	C-1533	Oil Filter
1507	ISUZU	FORWARD	6HE1			TRUCKS	C-1533	Oil Filter
1508	ISUZU	FORWARD	6HE1			TRUCKS	C-1533	Oil Filter
1509	ISUZU	FORWARD	6HE1			TRUCKS	C-1533	Oil Filter
1510	ISUZU	FORWARD	6HE1			TRUCKS	C-1533	Oil Filter
1511	ISUZU	FORWARD	6HE1			TRUCKS	C-1533	Oil Filter
1512	ISUZU	FORWARD	6HE1			TRUCKS	FC-1301	Fuel Filter
1513	ISUZU	FORWARD	6HE1			TRUCKS	FC-1301	Fuel Filter
1514	ISUZU	FORWARD	6HE1			TRUCKS	FC-1301	Fuel Filter
1515	ISUZU	FORWARD	6HE1			TRUCKS	FC-1301	Fuel Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1516	ISUZU	FORWARD	6HE1			TRUCKS	FC-1301	Fuel Filter
1517	ISUZU	FORWARD	6HE1			TRUCKS	FC-1301	Fuel Filter
1518	ISUZU	FORWARD	6HE1			TRUCKS	FC-1301	Fuel Filter
1519	ISUZU	FORWARD	6HE1			TRUCKS	FC-1301	Fuel Filter
1520	ISUZU	FORWARD	6HE1			TRUCKS	FC-1301	Fuel Filter
1521	ISUZU	FORWARD	6HE1-T			TRUCKS	A-1013	Air Filter
1522	ISUZU	FORWARD	6HE1-T			TRUCKS	A-1013	Air Filter
1523	ISUZU	FORWARD	6HE1-T			TRUCKS	A-1013	Air Filter
1524	ISUZU	FORWARD	6HE1-T			TRUCKS	A-1013	Air Filter
1525	ISUZU	FORWARD	6HE1-T			TRUCKS	A-1013	Air Filter
1526	ISUZU	FORWARD	6HE1-T			TRUCKS	A-1013	Air Filter
1527	ISUZU	FORWARD	6HE1-T			TRUCKS	A-1013	Air Filter
1528	ISUZU	FORWARD	6HE1-T			TRUCKS	A-1013	Air Filter
1529	ISUZU	FORWARD	6HE1-T			TRUCKS	A-1013	Air Filter
1530	ISUZU	FORWARD	6HE1-T			TRUCKS	A-1013	Air Filter
1531	ISUZU	FORWARD	6HE1-T			TRUCKS	A-1013	Air Filter
1532	ISUZU	FORWARD	6HE1-T			TRUCKS	A-1013	Air Filter
1533	ISUZU	FORWARD	6HE1-T			TRUCKS	A-1013	Air Filter
1534	ISUZU	FORWARD	6HE1-T			TRUCKS	A-1013	Air Filter
1535	ISUZU	FORWARD	6HE1-T			TRUCKS	A-5539	Air Filter
1536	ISUZU	FORWARD	6HE1-T			TRUCKS	C-1533	Oil Filter
1537	ISUZU	FORWARD	6HE1-T			TRUCKS	C-1533	Oil Filter
1538	ISUZU	FORWARD	6HE1-T			TRUCKS	C-1533	Oil Filter
1539	ISUZU	FORWARD	6HE1-T			TRUCKS	C-1533	Oil Filter
1540	ISUZU	FORWARD	6HE1-T			TRUCKS	C-1533	Oil Filter
1541	ISUZU	FORWARD	6HE1-T			TRUCKS	C-1533	Oil Filter
1542	ISUZU	FORWARD	6HE1-T			TRUCKS	C-1533	Oil Filter
1543	ISUZU	FORWARD	6HE1-T			TRUCKS	C-1533	Oil Filter
1544	ISUZU	FORWARD	6HE1-T			TRUCKS	C-1533	Oil Filter
1545	ISUZU	FORWARD	6HE1-T			TRUCKS	C-1533	Oil Filter
1546	ISUZU	FORWARD	6HE1-T			TRUCKS	C-1533	Oil Filter
1547	ISUZU	FORWARD	6HE1-T			TRUCKS	C-1533	Oil Filter
1548	ISUZU	FORWARD	6HE1-T			TRUCKS	C-1533	Oil Filter
1549	ISUZU	FORWARD	6HE1-T			TRUCKS	C-1533	Oil Filter
1550	ISUZU	FORWARD	6HE1-T			TRUCKS	FC-1301	Fuel Filter
1551	ISUZU	FORWARD	6HE1-T			TRUCKS	FC-1301	Fuel Filter
1552	ISUZU	FORWARD	6HE1-T			TRUCKS	FC-1301	Fuel Filter
1553	ISUZU	FORWARD	6HE1-T			TRUCKS	FC-1301	Fuel Filter
1554	ISUZU	FORWARD	6HE1-T			TRUCKS	FC-1301	Fuel Filter
1555	ISUZU	FORWARD	6HE1-T			TRUCKS	FC-1301	Fuel Filter
1556	ISUZU	FORWARD	6HE1-T			TRUCKS	FC-1301	Fuel Filter
1557	ISUZU	FORWARD	6HE1-T			TRUCKS	FC-1301	Fuel Filter
1558	ISUZU	FORWARD	6HE1-T			TRUCKS	FC-1301	Fuel Filter
1559	ISUZU	FORWARD	6HE1-T			TRUCKS	FC-1301	Fuel Filter
1560	ISUZU	FORWARD	6HE1-T			TRUCKS	FC-1301	Fuel Filter
1561	ISUZU	FORWARD	6HE1-T			TRUCKS	FC-1301	Fuel Filter
1562	ISUZU	FORWARD	6HE1-T			TRUCKS	FC-1301	Fuel Filter
1563	ISUZU	FORWARD	6HE1-T			TRUCKS	FC-1301	Fuel Filter
1564	ISUZU	FORWARD	6HF1			TRUCKS	A-5539	Air Filter
1565	ISUZU	FORWARD	6HF1			TRUCKS	C-1533	Oil Filter
1566	ISUZU	FORWARD	6HF1			TRUCKS	C-1533	Oil Filter
1567	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter
1568	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter
1569	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter
1570	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter
1571	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter
1572	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter
1573	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter
1574	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter
1575	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter
1576	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter
1577	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter
1578	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter
1579	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter



Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1580	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter
1581	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter
1582	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter
1583	ISUZU	FORWARD	6HH1			TRUCKS	A-5539	Air Filter
1584	ISUZU	FORWARD	6HH1			TRUCKS	A-6006	Air Filter
1585	ISUZU	FORWARD	6HH1			TRUCKS	A-6006	Air Filter
1586	ISUZU	FORWARD	6HH1			TRUCKS	A-6006	Air Filter
1587	ISUZU	FORWARD	6HH1			TRUCKS	A-6006	Air Filter
1588	ISUZU	FORWARD	6HH1			TRUCKS	A-6006	Air Filter
1589	ISUZU	FORWARD	6HH1			TRUCKS	A-6006	Air Filter
1590	ISUZU	FORWARD	6HH1			TRUCKS	A-6006	Air Filter
1591	ISUZU	FORWARD	6HH1			TRUCKS	A-6007	Air Filter
1592	ISUZU	FORWARD	6HH1			TRUCKS	A-6007	Air Filter
1593	ISUZU	FORWARD	6HH1			TRUCKS	A-6007	Air Filter
1594	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1595	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1596	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1597	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1598	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1599	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1600	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1601	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1602	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1603	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1604	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1605	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1606	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1607	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1608	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1609	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1610	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1611	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1612	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1613	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1614	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1615	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1616	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1617	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1618	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1619	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1620	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1621	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1622	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1623	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1624	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1625	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1626	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1627	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1628	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1629	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1630	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1631	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1632	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1633	ISUZU	FORWARD	6HH1			TRUCKS	C-1533	Oil Filter
1634	ISUZU	FORWARD	6HH1			TRUCKS	FC-1301	Fuel Filter
1635	ISUZU	FORWARD	6HH1			TRUCKS	FC-1301	Fuel Filter
1636	ISUZU	FORWARD	6HH1			TRUCKS	FC-1301	Fuel Filter
1637	ISUZU	FORWARD	6HH1			TRUCKS	FC-1301	Fuel Filter
1638	ISUZU	FORWARD	6HH1			TRUCKS	FC-1301	Fuel Filter
1639	ISUZU	FORWARD	6HH1			TRUCKS	FC-1301	Fuel Filter
1640	ISUZU	FORWARD	6HH1			TRUCKS	FC-1301	Fuel Filter
1641	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1642	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1643	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter



Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1644	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1645	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1646	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1647	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1648	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1649	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1650	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1651	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1652	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1653	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1654	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1655	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1656	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1657	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1658	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1659	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1660	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1661	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1662	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1663	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1664	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1665	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1666	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1667	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1668	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1669	ISUZU	FORWARD	6HH1			TRUCKS	FC-1509	Fuel Filter
1670	ISUZU	FORWARD	6HK1-T			TRUCKS	A-1013	Air Filter
1671	ISUZU	FORWARD	6HK1-T			TRUCKS	A-1013	Air Filter
1672	ISUZU	FORWARD	6HK1-T			TRUCKS	A-1013	Air Filter
1673	ISUZU	FORWARD	6HK1-T			TRUCKS	A-1013	Air Filter
1674	ISUZU	FORWARD	6HK1-T			TRUCKS	A-5539	Air Filter
1675	ISUZU	FORWARD	6HK1-T			TRUCKS	A-5539	Air Filter
1676	ISUZU	FORWARD	6HK1-T			TRUCKS	A-5539	Air Filter
1677	ISUZU	FORWARD	6HK1-T			TRUCKS	A-5539	Air Filter
1678	ISUZU	FORWARD	6HK1-T			TRUCKS	A-5539	Air Filter
1679	ISUZU	FORWARD	6HK1-T			TRUCKS	A-6006	Air Filter
1680	ISUZU	FORWARD	6HK1-T			TRUCKS	A-6006	Air Filter
1681	ISUZU	FORWARD	6HK1-T			TRUCKS	A-6006	Air Filter
1682	ISUZU	FORWARD	6HK1-T			TRUCKS	A-6006	Air Filter
1683	ISUZU	FORWARD	6HK1-T			TRUCKS	A-6036	Air Filter
1684	ISUZU	FORWARD	6HK1-T			TRUCKS	A-6036	Air Filter
1685	ISUZU	FORWARD	6HK1-T			TRUCKS	A-6036	Air Filter
1686	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1687	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1688	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1689	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1690	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1691	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1692	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1693	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1694	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1695	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1696	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1697	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1698	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1699	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1700	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1701	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1702	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1703	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1704	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1705	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1706	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1707	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1708	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1709	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1710	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1711	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1712	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1713	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1714	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1715	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1716	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1717	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1718	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1719	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1720	ISUZU	FORWARD	6HK1-T			TRUCKS	C-1533	Oil Filter
1721	ISUZU	FORWARD	6HK1-T			TRUCKS	EF-1509	Fuel Filter
1722	ISUZU	FORWARD	6HK1-T			TRUCKS	EF-1509	Fuel Filter
1723	ISUZU	FORWARD	6HK1-T			TRUCKS	EF-1509	Fuel Filter
1724	ISUZU	FORWARD	6HK1-T			TRUCKS	EF-1509	Fuel Filter
1725	ISUZU	FORWARD	6HK1-T			TRUCKS	EF-1509	Fuel Filter
1726	ISUZU	FORWARD	6HK1-T			TRUCKS	EF-1509	Fuel Filter
1727	ISUZU	FORWARD	6HK1-T			TRUCKS	EF-1509	Fuel Filter
1728	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1203	Fuel Filter
1729	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1203	Fuel Filter
1730	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1203	Fuel Filter
1731	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1203	Fuel Filter
1732	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1203	Fuel Filter
1733	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1203	Fuel Filter
1734	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1203	Fuel Filter
1735	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1203	Fuel Filter
1736	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1203	Fuel Filter
1737	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1203	Fuel Filter
1738	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1203	Fuel Filter
1739	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1203	Fuel Filter
1740	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1203	Fuel Filter
1741	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1203	Fuel Filter
1742	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1509	Fuel Filter
1743	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1509	Fuel Filter
1744	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1509	Fuel Filter
1745	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1509	Fuel Filter
1746	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1509	Fuel Filter
1747	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1509	Fuel Filter
1748	ISUZU	FORWARD	6HK1-T			TRUCKS	FC-1509	Fuel Filter
1749	ISUZU	FORWARD	6HL1			TRUCKS	A-5539	Air Filter
1750	ISUZU	FORWARD	6HL1			TRUCKS	A-5539	Air Filter
1751	ISUZU	FORWARD	6HL1			TRUCKS	A-5539	Air Filter
1752	ISUZU	FORWARD	6HL1			TRUCKS	A-5539	Air Filter
1753	ISUZU	FORWARD	6HL1			TRUCKS	A-5539	Air Filter
1754	ISUZU	FORWARD	6HL1			TRUCKS	A-5539	Air Filter
1755	ISUZU	FORWARD	6HL1			TRUCKS	A-5539	Air Filter
1756	ISUZU	FORWARD	6HL1			TRUCKS	A-6006	Air Filter
1757	ISUZU	FORWARD	6HL1			TRUCKS	A-6006	Air Filter
1758	ISUZU	FORWARD	6HL1			TRUCKS	A-6006	Air Filter
1759	ISUZU	FORWARD	6HL1			TRUCKS	A-6006	Air Filter
1760	ISUZU	FORWARD	6HL1			TRUCKS	A-6006	Air Filter
1761	ISUZU	FORWARD	6HL1			TRUCKS	A-6006	Air Filter
1762	ISUZU	FORWARD	6HL1			TRUCKS	A-6007	Air Filter
1763	ISUZU	FORWARD	6HL1			TRUCKS	A-6007	Air Filter
1764	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1765	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1766	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1767	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1768	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1769	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1770	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1771	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1772	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1773	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1774	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1775	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1776	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1777	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1778	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1779	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1780	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1781	ISUZU	FORWARD	6HL1			TRUCKS	C-1533	Oil Filter
1782	ISUZU	FORWARD	6HL1			TRUCKS	FC-1203	Fuel Filter
1783	ISUZU	FORWARD	6HL1			TRUCKS	FC-1203	Fuel Filter
1784	ISUZU	FORWARD	6HL1			TRUCKS	FC-1203	Fuel Filter
1785	ISUZU	FORWARD	6HL1			TRUCKS	FC-1203	Fuel Filter
1786	ISUZU	FORWARD	6HL1			TRUCKS	FC-1203	Fuel Filter
1787	ISUZU	FORWARD	6HL1			TRUCKS	FC-1203	Fuel Filter
1788	ISUZU	FORWARD	6HL1			TRUCKS	FC-1203	Fuel Filter
1789	ISUZU	FORWARD	6HL1			TRUCKS	FC-1203	Fuel Filter
1790	ISUZU	FORWARD	6HL1			TRUCKS	FC-1203	Fuel Filter
1791	ISUZU	FORWARD	6HL1			TRUCKS	FC-1203	Fuel Filter
1792	ISUZU	FORWARD	6HL1			TRUCKS	FC-1203	Fuel Filter
1793	ISUZU	FORWARD	6HL1			TRUCKS	FC-1203	Fuel Filter
1794	ISUZU	FORWARD	6HL1			TRUCKS	FC-1203	Fuel Filter
1795	ISUZU	FORWARD	6HL1			TRUCKS	FC-1203	Fuel Filter
1796	ISUZU	FORWARD	6HL1			TRUCKS	FC-1203	Fuel Filter
1797	ISUZU	FORWARD	6HL1			TRUCKS	FC-1203	Fuel Filter
1798	ISUZU	FORWARD	6HL1			TRUCKS	FC-1301	Fuel Filter
1799	ISUZU	FORWARD	6HL1			TRUCKS	FC-1301	Fuel Filter
1800	ISUZU	FORWARD	6HL1			TRUCKS	FC-1301	Fuel Filter
1801	ISUZU	FORWARD	6SA1			TRUCKS	C-1327	Oil Filter
1802	ISUZU	FORWARD	6SA1			TRUCKS	FC-1509	Fuel Filter
1803	ISUZU	FORWARD	BG1			TRUCKS	A-1305	Air Filter
1804	ISUZU	FORWARD	BG1			TRUCKS	FC-1509	Fuel Filter
1805	ISUZU	FORWARD	BG1			TRUCKS	O-1519	Oil Filter
1806	ISUZU	FORWARD	BG1-T			TRUCKS	A-6006	Air Filter
1807	ISUZU	FORWARD	BG1-T			TRUCKS	C-1524	Oil Filter
1808	ISUZU	FORWARD	BG1-T			TRUCKS	C-1524	Oil Filter
1809	ISUZU	FORWARD	BG1-T			TRUCKS	FC-1509	Fuel Filter
1810	ISUZU	FORWARD	BG1-T			TRUCKS	FC-1509	Fuel Filter
1811	ISUZU	FORWARD	HE1			TRUCKS	A-5539	Air Filter
1812	ISUZU	FORWARD	HE1			TRUCKS	C-1533	Oil Filter
1813	ISUZU	FORWARD	HE1			TRUCKS	C-1533	Oil Filter
1814	ISUZU	FORWARD	HE1			TRUCKS	FC-1301	Fuel Filter
1815	ISUZU	FORWARD	HE1			TRUCKS	FC-1301	Fuel Filter
1816	ISUZU	FORWARD	HE1-T			TRUCKS	A-1013	Air Filter
1817	ISUZU	FORWARD	HE1-T			TRUCKS	A-1013	Air Filter
1818	ISUZU	FORWARD	HE1-T			TRUCKS	C-1533	Oil Filter
1819	ISUZU	FORWARD	HE1-T			TRUCKS	C-1533	Oil Filter
1820	ISUZU	FORWARD	HE1-T			TRUCKS	FC-1301	Fuel Filter
1821	ISUZU	FORWARD	HE1-T			TRUCKS	FC-1301	Fuel Filter
1822	ISUZU	FORWARD	HK1-T			TRUCKS	C-1533	Oil Filter
1823	ISUZU	FORWARD	HK1-T			TRUCKS	C-1533	Oil Filter
1824	ISUZU	FORWARD	HK1-T			TRUCKS	C-1533	Oil Filter
1825	ISUZU	FORWARD	HK1-T			TRUCKS	C-1533	Oil Filter
1826	ISUZU	FORWARD	HK1-T			TRUCKS	FC-1203	Fuel Filter
1827	ISUZU	FORWARD	HK1-T			TRUCKS	FC-1203	Fuel Filter
1828	ISUZU	FORWARD	HK1-T			TRUCKS	FC-1509	Fuel Filter
1829	ISUZU	FORWARD	HK1-T			TRUCKS	FC-1509	Fuel Filter
1830	ISUZU	FORWARD	SA1			TRUCKS	A-6006	Air Filter
1831	ISUZU	FORWARD	SA1			TRUCKS	C-1327	Oil Filter
1832	ISUZU	FORWARD	SA1			TRUCKS	FC-1509	Fuel Filter
1833	ISUZU	FORWARD JUSTON	4HE1-T			TRUCKS	C-1542	Oil Filter
1834	ISUZU	FORWARD JUSTON	4HJ1			TRUCKS	A-1510	Air Filter
1835	ISUZU	FORWARD JUSTON	4HJ1			TRUCKS	A-6017	Air Filter

Sakura Filter							ENGINE APPLICATION	
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1836	ISUZU	FORWARD JUSTON	4HJ1			TRUCKS	A-6017	Air Filter
1837	ISUZU	FORWARD JUSTON	4HJ1			TRUCKS	C-1542	Oil Filter
1838	ISUZU	FORWARD JUSTON	4HJ1			TRUCKS	C-1542	Oil Filter
1839	ISUZU	FORWARD JUSTON	4HJ1			TRUCKS	C-1542	Oil Filter
1840	ISUZU	FORWARD JUSTON	4HJ1			TRUCKS	FC-1203	Fuel Filter
1841	ISUZU	FORWARD JUSTON	4HJ1			TRUCKS	FC-1203	Fuel Filter
1842	ISUZU	FORWARD JUSTON	4HK1-T			TRUCKS	C-1542	Oil Filter
1843	ISUZU	FORWARD JUSTON	4HK1-T			TRUCKS	C-1542	Oil Filter
1844	ISUZU	FORWARD JUSTON	4HK1-T			TRUCKS	FC-1203	Fuel Filter
1845	ISUZU	FORWARD JUSTON	4HK1-T			TRUCKS	FC-1203	Fuel Filter
1846	ISUZU	FORWARD JUSTON	6HE1			TRUCKS	A-6006	Air Filter
1847	ISUZU	FORWARD JUSTON	6HE1			TRUCKS	C-1533	Oil Filter
1848	ISUZU	FORWARD JUSTON	6HE1			TRUCKS	FC-1301	Fuel Filter
1849	ISUZU	FORWARD JUSTON	6HH1			TRUCKS	A-6006	Air Filter
1850	ISUZU	FORWARD JUSTON	6HH1			TRUCKS	C-1533	Oil Filter
1851	ISUZU	FORWARD JUSTON	6HH1			TRUCKS	FC-1301	Fuel Filter
1852	ISUZU	FORWARD JUSTON	6HL1			TRUCKS	A-6006	Air Filter
1853	ISUZU	FORWARD JUSTON	6HL1			TRUCKS	A-6006	Air Filter
1854	ISUZU	FORWARD JUSTON	6HL1			TRUCKS	C-1533	Oil Filter
1855	ISUZU	FORWARD JUSTON	6HL1			TRUCKS	C-1533	Oil Filter
1856	ISUZU	FORWARD JUSTON	6HL1			TRUCKS	FC-1203	Fuel Filter
1857	ISUZU	FORWARD JUSTON	6HL1			TRUCKS	FC-1301	Fuel Filter
1858	ISUZU	FRR - ISUZU 6HK1TCN 2002 -2004	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1859	ISUZU	FRR - ISUZU 7.1L 6HE1-TC 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1860	ISUZU	FSR - ISUZU 6.494L DIESEL 1988 -1991	Engine: N/A			TRUCKS	A-6007	Air Filter
1861	ISUZU	FSR - ISUZU 6.494L DIESEL 1988 -1991	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1862	ISUZU	FSR - ISUZU 6BD1-T 353 CID 5.785L 1987 -1990	Engine: N/A			TRUCKS	A-6007	Air Filter
1863	ISUZU	FSR - ISUZU 6BD1-T 353 CID 5.785L 1987 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1864	ISUZU	FSR - ISUZU 6BG1-NA 396 CID 1988 -1991	Engine: N/A			TRUCKS	A-6007	Air Filter
1865	ISUZU	FSR - ISUZU 6BG1-NA 396 CID 1988 -1991	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1866	ISUZU	FSR - ISUZU 6HK1TC 2003 -2004	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1867	ISUZU	FSR - ISUZU DIESEL 1987 -1990	Engine: N/A			TRUCKS	A-6007	Air Filter
1868	ISUZU	FSR - ISUZU DIESEL 1987 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1869	ISUZU	FSR11 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
1870	ISUZU	FSR11 - ISUZU 6BD1T	Engine: N/A			TRUCKS	A-6007	Air Filter
1871	ISUZU	FSR11 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
1872	ISUZU	FSR11FA - ISUZU 6BD1 1987	Engine: N/A			TRUCKS	A-6007	Air Filter
1873	ISUZU	FSR11HA - ISUZU 6BD1 1987	Engine: N/A			TRUCKS	A-6007	Air Filter
1874	ISUZU	FSR11KTRA - ISUZU 6BD1T 1987	Engine: N/A			TRUCKS	A-6007	Air Filter
1875	ISUZU	FSR12 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
1876	ISUZU	FSR12 - ISUZU 6BD1T	Engine: N/A			TRUCKS	A-6007	Air Filter
1877	ISUZU	FSR12 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
1878	ISUZU	FSR12FRA - ISUZU 6BG1 1987	Engine: N/A			TRUCKS	A-6007	Air Filter
1879	ISUZU	FSR12HA - ISUZU 6BG1 1987	Engine: N/A			TRUCKS	A-6007	Air Filter
1880	ISUZU	FSR12HRA - ISUZU 6BG1 1987	Engine: N/A			TRUCKS	A-6007	Air Filter
1881	ISUZU	FSR12KRA - ISUZU 6BG1 1987	Engine: N/A			TRUCKS	A-6007	Air Filter
1882	ISUZU	FSR12LA - ISUZU 6BG1 1987	Engine: N/A			TRUCKS	A-6007	Air Filter
1883	ISUZU	FSR450 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
1884	ISUZU	FSR450 - ISUZU 6BD1T	Engine: N/A			TRUCKS	A-6007	Air Filter
1885	ISUZU	FSR450 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
1886	ISUZU	FSR500 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
1887	ISUZU	FSR500 - ISUZU 6BD1T	Engine: N/A			TRUCKS	A-6007	Air Filter
1888	ISUZU	FSR500 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
1889	ISUZU	FSR500 - ISUZU 6HE1	Engine: N/A			TRUCKS	A-6007	Air Filter
1890	ISUZU	FSR550 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
1891	ISUZU	FSR550 - ISUZU 6BD1T	Engine: N/A			TRUCKS	A-6007	Air Filter
1892	ISUZU	FSR550 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
1893	ISUZU	FSR550 - ISUZU 6HE1	Engine: N/A			TRUCKS	A-6007	Air Filter
1894	ISUZU	FSR650 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
1895	ISUZU	FSR650 - ISUZU 6BD1T	Engine: N/A			TRUCKS	A-6007	Air Filter
1896	ISUZU	FSR650 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
1897	ISUZU	FSR650 - ISUZU 6HE1	Engine: N/A			TRUCKS	A-6007	Air Filter

## Sakura Filter

## ENGINE APPLICATION

NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1898	ISUZU	FSR750 - ISUZU 6HE1	Engine: N/A			TRUCKS	A-6007	Air Filter
1899	ISUZU	FSS500 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
1900	ISUZU	FTR - ISUZU 6BD1-T 353 CID 5.785L 1987 - 1990	Engine: N/A			TRUCKS	A-6007	Air Filter
1901	ISUZU	FTR - ISUZU 6BD1-T 353 CID 5.785L 1987 - 1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1902	ISUZU	FTR - ISUZU 6HK1TC 2003 -2004	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1903	ISUZU	FTR - ISUZU DIESEL 1987 -1990	Engine: N/A			TRUCKS	A-6007	Air Filter
1904	ISUZU	FTR - ISUZU DIESEL 1987 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1905	ISUZU	FTR11LTA - ISUZU 6BD1T 1987	Engine: N/A			TRUCKS	A-6007	Air Filter
1906	ISUZU	FTR12HA - ISUZU 6BG1 1987	Engine: N/A			TRUCKS	A-6007	Air Filter
1907	ISUZU	FTR12LA - ISUZU 6BG1 1987	Engine: N/A			TRUCKS	A-6007	Air Filter
1908	ISUZU	FTR800 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
1909	ISUZU	FTR800 SERIES - ISUZU 6HE1	Engine: N/A			TRUCKS	A-6007	Air Filter
1910	ISUZU	FTS12HA (4X4) - ISUZU 6BG1 1987	Engine: N/A			TRUCKS	A-6007	Air Filter
1911	ISUZU	FTS12HA - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
1912	ISUZU	FTS12HA - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
1913	ISUZU	FTS500 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
1914	ISUZU	FTS700 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
1915	ISUZU	FVR - ISUZU 6HK1TC 2003 -2004	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1916	ISUZU	FVR - ISUZU 6SA1-T 513 CID 1988	Engine: N/A			TRUCKS	C-5505	Oil Filter
1917	ISUZU	FVR - ISUZU 6SA1-T 513 CID 1988	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1918	ISUZU	FVR - ISUZU 8.413L DIESEL 1988	Engine: N/A			TRUCKS	C-5505	Oil Filter
1919	ISUZU	FVR - ISUZU 8.413L DIESEL 1988	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1920	ISUZU	FVR116S - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
1921	ISUZU	FVR116S - ISUZU 6BD1T	Engine: N/A			TRUCKS	A-6007	Air Filter
1922	ISUZU	FVR11NT - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
1923	ISUZU	FVR11NT - ISUZU 6BD1T	Engine: N/A			TRUCKS	A-6007	Air Filter
1924	ISUZU	FVR11NT - ISUZU 6BD1T 1985 -1986	Engine: N/A			TRUCKS	A-6007	Air Filter
1925	ISUZU	FVR12 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
1926	ISUZU	FVR12 - ISUZU 6BD1T	Engine: N/A			TRUCKS	A-6007	Air Filter
1927	ISUZU	FVR126 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
1928	ISUZU	FVR126 - ISUZU 6BD1T	Engine: N/A			TRUCKS	A-6007	Air Filter
1929	ISUZU	FVR12N - ISUZU 6BG1 1985 -1986	Engine: N/A			TRUCKS	A-6007	Air Filter
1930	ISUZU	FVR13HRA - ISUZU 6SA1 1987	Engine: N/A			TRUCKS	A-6007	Air Filter
1931	ISUZU	FVR13NRA - ISUZU 6SA1 1987	Engine: N/A			TRUCKS	A-6007	Air Filter
1932	ISUZU	FVR34SC -([2008-N/A])	N/A	2008	N/A	TRUCKS	EF-1509	Fuel Filter
1933	ISUZU	FVR900 MEDIUM - ISUZU 6SA1	Engine: N/A			TRUCKS	A-6007	Air Filter
1934	ISUZU	FVZ 34P 285PS	6HK1-UP			TRUCKS	A-6036	Air Filter
1935	ISUZU	FVZ 34P 285PS	6HK1-UP			TRUCKS	A-6037	Air Filter
1936	ISUZU	FXR - ISUZU 6HK1TC 2003 -2004	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
1937	ISUZU	GHCJ3 - ISUZU F20B 1999	Engine: N/A			TRUCKS	C-1605	Oil Filter
1938	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
1939	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
1940	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
1941	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
1942	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
1943	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
1944	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
1945	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
1946	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
1947	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
1948	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
1949	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	10PE1			TRUCKS	O-1532	Oil Filter
1950	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	10PE1			TRUCKS	O-1532	Oil Filter
1951	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	10PE1			TRUCKS	O-1532	Oil Filter
1952	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	10PE1			TRUCKS	O-1532	Oil Filter
1953	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6SD1-T			TRUCKS	A-6014	Air Filter
1954	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
1955	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6SD1-T			TRUCKS	O-1530	Oil Filter
1956	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6SD1-T			TRUCKS	O-1532	Oil Filter
1957	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6UZ1-T			TRUCKS	A-6014	Air Filter
1958	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6UZ1-T			TRUCKS	A-6014	Air Filter
1959	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6UZ1-T			TRUCKS	A-6014	Air Filter
1960	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6UZ1-T			TRUCKS	A-6014	Air Filter



Sakura Filter					ENGINE APPLICATION			
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
1961	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6UZ1-T			TRUCKS	F-1503	Fuel Filter
1962	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6UZ1-T			TRUCKS	F-1503	Fuel Filter
1963	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6UZ1-T			TRUCKS	O-1530	Oil Filter
1964	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6UZ1-T			TRUCKS	O-1530	Oil Filter
1965	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6UZ1-T			TRUCKS	O-1530	Oil Filter
1966	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6UZ1-T			TRUCKS	O-1532	Oil Filter
1967	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6UZ1-T			TRUCKS	O-1532	Oil Filter
1968	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6UZ1-T			TRUCKS	O-1532	Oil Filter
1969	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6UZ1-T			TRUCKS	O-1532	Oil Filter
1970	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6WF1-T			TRUCKS	A-6014	Air Filter
1971	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6WF1-T			TRUCKS	F-1503	Fuel Filter
1972	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6WF1-T			TRUCKS	O-1532	Oil Filter
1973	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6WG1-T			TRUCKS	A-6018	Air Filter
1974	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6WG1-T			TRUCKS	A-6018	Air Filter
1975	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6WG1-T			TRUCKS	A-6018	Air Filter
1976	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6WG1-T			TRUCKS	F-1503	Fuel Filter
1977	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6WG1-T			TRUCKS	F-1503	Fuel Filter
1978	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6WG1-T			TRUCKS	O-1530	Oil Filter
1979	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
1980	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
1981	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
1982	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	8PE1			TRUCKS	A-6014	Air Filter
1983	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	8PE1			TRUCKS	A-6014	Air Filter
1984	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	8PE1			TRUCKS	A-6014	Air Filter
1985	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	8PE1			TRUCKS	F-1503	Fuel Filter
1986	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	8PE1			TRUCKS	F-1503	Fuel Filter
1987	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	8PE1			TRUCKS	F-1503	Fuel Filter
1988	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	8PE1			TRUCKS	O-1532	Oil Filter
1989	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	8PE1			TRUCKS	O-1532	Oil Filter
1990	ISUZU	GIGA C V# / C X #/ C Y# TRUCK	8PE1			TRUCKS	O-1532	Oil Filter
1991	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	KL-CXZ80 [ 8PE1 ]	2000		TRUCKS	A-6014	Air Filter
1992	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	KL-CXZ80 [ 8PE1 ]	2000		TRUCKS	O-1527	Oil Filter
1993	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	KL-CXZ81 [ 10PE1 ]	2000		TRUCKS	A-6014	Air Filter
1994	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	KL-CXZ81 [ 10PE1 ]	2000		TRUCKS	O-1522	Oil Filter
1995	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	KL-CXZ81 [ 10PE1 ]	2000		TRUCKS	O-1529	Oil Filter
1996	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	KL-CYZ81 [ 10PE1 ]	2000		TRUCKS	A-6014	Air Filter
1997	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	KL-CYZ81 [ 10PE1 ]	2000		TRUCKS	O-1522	Oil Filter
1998	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	KL-CYZ81 [ 10PE1 ]	2000		TRUCKS	O-1529	Oil Filter
1999	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KF-CYZ52 [ 6WG1(T) ]	2000		TRUCKS	A-6018	Air Filter
2000	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KF-CYZ52 [ 6WG1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2001	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KF-CYZ52 [ 6WG1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2002	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CXY23 [ 6SD1(T) ]	2000		TRUCKS	A-6014	Air Filter
2003	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CXY23 [ 6SD1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2004	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CXY23 [ 6SD1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2005	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CXY51 [ 6VVF1(T) ]	2000		TRUCKS	A-6014	Air Filter
2006	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CXY51 [ 6VVF1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2007	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CXY51 [ 6VVF1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2008	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CXZ51 [ 6WF1(T) ]	2000		TRUCKS	A-6014	Air Filter
2009	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CXZ51 [ 6WF1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2010	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CXZ51 [ 6WF1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2011	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CXZ52 [ 6WG1(T) ]	2000		TRUCKS	A-6018	Air Filter
2012	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CXZ52 [ 6WG1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2013	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CXZ52 [ 6WG1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2014	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CYY23 [ 6SD1(T) ]	2000		TRUCKS	A-6014	Air Filter
2015	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CYY23 [ 6SD1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2016	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CYY23 [ 6SD1(T) ]	2000		TRUCKS	O-1529	Oil Filter

Sakura Filter					ENGINE APPLICATION			
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
2017	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CYY51 [ 6VVF1(T) ]	2000		TRUCKS	A-6014	Air Filter
2018	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CYY51 [ 6VVF1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2019	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CYY51 [ 6VVF1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2020	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CYY52 [ 6WG1(T) ]	2000		TRUCKS	A-6018	Air Filter
2021	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CYY52 [ 6WG1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2022	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CYY52 [ 6WG1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2023	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CYZ23 [ 6SD1(T) ]	2000		TRUCKS	A-6014	Air Filter
2024	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CYZ23 [ 6SD1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2025	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CYZ23 [ 6SD1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2026	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CYZ51 [ 6WF1(T) ]	2000		TRUCKS	A-6014	Air Filter
2027	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CYZ51 [ 6WF1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2028	ISUZU	GIGA CV# CX# CY# [ 00/01 - ]	TURBO KL-CYZ51 [ 6WF1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2029	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	ALL WHEEL DRIVE KL-CVS81 [ 10PE1 ]	2000		TRUCKS	A-6014	Air Filter
2030	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	ALL WHEEL DRIVE KL-CVS81 [ 10PE1 ]	2000		TRUCKS	O-1522	Oil Filter
2031	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	ALL WHEEL DRIVE KL-CVS81 [ 10PE1 ]	2000		TRUCKS	O-1529	Oil Filter
2032	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	ALL WHEEL DRIVE KL-CXW81 [ 10PE1 ]	2000		TRUCKS	A-6014	Air Filter
2033	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	ALL WHEEL DRIVE KL-CXW81 [ 10PE1 ]	2000		TRUCKS	O-1522	Oil Filter
2034	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	ALL WHEEL DRIVE KL-CXW81 [ 10PE1 ]	2000		TRUCKS	O-1529	Oil Filter
2035	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	KL-CYG81 [ 10PE1 ]	2000		TRUCKS	A-6014	Air Filter
2036	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	KL-CYG81 [ 10PE1 ]	2000		TRUCKS	O-1522	Oil Filter
2037	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	KL-CYG81 [ 10PE1 ]	2000		TRUCKS	O-1529	Oil Filter
2038	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	KL-CYH81 [ 10PE1 ]	2000		TRUCKS	A-6014	Air Filter
2039	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	KL-CYH81 [ 10PE1 ]	2000		TRUCKS	O-1522	Oil Filter
2040	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	KL-CYH81 [ 10PE1 ]	2000		TRUCKS	O-1529	Oil Filter
2041	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	KL-CYJ81 [ 10PE1 ]	2000		TRUCKS	A-6014	Air Filter
2042	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	KL-CYJ81 [ 10PE1 ]	2000		TRUCKS	O-1522	Oil Filter
2043	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	KL-CYJ81 [ 10PE1 ]	2000		TRUCKS	O-1529	Oil Filter
2044	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CXG23 [ 6SD1(T) ]	2000		TRUCKS	A-6014	Air Filter
2045	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CXG23 [ 6SD1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2046	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CXG23 [ 6SD1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2047	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CXG51 [ 6WF1(T) ]	2000		TRUCKS	A-6014	Air Filter
2048	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CXG51 [ 6WF1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2049	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CXG51 [ 6WF1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2050	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CXH23 [ 6SD1(T) ]	2000		TRUCKS	A-6014	Air Filter
2051	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CXH23 [ 6SD1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2052	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CXH23 [ 6SD1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2053	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CXH51 [ 6VVF1(T) ]	2000		TRUCKS	A-6014	Air Filter
2054	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CXH51 [ 6VVF1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2055	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CXH51 [ 6VVF1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2056	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYG51 [ 6WF1(T) ]	2000		TRUCKS	A-6014	Air Filter
2057	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYG51 [ 6WF1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2058	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYG51 [ 6WF1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2059	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYH23 [ 6SD1(T) ]	2000		TRUCKS	A-6014	Air Filter
2060	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYH23 [ 6SD1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2061	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYH23 [ 6SD1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2062	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYH51 [ 6WF1(T) ]	2000		TRUCKS	A-6014	Air Filter
2063	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYH51 [ 6WF1(T) ]	2000		TRUCKS	O-1522	Oil Filter

Sakura Filter					ENGINE APPLICATION			
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
2064	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYH51 [ 6WF1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2065	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYH52 [ 6WG1(T) ]	2000		TRUCKS	A-6018	Air Filter
2066	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYH52 [ 6WG1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2067	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYH52 [ 6WG1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2068	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYJ23 [ 6SD1(T) ]	2000		TRUCKS	A-6014	Air Filter
2069	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYJ23 [ 6SD1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2070	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYJ23 [ 6SD1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2071	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYJ51 [ 6WF1(T) ]	2000		TRUCKS	A-6014	Air Filter
2072	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYJ51 [ 6WF1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2073	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYJ51 [ 6WF1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2074	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYJ52 [ 6WG1(T) ]	2000		TRUCKS	A-6018	Air Filter
2075	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYJ52 [ 6WG1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2076	ISUZU	GIGA CV# CX# CY# [ 00/04 - ]	TURBO KL-CYJ52 [ 6WG1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2077	ISUZU	GIGA CV# CX# CY# [ 00/05 - ]	KL-CVR80 [ 8PE1 ]	2000		TRUCKS	A-6014	Air Filter
2078	ISUZU	GIGA CV# CX# CY# [ 00/05 - ]	KL-CVR80 [ 8PE1 ]	2000		TRUCKS	O-1529	Oil Filter
2079	ISUZU	GIGA CV# CX# CY# [ 00/05 - ]	TURBO KL-CYG23 [ 6SD1(T) ]	2000		TRUCKS	A-6014	Air Filter
2080	ISUZU	GIGA CV# CX# CY# [ 00/05 - ]	TURBO KL-CYG23 [ 6SD1(T) ]	2000		TRUCKS	O-1522	Oil Filter
2081	ISUZU	GIGA CV# CX# CY# [ 00/05 - ]	TURBO KL-CYG23 [ 6SD1(T) ]	2000		TRUCKS	O-1529	Oil Filter
2082	ISUZU	GIGA CV# CX# CY# [ 00/06 - ]	ALL WHEEL DRIVE KL-CYW81 [ 10PE1 ]	2000		TRUCKS	A-6014	Air Filter
2083	ISUZU	GIGA CV# CX# CY# [ 00/06 - ]	ALL WHEEL DRIVE KL-CYW81 [ 10PE1 ]	2000		TRUCKS	O-1522	Oil Filter
2084	ISUZU	GIGA CV# CX# CY# [ 00/06 - ]	ALL WHEEL DRIVE KL-CYW81 [ 10PE1 ]	2000		TRUCKS	O-1529	Oil Filter
2085	ISUZU	GIGA CV# CX# CY# [ 00/06 - ]	KL-CXZ74 [ 8TD1 ]	2000		TRUCKS	A-6018	Air Filter
2086	ISUZU	GIGA CV# CX# CY# [ 00/06 - ]	KL-CXZ74 [ 8TD1 ]	2000		TRUCKS	O-1522	Oil Filter
2087	ISUZU	GIGA CV# CX# CY# [ 00/06 - ]	KL-CXZ74 [ 8TD1 ]	2000		TRUCKS	O-1529	Oil Filter
2088	ISUZU	GIGA CV# CX# CY# [ 00/06 - ]	KL-CYW74 [ 8TD1 ]	2000		TRUCKS	A-6018	Air Filter
2089	ISUZU	GIGA CV# CX# CY# [ 00/06 - ]	KL-CYW74 [ 8TD1 ]	2000		TRUCKS	O-1522	Oil Filter
2090	ISUZU	GIGA CV# CX# CY# [ 00/06 - ]	KL-CYW74 [ 8TD1 ]	2000		TRUCKS	O-1529	Oil Filter
2091	ISUZU	GIGA CV# CX# CY# [ 00/06 - ]	KL-CYZ74 [ 8TD1 ]	2000		TRUCKS	A-6018	Air Filter
2092	ISUZU	GIGA CV# CX# CY# [ 00/06 - ]	KL-CYZ74 [ 8TD1 ]	2000		TRUCKS	O-1522	Oil Filter
2093	ISUZU	GIGA CV# CX# CY# [ 00/06 - ]	KL-CYZ74 [ 8TD1 ]	2000		TRUCKS	O-1529	Oil Filter
2094	ISUZU	GIGA CV# CX# CY# [ 00/12 - ]	KL-CXM73 [ 6TE1 ]	2000		TRUCKS	A-6014	Air Filter
2095	ISUZU	GIGA CV# CX# CY# [ 00/12 - ]	KL-CXM73 [ 6TE1 ]	2000		TRUCKS	O-1522	Oil Filter
2096	ISUZU	GIGA CV# CX# CY# [ 00/12 - ]	KL-CXM73 [ 6TE1 ]	2000		TRUCKS	O-1529	Oil Filter
2097	ISUZU	GIGA CV# CX# CY# [ 00/12 - ]	KL-CYM73 [ 6TE1 ]	2000		TRUCKS	A-6014	Air Filter
2098	ISUZU	GIGA CV# CX# CY# [ 00/12 - ]	KL-CYM73 [ 6TE1 ]	2000		TRUCKS	O-1522	Oil Filter
2099	ISUZU	GIGA CV# CX# CY# [ 00/12 - ]	KL-CYM73 [ 6TE1 ]	2000		TRUCKS	O-1529	Oil Filter
2100	ISUZU	GIGA CV# CX# CY# [ 00/12 - ]	KL-CYZ73 [ 6TE1 ]	2000		TRUCKS	A-6014	Air Filter
2101	ISUZU	GIGA CV# CX# CY# [ 00/12 - ]	KL-CYZ73 [ 6TE1 ]	2000		TRUCKS	O-1522	Oil Filter
2102	ISUZU	GIGA CV# CX# CY# [ 00/12 - ]	KL-CYZ73 [ 6TE1 ]	2000		TRUCKS	O-1529	Oil Filter
2103	ISUZU	GIGA CV# CX# CY# [ 00/12 - ]	TURBO KL-CYL73 [ 6TE1 ]	2000		TRUCKS	A-6014	Air Filter
2104	ISUZU	GIGA CV# CX# CY# [ 00/12 - ]	TURBO KL-CYL73 [ 6TE1 ]	2000		TRUCKS	O-1522	Oil Filter
2105	ISUZU	GIGA CV# CX# CY# [ 00/12 - ]	TURBO KL-CYL73 [ 6TE1 ]	2000		TRUCKS	O-1529	Oil Filter
2106	ISUZU	GIGA CV# CX# CY# [ 01/01 - ]	KL-CXZ73 [ 6TE1-S ]	2001		TRUCKS	A-6014	Air Filter
2107	ISUZU	GIGA CV# CX# CY# [ 01/01 - ]	KL-CXZ73 [ 6TE1-S ]	2001		TRUCKS	O-1522	Oil Filter
2108	ISUZU	GIGA CV# CX# CY# [ 01/01 - ]	KL-CXZ73 [ 6TE1-S ]	2001		TRUCKS	O-1529	Oil Filter
2109	ISUZU	GIGA CV# CX# CY# [ 01/05 - ]	TURBO SHORT CAB KL-CXG23 [ 6SD1(T) ]	2001		TRUCKS	O-1522	Oil Filter
2110	ISUZU	GIGA CV# CX# CY# [ 01/05 - ]	TURBO SHORT CAB KL-CXG23 [ 6SD1(T) ]	2001		TRUCKS	O-1529	Oil Filter
2111	ISUZU	GIGA CV# CX# CY# [ 01/05 - ]	TURBO SHORT CAB KL-CYG23 [ 6SD1(T) ]	2001		TRUCKS	O-1522	Oil Filter
2112	ISUZU	GIGA CV# CX# CY# [ 01/05 - ]	TURBO SHORT CAB KL-CYG23 [ 6SD1(T) ]	2001		TRUCKS	O-1529	Oil Filter
2113	ISUZU	GIGA CV# CX# CY# [ 01/05 - ]	TURBO SHORT CAB KL-CYJ23 [ 6SD1(T) ]	2001		TRUCKS	O-1522	Oil Filter
2114	ISUZU	GIGA CV# CX# CY# [ 01/05 - ]	TURBO SHORT CAB KL-CYJ23 [ 6SD1(T) ]	2001		TRUCKS	O-1529	Oil Filter

Sakura Filter				ENGINE APPLICATION				
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
2115	ISUZU	GIGA CV# CX# CY# [ 01/05 - ]	TURBO SHROT CAB KL-CYL23 [ 6SD1(T) ]	2001		TRUCKS	O-1522	Oil Filter
2116	ISUZU	GIGA CV# CX# CY# [ 01/05 - ]	TURBO SHROT CAB KL-CYL23 [ 6SD1(T) ]	2001		TRUCKS	O-1529	Oil Filter
2117	ISUZU	GIGA CV# CX# CY# [ 94/09 - ]	KC-CYZ81 [ 10PE1 ]	1994		TRUCKS	A-6014	Air Filter
2118	ISUZU	GIGA CV# CX# CY# [ 94/09 - ]	KC-CYZ81 [ 10PE1 ]	1994		TRUCKS	O-1522	Oil Filter
2119	ISUZU	GIGA CV# CX# CY# [ 94/09 - ]	KC-CYZ81 [ 10PE1 ]	1994		TRUCKS	O-1529	Oil Filter
2120	ISUZU	GIGA CV# CX# CY# [ 94/09 - ]	KC-CYZ82 [ 12PE1 ]	1994		TRUCKS	A-6014	Air Filter
2121	ISUZU	GIGA CV# CX# CY# [ 94/09 - ]	KC-CYZ82 [ 12PE1 ]	1994		TRUCKS	O-1521	Oil Filter
2122	ISUZU	GIGA CV# CX# CY# [ 94/09 - ]	KC-CYZ82 [ 12PE1 ]	1994		TRUCKS	O-1529	Oil Filter
2123	ISUZU	GIGA CV# CX# CY# [ 94/09 - ]	TURBO KC-CYZ50 [ 6WA1(T) ]	1994		TRUCKS	A-6014	Air Filter
2124	ISUZU	GIGA CV# CX# CY# [ 94/09 - ]	TURBO KC-CYZ50 [ 6WA1(T) ]	1994		TRUCKS	O-1522	Oil Filter
2125	ISUZU	GIGA CV# CX# CY# [ 94/09 - ]	TURBO KC-CYZ50 [ 6WA1(T) ]	1994		TRUCKS	O-1529	Oil Filter
2126	ISUZU	GIGA CV# CX# CY# [ 94/09 - 00/01 ]	KC-CXZ80 [ 8PE1 ]	1994	2000	TRUCKS	A-6014	Air Filter
2127	ISUZU	GIGA CV# CX# CY# [ 94/09 - 00/01 ]	KC-CXZ80 [ 8PE1 ]	1994	2000	TRUCKS	O-1527	Oil Filter
2128	ISUZU	GIGA CV# CX# CY# [ 94/09 - 99/10 ]	KC-CXZ82 [ 12PE1 ]	1994	1999	TRUCKS	A-6014	Air Filter
2129	ISUZU	GIGA CV# CX# CY# [ 94/09 - 99/10 ]	KC-CXZ82 [ 12PE1 ]	1994	1999	TRUCKS	O-1521	Oil Filter
2130	ISUZU	GIGA CV# CX# CY# [ 94/09 - 99/10 ]	KC-CXZ82 [ 12PE1 ]	1994	1999	TRUCKS	O-1529	Oil Filter
2131	ISUZU	GIGA CV# CX# CY# [ 94/09 - 99/11 ]	KC-CXZ81 [ 10PE1 ]	1994	1999	TRUCKS	A-6014	Air Filter
2132	ISUZU	GIGA CV# CX# CY# [ 94/09 - 99/11 ]	KC-CXZ81 [ 10PE1 ]	1994	1999	TRUCKS	O-1522	Oil Filter
2133	ISUZU	GIGA CV# CX# CY# [ 94/09 - 99/11 ]	KC-CXZ81 [ 10PE1 ]	1994	1999	TRUCKS	O-1529	Oil Filter
2134	ISUZU	GIGA CV# CX# CY# [ 94/09 - 99/11 ]	TURBO KC-CXZ50 [ 6WA1(T) ]	1994	1999	TRUCKS	A-6014	Air Filter
2135	ISUZU	GIGA CV# CX# CY# [ 94/09 - 99/11 ]	TURBO KC-CXZ50 [ 6WA1(T) ]	1994	1999	TRUCKS	O-1522	Oil Filter
2136	ISUZU	GIGA CV# CX# CY# [ 94/09 - 99/11 ]	TURBO KC-CXZ50 [ 6WA1(T) ]	1994	1999	TRUCKS	O-1529	Oil Filter
2137	ISUZU	GIGA CV# CX# CY# [ 94/10 - ]	KC-CXM82 [ 12PE1 ]	1994		TRUCKS	A-6014	Air Filter
2138	ISUZU	GIGA CV# CX# CY# [ 94/10 - ]	KC-CXM82 [ 12PE1 ]	1994		TRUCKS	O-1521	Oil Filter
2139	ISUZU	GIGA CV# CX# CY# [ 94/10 - ]	KC-CXM82 [ 12PE1 ]	1994		TRUCKS	O-1529	Oil Filter
2140	ISUZU	GIGA CV# CX# CY# [ 94/10 - ]	KC-CYM81 [ 10PE1 ]	1994		TRUCKS	A-6014	Air Filter
2141	ISUZU	GIGA CV# CX# CY# [ 94/10 - ]	KC-CYM81 [ 10PE1 ]	1994		TRUCKS	O-1522	Oil Filter
2142	ISUZU	GIGA CV# CX# CY# [ 94/10 - ]	KC-CYM81 [ 10PE1 ]	1994		TRUCKS	O-1529	Oil Filter
2143	ISUZU	GIGA CV# CX# CY# [ 94/10 - ]	KC-CYM82 [ 12PE1 ]	1994		TRUCKS	A-6014	Air Filter
2144	ISUZU	GIGA CV# CX# CY# [ 94/10 - ]	KC-CYM82 [ 12PE1 ]	1994		TRUCKS	O-1521	Oil Filter
2145	ISUZU	GIGA CV# CX# CY# [ 94/10 - ]	KC-CYM82 [ 12PE1 ]	1994		TRUCKS	O-1529	Oil Filter
2146	ISUZU	GIGA CV# CX# CY# [ 94/10 - ]	TURBO KC-CYM50 [ 6WA1(T) ]	1994		TRUCKS	A-6014	Air Filter
2147	ISUZU	GIGA CV# CX# CY# [ 94/10 - ]	TURBO KC-CYM50 [ 6WA1(T) ]	1994		TRUCKS	O-1522	Oil Filter
2148	ISUZU	GIGA CV# CX# CY# [ 94/10 - ]	TURBO KC-CYM50 [ 6WA1(T) ]	1994		TRUCKS	O-1529	Oil Filter
2149	ISUZU	GIGA CV# CX# CY# [ 94/10 - 99/11 ]	KC-CXM80 [ 8PE1 ]	1994	1999	TRUCKS	A-6014	Air Filter
2150	ISUZU	GIGA CV# CX# CY# [ 94/10 - 99/11 ]	KC-CXM80 [ 8PE1 ]	1994	1999	TRUCKS	O-1529	Oil Filter
2151	ISUZU	GIGA CV# CX# CY# [ 94/10 - 99/11 ]	KC-CXM81 [ 10PE1 ]	1994	1999	TRUCKS	A-6014	Air Filter
2152	ISUZU	GIGA CV# CX# CY# [ 94/10 - 99/11 ]	KC-CXM81 [ 10PE1 ]	1994	1999	TRUCKS	O-1522	Oil Filter
2153	ISUZU	GIGA CV# CX# CY# [ 94/10 - 99/11 ]	KC-CXM81 [ 10PE1 ]	1994	1999	TRUCKS	O-1529	Oil Filter
2154	ISUZU	GIGA CV# CX# CY# [ 94/10 - 99/11 ]	TURBO KC-CXM23 [ 6SD1(T) ]	1994	1999	TRUCKS	A-6014	Air Filter
2155	ISUZU	GIGA CV# CX# CY# [ 94/10 - 99/11 ]	TURBO KC-CXM23 [ 6SD1(T) ]	1994	1999	TRUCKS	O-1522	Oil Filter
2156	ISUZU	GIGA CV# CX# CY# [ 94/10 - 99/11 ]	TURBO KC-CXM23 [ 6SD1(T) ]	1994	1999	TRUCKS	O-1529	Oil Filter
2157	ISUZU	GIGA CV# CX# CY# [ 94/10 - 99/11 ]	TURBO KC-CXM50 [ 6WA1(T) ]	1994	1999	TRUCKS	A-6014	Air Filter
2158	ISUZU	GIGA CV# CX# CY# [ 94/10 - 99/11 ]	TURBO KC-CXM50 [ 6WA1(T) ]	1994	1999	TRUCKS	O-1522	Oil Filter
2159	ISUZU	GIGA CV# CX# CY# [ 94/10 - 99/11 ]	TURBO KC-CXM50 [ 6WA1(T) ]	1994	1999	TRUCKS	O-1529	Oil Filter
2160	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CXG80 [ 8PE1 ]	1994		TRUCKS	A-6014	Air Filter
2161	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CXG80 [ 8PE1 ]	1994		TRUCKS	O-1529	Oil Filter
2162	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CXG81 [ 10PE1 ]	1994		TRUCKS	A-6014	Air Filter
2163	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CXG81 [ 10PE1 ]	1994		TRUCKS	O-1522	Oil Filter
2164	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CXG81 [ 10PE1 ]	1994		TRUCKS	O-1529	Oil Filter
2165	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CXH81 [ 10PE1 ]	1994		TRUCKS	A-6014	Air Filter
2166	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CXH81 [ 10PE1 ]	1994		TRUCKS	O-1522	Oil Filter
2167	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CXH81 [ 10PE1 ]	1994		TRUCKS	O-1529	Oil Filter
2168	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CXH82 [ 12PE1 ]	1994		TRUCKS	A-6014	Air Filter
2169	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CXH82 [ 12PE1 ]	1994		TRUCKS	O-1521	Oil Filter
2170	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CXH82 [ 12PE1 ]	1994		TRUCKS	O-1529	Oil Filter
2171	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CYG81 [ 10PE1 ]	1994		TRUCKS	A-6014	Air Filter



Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
2172	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CYG81 [ 10PE1 ]	1994		TRUCKS	O-1522	Oil Filter
2173	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CYG81 [ 10PE1 ]	1994		TRUCKS	O-1529	Oil Filter
2174	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CYH81 [ 10PE1 ]	1994		TRUCKS	A-6014	Air Filter
2175	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CYH81 [ 10PE1 ]	1994		TRUCKS	O-1522	Oil Filter
2176	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CYH81 [ 10PE1 ]	1994		TRUCKS	O-1529	Oil Filter
2177	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CYH82 [ 12PE1 ]	1994		TRUCKS	A-6014	Air Filter
2178	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CYH82 [ 12PE1 ]	1994		TRUCKS	O-1521	Oil Filter
2179	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	KC-CYH82 [ 12PE1 ]	1994		TRUCKS	O-1529	Oil Filter
2180	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	TURBO KC-CXH23 [ 6SD1(T) ]	1994		TRUCKS	A-6014	Air Filter
2181	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	TURBO KC-CXH23 [ 6SD1(T) ]	1994		TRUCKS	O-1522	Oil Filter
2182	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	TURBO KC-CXH23 [ 6SD1(T) ]	1994		TRUCKS	O-1529	Oil Filter
2183	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	TURBO KC-CYG50 [ 6WA1(T) ]	1994		TRUCKS	A-6014	Air Filter
2184	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	TURBO KC-CYG50 [ 6WA1(T) ]	1994		TRUCKS	O-1522	Oil Filter
2185	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	TURBO KC-CYG50 [ 6WA1(T) ]	1994		TRUCKS	O-1529	Oil Filter
2186	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	TURBO KC-CYH50 [ 6WA1(T) ]	1994		TRUCKS	A-6014	Air Filter
2187	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	TURBO KC-CYH50 [ 6WA1(T) ]	1994		TRUCKS	O-1522	Oil Filter
2188	ISUZU	GIGA CV# CX# CY# [ 94/12 - ]	TURBO KC-CYH50 [ 6WA1(T) ]	1994		TRUCKS	O-1529	Oil Filter
2189	ISUZU	GIGA CV# CX# CY# [ 94/12 - 00/04 ]	TURBO KC-CXG23 [ 6SD1(T) ]	1994	2000	TRUCKS	A-6014	Air Filter
2190	ISUZU	GIGA CV# CX# CY# [ 94/12 - 00/04 ]	TURBO KC-CXG23 [ 6SD1(T) ]	1994	2000	TRUCKS	O-1522	Oil Filter
2191	ISUZU	GIGA CV# CX# CY# [ 94/12 - 00/04 ]	TURBO KC-CXG23 [ 6SD1(T) ]	1994	2000	TRUCKS	O-1529	Oil Filter
2192	ISUZU	GIGA CV# CX# CY# [ 94/12 - 00/04 ]	TURBO KC-CYG23 [ 6SD1(T) ]	1994	2000	TRUCKS	A-6014	Air Filter
2193	ISUZU	GIGA CV# CX# CY# [ 94/12 - 00/04 ]	TURBO KC-CYG23 [ 6SD1(T) ]	1994	2000	TRUCKS	O-1522	Oil Filter
2194	ISUZU	GIGA CV# CX# CY# [ 94/12 - 00/04 ]	TURBO KC-CYG23 [ 6SD1(T) ]	1994	2000	TRUCKS	O-1529	Oil Filter
2195	ISUZU	GIGA CV# CX# CY# [ 94/12 - 97/06 ]	KC-CXG82 [ 12PE1 ]	1994	1997	TRUCKS	A-6014	Air Filter
2196	ISUZU	GIGA CV# CX# CY# [ 94/12 - 97/06 ]	KC-CXG82 [ 12PE1 ]	1994	1997	TRUCKS	O-1521	Oil Filter
2197	ISUZU	GIGA CV# CX# CY# [ 94/12 - 97/06 ]	KC-CXG82 [ 12PE1 ]	1994	1997	TRUCKS	O-1529	Oil Filter
2198	ISUZU	GIGA CV# CX# CY# [ 94/12 - 99/11 ]	TURBO KC-CXG50 [ 6WA1(T) ]	1994	1999	TRUCKS	A-6014	Air Filter
2199	ISUZU	GIGA CV# CX# CY# [ 94/12 - 99/11 ]	TURBO KC-CXG50 [ 6WA1(T) ]	1994	1999	TRUCKS	O-1522	Oil Filter
2200	ISUZU	GIGA CV# CX# CY# [ 94/12 - 99/11 ]	TURBO KC-CXG50 [ 6WA1(T) ]	1994	1999	TRUCKS	O-1529	Oil Filter
2201	ISUZU	GIGA CV# CX# CY# [ 94/12 - 99/11 ]	TURBO KC-CXH50 [ 6WA1(T) ]	1994	1999	TRUCKS	A-6014	Air Filter
2202	ISUZU	GIGA CV# CX# CY# [ 94/12 - 99/11 ]	TURBO KC-CXH50 [ 6WA1(T) ]	1994	1999	TRUCKS	O-1522	Oil Filter
2203	ISUZU	GIGA CV# CX# CY# [ 94/12 - 99/11 ]	TURBO KC-CXH50 [ 6WA1(T) ]	1994	1999	TRUCKS	O-1529	Oil Filter
2204	ISUZU	GIGA CV# CX# CY# [ 95/03 - 00/05 ]	KC-CVR80 [ 8PE1 ]	1995	2000	TRUCKS	A-6014	Air Filter
2205	ISUZU	GIGA CV# CX# CY# [ 95/03 - 00/05 ]	KC-CVR80 [ 8PE1 ]	1995	2000	TRUCKS	O-1529	Oil Filter
2206	ISUZU	GIGA CV# CX# CY# [ 95/04 - ]	KC-CVZ80 [ 8PE1 ]	1995		TRUCKS	A-6014	Air Filter
2207	ISUZU	GIGA CV# CX# CY# [ 95/04 - ]	KC-CVZ80 [ 8PE1 ]	1995		TRUCKS	O-1529	Oil Filter
2208	ISUZU	GIGA CV# CX# CY# [ 95/04 - ]	KC-CVZ81 [ 10PE1 ]	1995		TRUCKS	A-6014	Air Filter
2209	ISUZU	GIGA CV# CX# CY# [ 95/04 - ]	KC-CVZ81 [ 10PE1 ]	1995		TRUCKS	O-1522	Oil Filter
2210	ISUZU	GIGA CV# CX# CY# [ 95/04 - ]	KC-CVZ81 [ 10PE1 ]	1995		TRUCKS	O-1529	Oil Filter
2211	ISUZU	GIGA CV# CX# CY# [ 95/04 - ]	KC-CXK81 [ 10PE1 ]	1995		TRUCKS	A-6014	Air Filter
2212	ISUZU	GIGA CV# CX# CY# [ 95/04 - ]	KC-CXK81 [ 10PE1 ]	1995		TRUCKS	O-1522	Oil Filter
2213	ISUZU	GIGA CV# CX# CY# [ 95/04 - ]	KC-CXK81 [ 10PE1 ]	1995		TRUCKS	O-1529	Oil Filter
2214	ISUZU	GIGA CV# CX# CY# [ 95/04 - ]	TURBO KC-CXK23 [ 6SD1(T) ]	1995		TRUCKS	A-6014	Air Filter
2215	ISUZU	GIGA CV# CX# CY# [ 95/04 - ]	TURBO KC-CXK23 [ 6SD1(T) ]	1995		TRUCKS	O-1522	Oil Filter
2216	ISUZU	GIGA CV# CX# CY# [ 95/04 - ]	TURBO KC-CXK23 [ 6SD1(T) ]	1995		TRUCKS	O-1529	Oil Filter
2217	ISUZU	GIGA CV# CX# CY# [ 95/04 - 99/11 ]	TURBO KC-CXK50 [ 6WA1(T) ]	1995	1999	TRUCKS	A-6014	Air Filter
2218	ISUZU	GIGA CV# CX# CY# [ 95/04 - 99/11 ]	TURBO KC-CXK50 [ 6WA1(T) ]	1995	1999	TRUCKS	O-1522	Oil Filter
2219	ISUZU	GIGA CV# CX# CY# [ 95/04 - 99/11 ]	TURBO KC-CXK50 [ 6WA1(T) ]	1995	1999	TRUCKS	O-1529	Oil Filter
2220	ISUZU	GIGA CV# CX# CY# [ 95/04 - 99/11 ]	TURBO KC-CXL50 [ 6WA1(T) ]	1995	1999	TRUCKS	A-6014	Air Filter
2221	ISUZU	GIGA CV# CX# CY# [ 95/04 - 99/11 ]	TURBO KC-CXL50 [ 6WA1(T) ]	1995	1999	TRUCKS	O-1522	Oil Filter
2222	ISUZU	GIGA CV# CX# CY# [ 95/04 - 99/11 ]	TURBO KC-CXL50 [ 6WA1(T) ]	1995	1999	TRUCKS	O-1529	Oil Filter



Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
2223	ISUZU	GIGA CV# CX# CY# [ 95/05 - 97/03 ]	ALL WHEEL DRIVE KC-CVS81 [ 10PE1 ]	1995	1997	TRUCKS	A-1828	Air Filter
2224	ISUZU	GIGA CV# CX# CY# [ 95/05 - 97/03 ]	ALL WHEEL DRIVE KC-CVS81 [ 10PE1 ]	1995	1997	TRUCKS	O-1522	Oil Filter
2225	ISUZU	GIGA CV# CX# CY# [ 95/05 - 97/03 ]	ALL WHEEL DRIVE KC-CVS81 [ 10PE1 ]	1995	1997	TRUCKS	O-1529	Oil Filter
2226	ISUZU	GIGA CV# CX# CY# [ 95/05 - 97/03 ]	ALL WHEEL DRIVE KC-CXW81 [ 10PE1 ]	1995	1997	TRUCKS	A-1828	Air Filter
2227	ISUZU	GIGA CV# CX# CY# [ 95/05 - 97/03 ]	ALL WHEEL DRIVE KC-CXW81 [ 10PE1 ]	1995	1997	TRUCKS	O-1522	Oil Filter
2228	ISUZU	GIGA CV# CX# CY# [ 95/05 - 97/03 ]	ALL WHEEL DRIVE KC-CXW81 [ 10PE1 ]	1995	1997	TRUCKS	O-1529	Oil Filter
2229	ISUZU	GIGA CV# CX# CY# [ 95/05 - 97/03 ]	ALL WHEEL DRIVE KC-CYW81 [ 10PE1 ]	1995	1997	TRUCKS	A-1828	Air Filter
2230	ISUZU	GIGA CV# CX# CY# [ 95/05 - 97/03 ]	ALL WHEEL DRIVE KC-CYW81 [ 10PE1 ]	1995	1997	TRUCKS	O-1522	Oil Filter
2231	ISUZU	GIGA CV# CX# CY# [ 95/05 - 97/03 ]	ALL WHEEL DRIVE KC-CYW81 [ 10PE1 ]	1995	1997	TRUCKS	O-1529	Oil Filter
2232	ISUZU	GIGA CV# CX# CY# [ 96/10 - ]	TURBO KC-CYM23 [ 6SD1(T) ]	1996		TRUCKS	A-6014	Air Filter
2233	ISUZU	GIGA CV# CX# CY# [ 96/10 - ]	TURBO KC-CYM23 [ 6SD1(T) ]	1996		TRUCKS	O-1522	Oil Filter
2234	ISUZU	GIGA CV# CX# CY# [ 96/10 - ]	TURBO KC-CYM23 [ 6SD1(T) ]	1996		TRUCKS	O-1529	Oil Filter
2235	ISUZU	GIGA CV# CX# CY# [ 96/11 - ]	TURBO KC-CXZ23 [ 6SD1(T) ]	1996		TRUCKS	A-6014	Air Filter
2236	ISUZU	GIGA CV# CX# CY# [ 96/11 - ]	TURBO KC-CXZ23 [ 6SD1(T) ]	1996		TRUCKS	O-1522	Oil Filter
2237	ISUZU	GIGA CV# CX# CY# [ 96/11 - ]	TURBO KC-CXZ23 [ 6SD1(T) ]	1996		TRUCKS	O-1529	Oil Filter
2238	ISUZU	GIGA CV# CX# CY# [ 96/11 - ]	TURBO KC-CYZ23 [ 6SD1(T) ]	1996		TRUCKS	A-6014	Air Filter
2239	ISUZU	GIGA CV# CX# CY# [ 96/11 - ]	TURBO KC-CYZ23 [ 6SD1(T) ]	1996		TRUCKS	O-1522	Oil Filter
2240	ISUZU	GIGA CV# CX# CY# [ 96/11 - ]	TURBO KC-CYZ23 [ 6SD1(T) ]	1996		TRUCKS	O-1529	Oil Filter
2241	ISUZU	GIGA CV# CX# CY# [ 97/04 - ]	ALL WHEEL DRIVE KC-CVS81 [ 10PE1 ]	1997		TRUCKS	A-6014	Air Filter
2242	ISUZU	GIGA CV# CX# CY# [ 97/04 - ]	ALL WHEEL DRIVE KC-CVS81 [ 10PE1 ]	1997		TRUCKS	O-1522	Oil Filter
2243	ISUZU	GIGA CV# CX# CY# [ 97/04 - ]	ALL WHEEL DRIVE KC-CVS81 [ 10PE1 ]	1997		TRUCKS	O-1529	Oil Filter
2244	ISUZU	GIGA CV# CX# CY# [ 97/04 - ]	ALL WHEEL DRIVE KC-CYW82 [ 12PE1 ]	1997		TRUCKS	A-6014	Air Filter
2245	ISUZU	GIGA CV# CX# CY# [ 97/04 - ]	ALL WHEEL DRIVE KC-CYW82 [ 12PE1 ]	1997		TRUCKS	O-1521	Oil Filter
2246	ISUZU	GIGA CV# CX# CY# [ 97/04 - ]	ALL WHEEL DRIVE KC-CYW82 [ 12PE1 ]	1997		TRUCKS	O-1529	Oil Filter
2247	ISUZU	GIGA CV# CX# CY# [ 97/04 - 00/04 ]	ALL WHEEL DRIVE KC-CXW81 [ 10PE1 ]	1997	2000	TRUCKS	A-6014	Air Filter
2248	ISUZU	GIGA CV# CX# CY# [ 97/04 - 00/04 ]	ALL WHEEL DRIVE KC-CXW81 [ 10PE1 ]	1997	2000	TRUCKS	O-1522	Oil Filter
2249	ISUZU	GIGA CV# CX# CY# [ 97/04 - 00/04 ]	ALL WHEEL DRIVE KC-CXW81 [ 10PE1 ]	1997	2000	TRUCKS	O-1529	Oil Filter
2250	ISUZU	GIGA CV# CX# CY# [ 97/04 - 98/01 ]	ALL WHEEL DRIVE KC-CYW81 [ 10PE1 ]	1997	1998	TRUCKS	A-6014	Air Filter
2251	ISUZU	GIGA CV# CX# CY# [ 97/04 - 98/01 ]	ALL WHEEL DRIVE KC-CYW81 [ 10PE1 ]	1997	1998	TRUCKS	O-1522	Oil Filter
2252	ISUZU	GIGA CV# CX# CY# [ 97/04 - 98/01 ]	ALL WHEEL DRIVE KC-CYW81 [ 10PE1 ]	1997	1998	TRUCKS	O-1529	Oil Filter
2253	ISUZU	GIGA CV# CX# CY# [ 97/05 - ]	KC-CYM80 [ 8PE1 ]	1997		TRUCKS	A-6014	Air Filter
2254	ISUZU	GIGA CV# CX# CY# [ 97/05 - ]	KC-CYM80 [ 8PE1 ]	1997		TRUCKS	O-1529	Oil Filter
2255	ISUZU	GIGA CV# CX# CY# [ 97/05 - ]	TURBO KC-CYG52 [ 6WG1(T) ]	1997		TRUCKS	A-6018	Air Filter
2256	ISUZU	GIGA CV# CX# CY# [ 97/05 - ]	TURBO KC-CYG52 [ 6WG1(T) ]	1997		TRUCKS	O-1522	Oil Filter
2257	ISUZU	GIGA CV# CX# CY# [ 97/05 - ]	TURBO KC-CYG52 [ 6WG1(T) ]	1997		TRUCKS	O-1529	Oil Filter
2258	ISUZU	GIGA CV# CX# CY# [ 97/05 - ]	TURBO KC-CYM52 [ 6WG1(T) ]	1997		TRUCKS	A-6018	Air Filter
2259	ISUZU	GIGA CV# CX# CY# [ 97/05 - ]	TURBO KC-CYM52 [ 6WG1(T) ]	1997		TRUCKS	O-1522	Oil Filter
2260	ISUZU	GIGA CV# CX# CY# [ 97/05 - ]	TURBO KC-CYM52 [ 6WG1(T) ]	1997		TRUCKS	O-1529	Oil Filter
2261	ISUZU	GIGA CV# CX# CY# [ 97/05 - ]	TURBO KC-CYZ52 [ 6WG1(T) ]	1997		TRUCKS	A-6018	Air Filter
2262	ISUZU	GIGA CV# CX# CY# [ 97/05 - ]	TURBO KC-CYZ52 [ 6WG1(T) ]	1997		TRUCKS	O-1522	Oil Filter
2263	ISUZU	GIGA CV# CX# CY# [ 97/05 - ]	TURBO KC-CYZ52 [ 6WG1(T) ]	1997		TRUCKS	O-1529	Oil Filter
2264	ISUZU	GIGA CV# CX# CY# [ 97/07 - ]	TURBO KC-CYL50 [ 6WA1(T) ]	1997		TRUCKS	A-6014	Air Filter
2265	ISUZU	GIGA CV# CX# CY# [ 97/07 - ]	TURBO KC-CYL50 [ 6WA1(T) ]	1997		TRUCKS	O-1522	Oil Filter
2266	ISUZU	GIGA CV# CX# CY# [ 97/07 - ]	TURBO KC-CYL50 [ 6WA1(T) ]	1997		TRUCKS	O-1529	Oil Filter
2267	ISUZU	GIGA CV# CX# CY# [ 97/07 - 00/03 ]	KC-CYJ81 [ 10PE1 ]	1997	2000	TRUCKS	A-6014	Air Filter
2268	ISUZU	GIGA CV# CX# CY# [ 97/07 - 00/03 ]	KC-CYJ81 [ 10PE1 ]	1997	2000	TRUCKS	O-1522	Oil Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
2269	ISUZU	GIGA CV# CX# CY# [ 97/07 - 00/03 ]	KC-CYJ81 [ 10PE1 ]	1997	2000	TRUCKS	O-1529	Oil Filter
2270	ISUZU	GIGA CV# CX# CY# [ 97/07 - 00/03 ]	TURBO KC-CYJ50 [ 6WA1(T) ]	1997	2000	TRUCKS	A-6014	Air Filter
2271	ISUZU	GIGA CV# CX# CY# [ 97/07 - 00/03 ]	TURBO KC-CYJ50 [ 6WA1(T) ]	1997	2000	TRUCKS	O-1522	Oil Filter
2272	ISUZU	GIGA CV# CX# CY# [ 97/07 - 00/03 ]	TURBO KC-CYJ50 [ 6WA1(T) ]	1997	2000	TRUCKS	O-1529	Oil Filter
2273	ISUZU	GIGA CV# CX# CY# [ 97/10 - ]	TURBO KC-CYL23 [ 6SD1(T) ]	1997		TRUCKS	A-6014	Air Filter
2274	ISUZU	GIGA CV# CX# CY# [ 97/10 - ]	TURBO KC-CYL23 [ 6SD1(T) ]	1997		TRUCKS	O-1522	Oil Filter
2275	ISUZU	GIGA CV# CX# CY# [ 97/10 - ]	TURBO KC-CYL23 [ 6SD1(T) ]	1997		TRUCKS	O-1529	Oil Filter
2276	ISUZU	GIGA CV# CX# CY# [ 97/10 - 99/10 ]	KC-CYL81 [ 10PE1 ]	1997	1999	TRUCKS	A-6014	Air Filter
2277	ISUZU	GIGA CV# CX# CY# [ 97/10 - 99/10 ]	KC-CYL81 [ 10PE1 ]	1997	1999	TRUCKS	O-1522	Oil Filter
2278	ISUZU	GIGA CV# CX# CY# [ 97/10 - 99/10 ]	KC-CYL81 [ 10PE1 ]	1997	1999	TRUCKS	O-1529	Oil Filter
2279	ISUZU	GIGA CV# CX# CY# [ 98/02 - ]	ALL WHEEL DRIVE KC-CYW81 [ 10PE1 ]	1998		TRUCKS	A-6014	Air Filter
2280	ISUZU	GIGA CV# CX# CY# [ 98/02 - ]	ALL WHEEL DRIVE KC-CYW81 [ 10PE1 ]	1998		TRUCKS	O-1522	Oil Filter
2281	ISUZU	GIGA CV# CX# CY# [ 98/02 - ]	ALL WHEEL DRIVE KC-CYW81 [ 10PE1 ]	1998		TRUCKS	O-1529	Oil Filter
2282	ISUZU	GIGA CV# CX# CY# [ 98/10 - ]	TURBO KC-CYL51 [ 6WF1(T) ]	1998		TRUCKS	A-6014	Air Filter
2283	ISUZU	GIGA CV# CX# CY# [ 98/10 - ]	TURBO KC-CYL51 [ 6WF1(T) ]	1998		TRUCKS	O-1522	Oil Filter
2284	ISUZU	GIGA CV# CX# CY# [ 98/10 - ]	TURBO KC-CYL51 [ 6WF1(T) ]	1998		TRUCKS	O-1529	Oil Filter
2285	ISUZU	GIGA CV# CX# CY# [ 98/10 - ]	TURBO KC-CYM51 [ 6WF1(T) ]	1998		TRUCKS	A-6014	Air Filter
2286	ISUZU	GIGA CV# CX# CY# [ 98/10 - ]	TURBO KC-CYM51 [ 6WF1(T) ]	1998		TRUCKS	O-1522	Oil Filter
2287	ISUZU	GIGA CV# CX# CY# [ 98/10 - ]	TURBO KC-CYM51 [ 6WF1(T) ]	1998		TRUCKS	O-1529	Oil Filter
2288	ISUZU	GIGA CV# CX# CY# [ 98/12 - 00/03 ]	TURBO KC-CYJ51 [ 6WF1(T) ]	1998	2000	TRUCKS	A-6014	Air Filter
2289	ISUZU	GIGA CV# CX# CY# [ 98/12 - 00/03 ]	TURBO KC-CYJ51 [ 6WF1(T) ]	1998	2000	TRUCKS	O-1522	Oil Filter
2290	ISUZU	GIGA CV# CX# CY# [ 98/12 - 00/03 ]	TURBO KC-CYJ51 [ 6WF1(T) ]	1998	2000	TRUCKS	O-1529	Oil Filter
2291	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	KL-CXM80 [ 8PE1 ]	1999		TRUCKS	A-6014	Air Filter
2292	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	KL-CXM80 [ 8PE1 ]	1999		TRUCKS	O-1529	Oil Filter
2293	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	KL-CXM81 [ 10PE1 ]	1999		TRUCKS	A-6014	Air Filter
2294	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	KL-CXM81 [ 10PE1 ]	1999		TRUCKS	O-1522	Oil Filter
2295	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	KL-CXM81 [ 10PE1 ]	1999		TRUCKS	O-1529	Oil Filter
2296	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	KL-CYL81 [ 10PE1 ]	1999		TRUCKS	A-6014	Air Filter
2297	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	KL-CYL81 [ 10PE1 ]	1999		TRUCKS	O-1522	Oil Filter
2298	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	KL-CYL81 [ 10PE1 ]	1999		TRUCKS	O-1529	Oil Filter
2299	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	KL-CYM81 [ 10PE1 ]	1999		TRUCKS	A-6014	Air Filter
2300	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	KL-CYM81 [ 10PE1 ]	1999		TRUCKS	O-1522	Oil Filter
2301	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	KL-CYM81 [ 10PE1 ]	1999		TRUCKS	O-1529	Oil Filter
2302	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CXM23 [ 6SD1(T) ]	1999		TRUCKS	A-6014	Air Filter
2303	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CXM23 [ 6SD1(T) ]	1999		TRUCKS	O-1522	Oil Filter
2304	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CXM23 [ 6SD1(T) ]	1999		TRUCKS	O-1529	Oil Filter
2305	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CXM51 [ 6WF1(T) ]	1999		TRUCKS	A-6014	Air Filter
2306	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CXM51 [ 6WF1(T) ]	1999		TRUCKS	O-1522	Oil Filter
2307	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CXM51 [ 6WF1(T) ]	1999		TRUCKS	O-1529	Oil Filter
2308	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYL23 [ 6SD1(T) ]	1999		TRUCKS	A-6014	Air Filter
2309	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYL23 [ 6SD1(T) ]	1999		TRUCKS	O-1522	Oil Filter
2310	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYL23 [ 6SD1(T) ]	1999		TRUCKS	O-1529	Oil Filter
2311	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYL51 [ 6WF1(T) ]	1999		TRUCKS	A-6014	Air Filter
2312	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYL51 [ 6WF1(T) ]	1999		TRUCKS	O-1522	Oil Filter
2313	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYL51 [ 6WF1(T) ]	1999		TRUCKS	O-1529	Oil Filter
2314	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYL52 [ 6WG1(T) ]	1999		TRUCKS	A-6018	Air Filter
2315	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYL52 [ 6WG1(T) ]	1999		TRUCKS	O-1522	Oil Filter
2316	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYL52 [ 6WG1(T) ]	1999		TRUCKS	O-1529	Oil Filter
2317	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYM23 [ 6SD1(T) ]	1999		TRUCKS	A-6014	Air Filter

Sakura Filter							ENGINE APPLICATION	
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
2318	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYM23 [ 6SD1(T) ]	1999		TRUCKS	O-1522	Oil Filter
2319	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYM23 [ 6SD1(T) ]	1999		TRUCKS	O-1529	Oil Filter
2320	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYM51 [ 6WF1(T) ]	1999		TRUCKS	A-6014	Air Filter
2321	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYM51 [ 6WF1(T) ]	1999		TRUCKS	O-1522	Oil Filter
2322	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYM51 [ 6WF1(T) ]	1999		TRUCKS	O-1529	Oil Filter
2323	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYM52 [ 6WG1(T) ]	1999		TRUCKS	A-6018	Air Filter
2324	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYM52 [ 6WG1(T) ]	1999		TRUCKS	O-1522	Oil Filter
2325	ISUZU	GIGA CV# CX# CY# [ 99/11 - ]	TURBO KL-CYM52 [ 6WG1(T) ]	1999		TRUCKS	O-1529	Oil Filter
2326	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2327	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2328	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2329	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2330	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2331	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2332	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2333	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2334	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2335	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2336	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2337	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2338	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2339	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2340	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2341	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2342	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2343	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2344	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2345	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2346	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	O-1532	Oil Filter
2347	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	O-1532	Oil Filter
2348	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	O-1532	Oil Filter
2349	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	O-1532	Oil Filter
2350	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	O-1532	Oil Filter
2351	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	O-1532	Oil Filter
2352	ISUZU	GIGA CV#/CX #/CY# TRUCK	10PE1			TRUCKS	O-1532	Oil Filter
2353	ISUZU	GIGA CV#/CX #/CY# TRUCK	12PE1			TRUCKS	A-6014	Air Filter
2354	ISUZU	GIGA CV#/CX #/CY# TRUCK	12PE1			TRUCKS	A-6014	Air Filter
2355	ISUZU	GIGA CV#/CX #/CY# TRUCK	12PE1			TRUCKS	F-1503	Fuel Filter
2356	ISUZU	GIGA CV#/CX #/CY# TRUCK	12PE1			TRUCKS	F-1503	Fuel Filter
2357	ISUZU	GIGA CV#/CX #/CY# TRUCK	12PE1			TRUCKS	O-1521	Oil Filter
2358	ISUZU	GIGA CV#/CX #/CY# TRUCK	12PE1			TRUCKS	O-1521	Oil Filter
2359	ISUZU	GIGA CV#/CX #/CY# TRUCK	12PE1			TRUCKS	O-1532	Oil Filter
2360	ISUZU	GIGA CV#/CX #/CY# TRUCK	12PE1			TRUCKS	O-1532	Oil Filter
2361	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	A-6014	Air Filter
2362	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	A-6014	Air Filter
2363	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	A-6014	Air Filter
2364	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	A-6014	Air Filter
2365	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	A-6014	Air Filter
2366	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	A-6014	Air Filter
2367	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	A-6014	Air Filter
2368	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	A-6014	Air Filter
2369	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
2370	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
2371	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
2372	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
2373	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
2374	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
2375	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
2376	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
2377	ISUZU	GIGA CV#/CX #/CY# TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter

Sakura Filter	ENGINE APPLICATION
---------------	--------------------

Sakura Filter	ENGINE APPLICATION
---------------	--------------------

[illegible]



[illegible]



Sakura Filter	ENGINE APPLICATION
---------------	--------------------

Sakura Filter	ENGINE APPLICATION
---------------	--------------------

[illegible]

Sakura Filter	ENGINE APPLICATION
---------------	--------------------

Sakura Filter	ENGINE APPLICATION
---------------	--------------------

[illegible]

## Sakura Filter

## ENGINE APPLICATION

NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
2634	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1530	Oil Filter
2635	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2636	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2637	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2638	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2639	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2640	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2641	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2642	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2643	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2644	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2645	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2646	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2647	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2648	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2649	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2650	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2651	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2652	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2653	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2654	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2655	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2656	ISUZU	GIGA CV#/CX #/CY# TRUCK	6WG1-T			TRUCKS	O-1532	Oil Filter
2657	ISUZU	GIGA CV#/CX #/CY# TRUCK	8PE1			TRUCKS	A-6014	Air Filter
2658	ISUZU	GIGA CV#/CX #/CY# TRUCK	8PE1			TRUCKS	A-6014	Air Filter
2659	ISUZU	GIGA CV#/CX #/CY# TRUCK	8PE1			TRUCKS	F-1503	Fuel Filter
2660	ISUZU	GIGA CV#/CX #/CY# TRUCK	8PE1			TRUCKS	F-1503	Fuel Filter
2661	ISUZU	GIGA CV#/CX #/CY# TRUCK	8PE1			TRUCKS	O-1532	Oil Filter
2662	ISUZU	GIGA CV#/CX #/CY# TRUCK	8PE1			TRUCKS	O-1532	Oil Filter
2663	ISUZU	GIGA CV#/CX #/CY# TRUCK	8TD1			TRUCKS	A-6018	Air Filter
2664	ISUZU	GIGA CV#/CX #/CY# TRUCK	8TD1			TRUCKS	A-6018	Air Filter
2665	ISUZU	GIGA CV#/CX #/CY# TRUCK	8TD1			TRUCKS	F-1503	Fuel Filter
2666	ISUZU	GIGA CV#/CX #/CY# TRUCK	8TD1			TRUCKS	F-1503	Fuel Filter
2667	ISUZU	GIGA CV#/CX #/CY# TRUCK	8TD1			TRUCKS	O-1530	Oil Filter
2668	ISUZU	GIGA CV#/CX #/CY# TRUCK	8TD1			TRUCKS	O-1530	Oil Filter
2669	ISUZU	GIGA CV#/CX #/CY# TRUCK	8TD1			TRUCKS	O-1532	Oil Filter
2670	ISUZU	GIGA CV#/CX #/CY# TRUCK	8TD1			TRUCKS	O-1532	Oil Filter
2671	ISUZU	GIGA CV#/CX#/CY # TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2672	ISUZU	GIGA CV#/CX#/CY # TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2673	ISUZU	GIGA CV#/CX#/CY # TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2674	ISUZU	GIGA CV#/CX#/CY # TRUCK	10PE1			TRUCKS	O-1532	Oil Filter
2675	ISUZU	GIGA CV#/CX#/CY # TRUCK	12PE1			TRUCKS	A-6014	Air Filter
2676	ISUZU	GIGA CV#/CX#/CY # TRUCK	12PE1			TRUCKS	F-1503	Fuel Filter
2677	ISUZU	GIGA CV#/CX#/CY # TRUCK	12PE1			TRUCKS	O-1521	Oil Filter
2678	ISUZU	GIGA CV#/CX#/CY # TRUCK	12PE1			TRUCKS	O-1532	Oil Filter
2679	ISUZU	GIGA CV#/CX#/CY # TRUCK	60PE1			TRUCKS	A-6014	Air Filter
2680	ISUZU	GIGA CV#/CX#/CY # TRUCK	60PE1			TRUCKS	F-1503	Fuel Filter
2681	ISUZU	GIGA CV#/CX#/CY # TRUCK	60PE1			TRUCKS	O-1530	Oil Filter
2682	ISUZU	GIGA CV#/CX#/CY # TRUCK	60PE1			TRUCKS	O-1532	Oil Filter
2683	ISUZU	GIGA CV#/CX#/CY # TRUCK	62PE1			TRUCKS	A-6014	Air Filter
2684	ISUZU	GIGA CV#/CX#/CY # TRUCK	62PE1			TRUCKS	F-1503	Fuel Filter
2685	ISUZU	GIGA CV#/CX#/CY # TRUCK	62PE1			TRUCKS	O-1521	Oil Filter
2686	ISUZU	GIGA CV#/CX#/CY # TRUCK	62PE1			TRUCKS	O-1532	Oil Filter
2687	ISUZU	GIGA CV#/CX#/CY # TRUCK	6SD1-T			TRUCKS	A-6014	Air Filter
2688	ISUZU	GIGA CV#/CX#/CY # TRUCK	6SD1-T			TRUCKS	A-6014	Air Filter
2689	ISUZU	GIGA CV#/CX#/CY # TRUCK	6SD1-T			TRUCKS	A-6014	Air Filter
2690	ISUZU	GIGA CV#/CX#/CY # TRUCK	6SD1-T			TRUCKS	A-6014	Air Filter
2691	ISUZU	GIGA CV#/CX#/CY # TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
2692	ISUZU	GIGA CV#/CX#/CY # TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
2693	ISUZU	GIGA CV#/CX#/CY # TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
2694	ISUZU	GIGA CV#/CX#/CY # TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
2695	ISUZU	GIGA CV#/CX#/CY # TRUCK	6SD1-T			TRUCKS	F-1503	Fuel Filter
2696	ISUZU	GIGA CV#/CX#/CY # TRUCK	6SD1-T			TRUCKS	O-1530	Oil Filter
2697	ISUZU	GIGA CV#/CX#/CY # TRUCK	6SD1-T			TRUCKS	O-1530	Oil Filter

[illegible]



Sakura Filter	ENGINE APPLICATION
---------------	--------------------

Sakura Filter	ENGINE APPLICATION
---------------	--------------------

NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
2762	ISUZU	GIGA CV#/CX#/CY # TRUCK	6WF1-T			TRUCKS	A-6014	Air Filter
2763	ISUZU	GIGA CV#/CX#/CY # TRUCK	6WF1-T			TRUCKS	F-1503	Fuel Filter
2764	ISUZU	GIGA CV#/CX#/CY # TRUCK	6WF1-T			TRUCKS	F-1503	Fuel Filter
2765	ISUZU	GIGA CV#/CX#/CY # TRUCK	6WF1-T			TRUCKS	F-1503	Fuel Filter
2766	ISUZU	GIGA CV#/CX#/CY # TRUCK	6WF1-T			TRUCKS	F-1503	Fuel Filter
2767	ISUZU	GIGA CV#/CX#/CY # TRUCK	6WF1-T			TRUCKS	O-1530	Oil Filter
2768	ISUZU	GIGA CV#/CX#/CY # TRUCK	6WF1-T			TRUCKS	O-1530	Oil Filter
2769	ISUZU	GIGA CV#/CX#/CY # TRUCK	6WF1-T			TRUCKS	O-1532	Oil Filter
2770	ISUZU	GIGA CV#/CX#/CY # TRUCK	6WF1-T			TRUCKS	O-1532	Oil Filter
2771	ISUZU	GIGA CV#/CX#/CY # TRUCK	6WF1-T			TRUCKS	O-1532	Oil Filter
2772	ISUZU	GIGA CV#/CX#/CY # TRUCK	6WF1-T			TRUCKS	O-1532	Oil Filter
2773	ISUZU	GIGA CV#/CX#/CY # TRUCK	8PE1			TRUCKS	A-6014	Air Filter
2774	ISUZU	GIGA CV#/CX#/CY # TRUCK	8PE1			TRUCKS	F-1503	Fuel Filter
2775	ISUZU	GIGA CV#/CX#/CY # TRUCK	8PE1			TRUCKS	O-1532	Oil Filter
2776	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2777	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2778	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2779	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2780	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2781	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2782	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2783	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2784	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2785	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2786	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2787	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2788	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2789	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2790	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	A-6014	Air Filter
2791	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2792	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2793	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2794	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2795	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2796	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2797	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2798	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2799	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2800	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2801	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2802	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2803	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2804	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2805	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2806	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	F-1503	Fuel Filter
2807	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2808	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2809	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2810	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2811	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2812	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2813	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2814	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2815	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2816	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2817	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2818	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2819	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2820	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2821	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2822	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1530	Oil Filter
2823	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1532	Oil Filter
2824	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1532	Oil Filter
2825	ISUZU	GIGA CV#/CX#/CY# TRUCK	10PE1			TRUCKS	O-1532	Oil Filter



## ENGINE APPLICATION

[illegible]

## Sakura Filter

## ENGINE APPLICATION

[illegible]

Sakura Filter	ENGINE APPLICATION
---------------	--------------------

Sakura Filter	ENGINE APPLICATION
---------------	--------------------

[illegible]

Sakura Filter	ENGINE APPLICATION
---------------	--------------------

Sakura Filter	ENGINE APPLICATION
---------------	--------------------

[illegible]



Sakura Filter	ENGINE APPLICATION
---------------	--------------------

Sakura Filter	ENGINE APPLICATION
---------------	--------------------

[illegible]



Sakura Filter							ENGINE APPLICATION	
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
3146	ISUZU	GIGA E X # TRACTOR	10PE1			TRUCKS	A-6014	Air Filter
3147	ISUZU	GIGA E X # TRACTOR	10PE1			TRUCKS	F-1503	Fuel Filter
3148	ISUZU	GIGA E X # TRACTOR	10PE1			TRUCKS	F-1503	Fuel Filter
3149	ISUZU	GIGA E X # TRACTOR	10PE1			TRUCKS	O-1530	Oil Filter
3150	ISUZU	GIGA E X # TRACTOR	10PE1			TRUCKS	O-1530	Oil Filter
3151	ISUZU	GIGA E X # TRACTOR	10PE1			TRUCKS	O-1532	Oil Filter
3152	ISUZU	GIGA E X # TRACTOR	10PE1			TRUCKS	O-1532	Oil Filter
3153	ISUZU	GIGA E X # TRACTOR	10TD1			TRUCKS	A-6014	Air Filter
3154	ISUZU	GIGA E X # TRACTOR	10TD1			TRUCKS	A-6018	Air Filter
3155	ISUZU	GIGA E X # TRACTOR	10TD1			TRUCKS	A-6018	Air Filter
3156	ISUZU	GIGA E X # TRACTOR	10TD1			TRUCKS	F-1503	Fuel Filter
3157	ISUZU	GIGA E X # TRACTOR	10TD1			TRUCKS	F-1503	Fuel Filter
3158	ISUZU	GIGA E X # TRACTOR	10TD1			TRUCKS	F-1503	Fuel Filter
3159	ISUZU	GIGA E X # TRACTOR	10TD1			TRUCKS	O-1521	Oil Filter
3160	ISUZU	GIGA E X # TRACTOR	10TD1			TRUCKS	O-1521	Oil Filter
3161	ISUZU	GIGA E X # TRACTOR	10TD1			TRUCKS	O-1530	Oil Filter
3162	ISUZU	GIGA E X # TRACTOR	10TD1			TRUCKS	O-1532	Oil Filter
3163	ISUZU	GIGA E X # TRACTOR	10TD1			TRUCKS	O-1532	Oil Filter
3164	ISUZU	GIGA E X # TRACTOR	10TD1			TRUCKS	O-1532	Oil Filter
3165	ISUZU	GIGA E X # TRACTOR	12PE1			TRUCKS	A-6014	Air Filter
3166	ISUZU	GIGA E X # TRACTOR	12PE1			TRUCKS	A-6014	Air Filter
3167	ISUZU	GIGA E X # TRACTOR	12PE1			TRUCKS	A-6014	Air Filter
3168	ISUZU	GIGA E X # TRACTOR	12PE1			TRUCKS	F-1503	Fuel Filter
3169	ISUZU	GIGA E X # TRACTOR	12PE1			TRUCKS	F-1503	Fuel Filter
3170	ISUZU	GIGA E X # TRACTOR	12PE1			TRUCKS	F-1503	Fuel Filter
3171	ISUZU	GIGA E X # TRACTOR	12PE1			TRUCKS	O-1521	Oil Filter
3172	ISUZU	GIGA E X # TRACTOR	12PE1			TRUCKS	O-1521	Oil Filter
3173	ISUZU	GIGA E X # TRACTOR	12PE1			TRUCKS	O-1521	Oil Filter
3174	ISUZU	GIGA E X # TRACTOR	12PE1			TRUCKS	O-1532	Oil Filter
3175	ISUZU	GIGA E X # TRACTOR	12PE1			TRUCKS	O-1532	Oil Filter
3176	ISUZU	GIGA E X # TRACTOR	12PE1			TRUCKS	O-1532	Oil Filter
3177	ISUZU	GIGA E X # TRACTOR	2PE1			TRUCKS	A-6014	Air Filter
3178	ISUZU	GIGA E X # TRACTOR	2PE1			TRUCKS	F-1503	Fuel Filter
3179	ISUZU	GIGA E X # TRACTOR	2PE1			TRUCKS	O-1521	Oil Filter
3180	ISUZU	GIGA E X # TRACTOR	2PE1			TRUCKS	O-1532	Oil Filter
3181	ISUZU	GIGA E X # TRACTOR	6SD1			TRUCKS	A-6014	Air Filter
3182	ISUZU	GIGA E X # TRACTOR	6SD1			TRUCKS	F-1503	Fuel Filter
3183	ISUZU	GIGA E X # TRACTOR	6SD1			TRUCKS	O-1530	Oil Filter
3184	ISUZU	GIGA E X # TRACTOR	6SD1			TRUCKS	O-1532	Oil Filter
3185	ISUZU	GIGA E X # TRACTOR	6TE1			TRUCKS	A-6014	Air Filter
3186	ISUZU	GIGA E X # TRACTOR	6TE1			TRUCKS	A-6014	Air Filter
3187	ISUZU	GIGA E X # TRACTOR	6TE1			TRUCKS	F-1503	Fuel Filter
3188	ISUZU	GIGA E X # TRACTOR	6TE1			TRUCKS	F-1503	Fuel Filter
3189	ISUZU	GIGA E X # TRACTOR	6TE1			TRUCKS	O-1530	Oil Filter
3190	ISUZU	GIGA E X # TRACTOR	6TE1			TRUCKS	O-1530	Oil Filter
3191	ISUZU	GIGA E X # TRACTOR	6TE1			TRUCKS	O-1532	Oil Filter
3192	ISUZU	GIGA E X # TRACTOR	6TE1			TRUCKS	O-1532	Oil Filter
3193	ISUZU	GIGA E X # TRACTOR	6UZ1-T			TRUCKS	A-6014	Air Filter
3194	ISUZU	GIGA E X # TRACTOR	6UZ1-T			TRUCKS	O-1530	Oil Filter
3195	ISUZU	GIGA E X # TRACTOR	6UZ1-T			TRUCKS	O-1532	Oil Filter
3196	ISUZU	GIGA E X # TRACTOR	6WA1-T			TRUCKS	A-6014	Air Filter
3197	ISUZU	GIGA E X # TRACTOR	6WA1-T			TRUCKS	A-6014	Air Filter
3198	ISUZU	GIGA E X # TRACTOR	6WA1-T			TRUCKS	F-1503	Fuel Filter
3199	ISUZU	GIGA E X # TRACTOR	6WA1-T			TRUCKS	F-1503	Fuel Filter
3200	ISUZU	GIGA E X # TRACTOR	6WA1-T			TRUCKS	O-1530	Oil Filter
3201	ISUZU	GIGA E X # TRACTOR	6WA1-T			TRUCKS	O-1530	Oil Filter
3202	ISUZU	GIGA E X # TRACTOR	6WA1-T			TRUCKS	O-1532	Oil Filter
3203	ISUZU	GIGA E X # TRACTOR	6WA1-T			TRUCKS	O-1532	Oil Filter
3204	ISUZU	GIGA E X # TRACTOR	6WF1-T			TRUCKS	A-6014	Air Filter
3205	ISUZU	GIGA E X # TRACTOR	6WF1-T			TRUCKS	A-6014	Air Filter
3206	ISUZU	GIGA E X # TRACTOR	6WF1-T			TRUCKS	A-6014	Air Filter
3207	ISUZU	GIGA E X # TRACTOR	6WF1-T			TRUCKS	A-6014	Air Filter
3208	ISUZU	GIGA E X # TRACTOR	6WF1-T			TRUCKS	A-6014	Air Filter
3209	ISUZU	GIGA E X # TRACTOR	6WF1-T			TRUCKS	F-1503	Fuel Filter

Sakura Filter	ENGINE APPLICATION
---------------	--------------------

Sakura Filter	ENGINE APPLICATION
---------------	--------------------

[illegible]

Sakura Filter							ENGINE APPLICATION	
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
3274	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1530	Oil Filter
3275	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1530	Oil Filter
3276	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1530	Oil Filter
3277	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1530	Oil Filter
3278	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1530	Oil Filter
3279	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1530	Oil Filter
3280	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1530	Oil Filter
3281	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1530	Oil Filter
3282	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1530	Oil Filter
3283	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1530	Oil Filter
3284	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1530	Oil Filter
3285	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1530	Oil Filter
3286	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1530	Oil Filter
3287	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3288	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3289	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3290	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3291	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3292	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3293	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3294	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3295	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3296	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3297	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3298	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3299	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3300	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3301	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3302	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3303	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3304	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3305	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3306	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3307	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3308	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3309	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3310	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3311	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3312	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3313	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3314	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3315	ISUZU	GIGA E X # TRACTOR	6WG1-T			TRUCKS	O-1532	Oil Filter
3316	ISUZU	GIGA E X # TRACTOR	8TD1			TRUCKS	A-6018	Air Filter
3317	ISUZU	GIGA E X # TRACTOR	8TD1			TRUCKS	A-6018	Air Filter
3318	ISUZU	GIGA E X # TRACTOR	8TD1			TRUCKS	A-6018	Air Filter
3319	ISUZU	GIGA E X # TRACTOR	8TD1			TRUCKS	A-6018	Air Filter
3320	ISUZU	GIGA E X # TRACTOR	8TD1			TRUCKS	F-1503	Fuel Filter
3321	ISUZU	GIGA E X # TRACTOR	8TD1			TRUCKS	F-1503	Fuel Filter
3322	ISUZU	GIGA E X # TRACTOR	8TD1			TRUCKS	F-1503	Fuel Filter
3323	ISUZU	GIGA E X # TRACTOR	8TD1			TRUCKS	O-1530	Oil Filter
3324	ISUZU	GIGA E X # TRACTOR	8TD1			TRUCKS	O-1530	Oil Filter
3325	ISUZU	GIGA E X # TRACTOR	8TD1			TRUCKS	O-1530	Oil Filter
3326	ISUZU	GIGA E X # TRACTOR	8TD1			TRUCKS	O-1530	Oil Filter
3327	ISUZU	GIGA E X # TRACTOR	8TD1			TRUCKS	O-1532	Oil Filter
3328	ISUZU	GIGA E X # TRACTOR	8TD1			TRUCKS	O-1532	Oil Filter
3329	ISUZU	GIGA E X # TRACTOR	8TD1			TRUCKS	O-1532	Oil Filter
3330	ISUZU	GIGA E X # TRACTOR	8TD1			TRUCKS	O-1532	Oil Filter
3331	ISUZU	GIGA SITEC 385 -(N/A)	N/A			TRUCKS	EO-1302	Oil Filter
3332	ISUZU	GIGA SITEC 425 (2002-N/A)	N/A	2002	N/A	TRUCKS	EO-1302	Oil Filter
3333	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	KL-EXD74 [ 8TD1 ]	2000		TRUCKS	A-6018	Air Filter
3334	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	KL-EXD74 [ 8TD1 ]	2000		TRUCKS	O-1522	Oil Filter
3335	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	KL-EXD74 [ 8TD1 ]	2000		TRUCKS	O-1529	Oil Filter
3336	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	KL-EXR74 [ 8TD1 ]	2000		TRUCKS	A-6018	Air Filter
3337	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	KL-EXR74 [ 8TD1 ]	2000		TRUCKS	O-1522	Oil Filter

## Sakura Filter

## ENGINE APPLICATION

NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
3338	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	KL-EXR74 [ 8TD1 ]	2000		TRUCKS	O-1529	Oil Filter
3339	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	KL-EXY74 [ 8TD1 ]	2000		TRUCKS	A-6018	Air Filter
3340	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	KL-EXY74 [ 8TD1 ]	2000		TRUCKS	O-1522	Oil Filter
3341	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	KL-EXY74 [ 8TD1 ]	2000		TRUCKS	O-1529	Oil Filter
3342	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	KL-EXZ74 [ 8TD1 ]	2000		TRUCKS	A-6018	Air Filter
3343	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	KL-EXZ74 [ 8TD1 ]	2000		TRUCKS	O-1522	Oil Filter
3344	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	KL-EXZ74 [ 8TD1 ]	2000		TRUCKS	O-1529	Oil Filter
3345	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	KL-EXZ75 [ 10TD1 ]	2000		TRUCKS	A-6018	Air Filter
3346	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	KL-EXZ75 [ 10TD1 ]	2000		TRUCKS	O-1521	Oil Filter
3347	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	KL-EXZ75 [ 10TD1 ]	2000		TRUCKS	O-1529	Oil Filter
3348	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXD51 [ 6WF1(T) ]	2000		TRUCKS	A-6014	Air Filter
3349	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXD51 [ 6WF1(T) ]	2000		TRUCKS	O-1522	Oil Filter
3350	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXD51 [ 6WF1(T) ]	2000		TRUCKS	O-1529	Oil Filter
3351	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXD52 [ 6WG1(T) ]	2000		TRUCKS	A-6018	Air Filter
3352	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXD52 [ 6WG1(T) ]	2000		TRUCKS	O-1522	Oil Filter
3353	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXD52 [ 6WG1(T) ]	2000		TRUCKS	O-1529	Oil Filter
3354	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXR23 [ 6SD1(T) ]	2000		TRUCKS	A-6014	Air Filter
3355	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXR23 [ 6SD1(T) ]	2000		TRUCKS	O-1522	Oil Filter
3356	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXR23 [ 6SD1(T) ]	2000		TRUCKS	O-1529	Oil Filter
3357	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXR51 [ 6WF1(T) ]	2000		TRUCKS	A-6014	Air Filter
3358	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXR51 [ 6WF1(T) ]	2000		TRUCKS	O-1522	Oil Filter
3359	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXR51 [ 6WF1(T) ]	2000		TRUCKS	O-1529	Oil Filter
3360	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXR52 [ 6WG1(T) ]	2000		TRUCKS	A-6018	Air Filter
3361	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXR52 [ 6WG1(T) ]	2000		TRUCKS	O-1522	Oil Filter
3362	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXR52 [ 6WG1(T) ]	2000		TRUCKS	O-1529	Oil Filter
3363	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXY52 [ 6WG1(T) ]	2000		TRUCKS	A-6018	Air Filter
3364	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXY52 [ 6WG1(T) ]	2000		TRUCKS	O-1522	Oil Filter
3365	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXY52 [ 6WG1(T) ]	2000		TRUCKS	O-1529	Oil Filter
3366	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXZ52 [ 6WG1(T) ]	2000		TRUCKS	A-6018	Air Filter
3367	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXZ52 [ 6WG1(T) ]	2000		TRUCKS	O-1522	Oil Filter
3368	ISUZU	GIGA TRACTOR EX# [ 00/06 - ]	TURBO KL-EXZ52 [ 6WG1(T) ]	2000		TRUCKS	O-1529	Oil Filter
3369	ISUZU	GIGA TRACTOR EX# [ 00/12 - ]	KL-EXR73 [ 6TE1 ]	2000		TRUCKS	A-6014	Air Filter
3370	ISUZU	GIGA TRACTOR EX# [ 00/12 - ]	KL-EXR73 [ 6TE1 ]	2000		TRUCKS	O-1522	Oil Filter
3371	ISUZU	GIGA TRACTOR EX# [ 00/12 - ]	KL-EXR73 [ 6TE1 ]	2000		TRUCKS	O-1529	Oil Filter
3372	ISUZU	GIGA TRACTOR EX# [ 01/01 - ]	KL-EXD73 [ 6TE1-S ]	2001		TRUCKS	A-6014	Air Filter
3373	ISUZU	GIGA TRACTOR EX# [ 01/01 - ]	KL-EXD73 [ 6TE1-S ]	2001		TRUCKS	O-1522	Oil Filter
3374	ISUZU	GIGA TRACTOR EX# [ 01/01 - ]	KL-EXD73 [ 6TE1-S ]	2001		TRUCKS	O-1529	Oil Filter
3375	ISUZU	GIGA TRACTOR EX# [ 95/06 - ]	KC-EXD81 [ 10PE1 ]	1995		TRUCKS	A-6014	Air Filter
3376	ISUZU	GIGA TRACTOR EX# [ 95/06 - ]	KC-EXD81 [ 10PE1 ]	1995		TRUCKS	O-1522	Oil Filter
3377	ISUZU	GIGA TRACTOR EX# [ 95/06 - ]	KC-EXD81 [ 10PE1 ]	1995		TRUCKS	O-1529	Oil Filter
3378	ISUZU	GIGA TRACTOR EX# [ 95/06 - ]	KC-EXZ82 [ 12PE1 ]	1995		TRUCKS	A-6014	Air Filter
3379	ISUZU	GIGA TRACTOR EX# [ 95/06 - ]	KC-EXZ82 [ 12PE1 ]	1995		TRUCKS	O-1521	Oil Filter
3380	ISUZU	GIGA TRACTOR EX# [ 95/06 - ]	KC-EXZ82 [ 12PE1 ]	1995		TRUCKS	O-1529	Oil Filter
3381	ISUZU	GIGA TRACTOR EX# [ 95/06 - 00/05 ]	KC-EXR81 [ 10PE1 ]	1995	2000	TRUCKS	A-6014	Air Filter
3382	ISUZU	GIGA TRACTOR EX# [ 95/06 - 00/05 ]	KC-EXR81 [ 10PE1 ]	1995	2000	TRUCKS	O-1522	Oil Filter
3383	ISUZU	GIGA TRACTOR EX# [ 95/06 - 00/05 ]	KC-EXR81 [ 10PE1 ]	1995	2000	TRUCKS	O-1529	Oil Filter
3384	ISUZU	GIGA TRACTOR EX# [ 95/06 - 00/05 ]	KC-EXR82 [ 12PE1 ]	1995	2000	TRUCKS	A-6014	Air Filter
3385	ISUZU	GIGA TRACTOR EX# [ 95/06 - 00/05 ]	KC-EXR82 [ 12PE1 ]	1995	2000	TRUCKS	O-1521	Oil Filter
3386	ISUZU	GIGA TRACTOR EX# [ 95/06 - 00/05 ]	KC-EXR82 [ 12PE1 ]	1995	2000	TRUCKS	O-1529	Oil Filter
3387	ISUZU	GIGA TRACTOR EX# [ 95/06 - 97/04 ]	KC-EXD82 [ 12PE1 ]	1995	1997	TRUCKS	A-6014	Air Filter
3388	ISUZU	GIGA TRACTOR EX# [ 95/06 - 97/04 ]	KC-EXD82 [ 12PE1 ]	1995	1997	TRUCKS	O-1521	Oil Filter
3389	ISUZU	GIGA TRACTOR EX# [ 95/06 - 97/04 ]	KC-EXD82 [ 12PE1 ]	1995	1997	TRUCKS	O-1529	Oil Filter
3390	ISUZU	GIGA TRACTOR EX# [ 96/12 - 00/05 ]	TURBO KC-EXR52 [ 6WG1(T) ]	1996	2000	TRUCKS	A-6018	Air Filter
3391	ISUZU	GIGA TRACTOR EX# [ 96/12 - 00/05 ]	TURBO KC-EXR52 [ 6WG1(T) ]	1996	2000	TRUCKS	O-1522	Oil Filter



Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
3392	ISUZU	GIGA TRACTOR EX# [ 96/12 - 00/05 ]	TURBO KC-EXR52 [ 6WG1(T) ]	1996	2000	TRUCKS	O-1529	Oil Filter
3393	ISUZU	GIGA TRACTOR EX# [ 97/04 - ]	KC-EXZ75 [ 10TD1 ]	1997		TRUCKS	A-6018	Air Filter
3394	ISUZU	GIGA TRACTOR EX# [ 97/04 - ]	KC-EXZ75 [ 10TD1 ]	1997		TRUCKS	O-1521	Oil Filter
3395	ISUZU	GIGA TRACTOR EX# [ 97/04 - ]	KC-EXZ75 [ 10TD1 ]	1997		TRUCKS	O-1529	Oil Filter
3396	ISUZU	GIGA TRACTOR EX# [ 97/04 - 00/05 ]	KC-EXY82 [ 12PE1 ]	1997	2000	TRUCKS	A-6014	Air Filter
3397	ISUZU	GIGA TRACTOR EX# [ 97/04 - 00/05 ]	KC-EXY82 [ 12PE1 ]	1997	2000	TRUCKS	O-1521	Oil Filter
3398	ISUZU	GIGA TRACTOR EX# [ 97/04 - 00/05 ]	KC-EXY82 [ 12PE1 ]	1997	2000	TRUCKS	O-1529	Oil Filter
3399	ISUZU	GIGA TRACTOR EX# [ 97/04 - 00/05 ]	TURBO KC-EXR50 [ 6WA1(T) ]	1997	2000	TRUCKS	A-6014	Air Filter
3400	ISUZU	GIGA TRACTOR EX# [ 97/04 - 00/05 ]	TURBO KC-EXR50 [ 6WA1(T) ]	1997	2000	TRUCKS	O-1522	Oil Filter
3401	ISUZU	GIGA TRACTOR EX# [ 97/04 - 00/05 ]	TURBO KC-EXR50 [ 6WA1(T) ]	1997	2000	TRUCKS	O-1529	Oil Filter
3402	ISUZU	GIGA TRACTOR EX# [ 97/04 - 00/05 ]	TURBO KC-EXY52 [ 6WG1(T) ]	1997	2000	TRUCKS	A-6018	Air Filter
3403	ISUZU	GIGA TRACTOR EX# [ 97/04 - 00/05 ]	TURBO KC-EXY52 [ 6WG1(T) ]	1997	2000	TRUCKS	O-1522	Oil Filter
3404	ISUZU	GIGA TRACTOR EX# [ 97/04 - 00/05 ]	TURBO KC-EXY52 [ 6WG1(T) ]	1997	2000	TRUCKS	O-1529	Oil Filter
3405	ISUZU	GIGA TRACTOR EX# [ 97/04 - 00/05 ]	TURBO KC-EXZ52 [ 6WG1(T) ]	1997	2000	TRUCKS	A-6018	Air Filter
3406	ISUZU	GIGA TRACTOR EX# [ 97/04 - 00/05 ]	TURBO KC-EXZ52 [ 6WG1(T) ]	1997	2000	TRUCKS	O-1522	Oil Filter
3407	ISUZU	GIGA TRACTOR EX# [ 97/04 - 00/05 ]	TURBO KC-EXZ52 [ 6WG1(T) ]	1997	2000	TRUCKS	O-1529	Oil Filter
3408	ISUZU	GIGA TRACTOR EX# [ 97/08 - 00/05 ]	TURBO KC-EXD50 [ 6VVA1(T) ]	1997	2000	TRUCKS	A-6014	Air Filter
3409	ISUZU	GIGA TRACTOR EX# [ 97/08 - 00/05 ]	TURBO KC-EXD50 [ 6VVA1(T) ]	1997	2000	TRUCKS	O-1522	Oil Filter
3410	ISUZU	GIGA TRACTOR EX# [ 97/08 - 00/05 ]	TURBO KC-EXD50 [ 6VVA1(T) ]	1997	2000	TRUCKS	O-1529	Oil Filter
3411	ISUZU	GIGA TRACTOR EX# [ 97/08 - 00/05 ]	TURBO KC-EXD52 [ 6WG1(T) ]	1997	2000	TRUCKS	A-6018	Air Filter
3412	ISUZU	GIGA TRACTOR EX# [ 97/08 - 00/05 ]	TURBO KC-EXD52 [ 6WG1(T) ]	1997	2000	TRUCKS	O-1522	Oil Filter
3413	ISUZU	GIGA TRACTOR EX# [ 97/08 - 00/05 ]	TURBO KC-EXD52 [ 6WG1(T) ]	1997	2000	TRUCKS	O-1529	Oil Filter
3414	ISUZU	ISUZU 12PB1 1983/SVG	Engine: N/A			TRUCKS	AS-2205	Air Filter
3415	ISUZU	ISUZU 2.2 L DIESEL/MIDI 2.2L	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3416	ISUZU	ISUZU 4.8L 4HE1-TC/NPR DIESEL-((1999/N/A))	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3417	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD24 4-Wheel	Engine: N/A			TRUCKS	A-1502	Air Filter
3418	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD24 4-Wheel	Engine: N/A			TRUCKS	AS-1502	Air Filter
3419	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD44	Engine: N/A			TRUCKS	A-1502	Air Filter
3420	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD44	Engine: N/A			TRUCKS	AS-1502	Air Filter
3421	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD44	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3422	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD44	Engine: N/A			TRUCKS	O-1502	Oil Filter
3423	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD46	Engine: N/A			TRUCKS	A-1502	Air Filter
3424	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD46	Engine: N/A			TRUCKS	AS-1502	Air Filter
3425	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD46	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3426	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD46	Engine: N/A			TRUCKS	O-1502	Oil Filter
3427	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD54	Engine: N/A			TRUCKS	A-1502	Air Filter
3428	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD54	Engine: N/A			TRUCKS	AS-1502	Air Filter
3429	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD54	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3430	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD54	Engine: N/A			TRUCKS	O-1502	Oil Filter
3431	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD64	Engine: N/A			TRUCKS	A-1502	Air Filter
3432	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD64	Engine: N/A			TRUCKS	AS-1502	Air Filter
3433	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD64	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3434	ISUZU	ISUZU 4BA1/6- Wheel Truck/TLD64	Engine: N/A			TRUCKS	O-1502	Oil Filter
3435	ISUZU	ISUZU 4BB1/6- Wheel Truck/KS21	Engine: N/A			TRUCKS	A-6013	Air Filter
3436	ISUZU	ISUZU 4BB1/6- Wheel Truck/KS21	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3437	ISUZU	ISUZU 4BB1/6- Wheel Truck/KS21	Engine: N/A			TRUCKS	O-1503	Oil Filter
3438	ISUZU	ISUZU 4BB1/6- Wheel Truck/KS31	Engine: N/A			TRUCKS	A-6013	Air Filter
3439	ISUZU	ISUZU 4BB1/6- Wheel Truck/KS31	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3440	ISUZU	ISUZU 4BB1/6- Wheel Truck/KS31	Engine: N/A			TRUCKS	O-1503	Oil Filter
3441	ISUZU	ISUZU 4BB1/6- Wheel Truck/KS31R	Engine: N/A			TRUCKS	A-6013	Air Filter
3442	ISUZU	ISUZU 4BB1/6- Wheel Truck/KS31R	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3443	ISUZU	ISUZU 4BB1/6- Wheel Truck/KS31R	Engine: N/A			TRUCKS	O-1503	Oil Filter
3444	ISUZU	ISUZU 4BB1/6- Wheel Truck/KT35	Engine: N/A			TRUCKS	A-6013	Air Filter
3445	ISUZU	ISUZU 4BB1/6- Wheel Truck/KT35	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3446	ISUZU	ISUZU 4BB1/6- Wheel Truck/KT35	Engine: N/A			TRUCKS	O-1503	Oil Filter
3447	ISUZU	ISUZU 4BC2/6- Wheel Truck/NKR575U5	Engine: N/A			TRUCKS	A-6012	Air Filter



Sakura Filter				ENGINE APPLICATION				
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
3448	ISUZU	ISUZU 4BC2/6- Wheel Truck/NKR575U5	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3449	ISUZU	ISUZU 4BC2/6- Wheel Truck/NKR575U5	Engine: N/A			TRUCKS	O-1503	Oil Filter
3450	ISUZU	ISUZU 4BC2/6- Wheel Truck/NPR57L	Engine: N/A			TRUCKS	A-6012	Air Filter
3451	ISUZU	ISUZU 4BC2/6- Wheel Truck/NPR57L	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3452	ISUZU	ISUZU 4BC2/6- Wheel Truck/NPR57L	Engine: N/A			TRUCKS	O-1503	Oil Filter
3453	ISUZU	ISUZU 4BC2/6- Wheel Truck/TLD56	Engine: N/A			TRUCKS	A-6012	Air Filter
3454	ISUZU	ISUZU 4BC2/6- Wheel Truck/TLD56	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3455	ISUZU	ISUZU 4BC2/6- Wheel Truck/TLD56	Engine: N/A			TRUCKS	O-1503	Oil Filter
3456	ISUZU	ISUZU 4BC2/6- Wheel Truck/TLD56JY	Engine: N/A			TRUCKS	A-6012	Air Filter
3457	ISUZU	ISUZU 4BC2/6- Wheel Truck/TLD56JY	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3458	ISUZU	ISUZU 4BC2/6- Wheel Truck/TLD56JY	Engine: N/A			TRUCKS	O-1503	Oil Filter
3459	ISUZU	ISUZU 4BC2/6- Wheel Truck/TLD56Y	Engine: N/A			TRUCKS	A-6012	Air Filter
3460	ISUZU	ISUZU 4BC2/6- Wheel Truck/TLD56Y	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3461	ISUZU	ISUZU 4BC2/6- Wheel Truck/TLD56Y	Engine: N/A			TRUCKS	O-1503	Oil Filter
3462	ISUZU	ISUZU 4BD1/6- Wheel Truck/KS22	Engine: N/A			TRUCKS	A-1505	Air Filter
3463	ISUZU	ISUZU 4BD1/6- Wheel Truck/KS22	Engine: N/A			TRUCKS	A-6012	Air Filter
3464	ISUZU	ISUZU 4BD1/6- Wheel Truck/KS22	Engine: N/A			TRUCKS	C-1504	Oil Filter
3465	ISUZU	ISUZU 4BD1/6- Wheel Truck/KS22	Engine: N/A			TRUCKS	C-1508	Oil Filter
3466	ISUZU	ISUZU 4BD1/6- Wheel Truck/KS22	Engine: N/A			TRUCKS	C-1512	Oil Filter
3467	ISUZU	ISUZU 4BD1/6- Wheel Truck/KS22	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3468	ISUZU	ISUZU 4BD1/6- Wheel Truck/KS22	Engine: N/A			TRUCKS	O-1503	Oil Filter
3469	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59L	Engine: N/A			TRUCKS	A-1505	Air Filter
3470	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59L	Engine: N/A			TRUCKS	A-6012	Air Filter
3471	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59L	Engine: N/A			TRUCKS	C-1504	Oil Filter
3472	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59L	Engine: N/A			TRUCKS	C-1508	Oil Filter
3473	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59L	Engine: N/A			TRUCKS	C-1512	Oil Filter
3474	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59L	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3475	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59L	Engine: N/A			TRUCKS	O-1503	Oil Filter
3476	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59LU5	Engine: N/A			TRUCKS	A-1505	Air Filter
3477	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59LU5	Engine: N/A			TRUCKS	A-6012	Air Filter
3478	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59LU5	Engine: N/A			TRUCKS	C-1504	Oil Filter
3479	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59LU5	Engine: N/A			TRUCKS	C-1508	Oil Filter
3480	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59LU5	Engine: N/A			TRUCKS	C-1512	Oil Filter
3481	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59LU5	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3482	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59LU5	Engine: N/A			TRUCKS	O-1503	Oil Filter
3483	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59LU5F	Engine: N/A			TRUCKS	A-1505	Air Filter
3484	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59LU5F	Engine: N/A			TRUCKS	A-6012	Air Filter
3485	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59LU5F	Engine: N/A			TRUCKS	C-1504	Oil Filter
3486	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59LU5F	Engine: N/A			TRUCKS	C-1508	Oil Filter
3487	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59LU5F	Engine: N/A			TRUCKS	C-1512	Oil Filter
3488	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59LU5F	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3489	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59LU5F	Engine: N/A			TRUCKS	O-1503	Oil Filter
3490	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59P /NPR59PU5	Engine: N/A			TRUCKS	A-1505	Air Filter
3491	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59P /NPR59PU5	Engine: N/A			TRUCKS	A-6012	Air Filter
3492	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59P /NPR59PU5	Engine: N/A			TRUCKS	C-1504	Oil Filter
3493	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59P /NPR59PU5	Engine: N/A			TRUCKS	C-1508	Oil Filter
3494	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59P /NPR59PU5	Engine: N/A			TRUCKS	C-1512	Oil Filter
3495	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59P /NPR59PU5	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3496	ISUZU	ISUZU 4BD1/6- Wheel Truck/NPR59P /NPR59PU5	Engine: N/A			TRUCKS	O-1503	Oil Filter
3497	ISUZU	ISUZU 4BD2-T -	Engine: N/A			ENGINES,GENSETS,COOLIN G UNITS	C-1522	Oil Filter
3498	ISUZU	ISUZU 4BD2-TC -	Engine: N/A			ENGINES,GENSETS,COOLIN G UNITS	C-1522	Oil Filter
3499	ISUZU	ISUZU 4BE1/6- Wheel Truck/NKR58L	Engine: N/A			TRUCKS	A-6012	Air Filter
3500	ISUZU	ISUZU 4BE1/6- Wheel Truck/NKR58L	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3501	ISUZU	ISUZU 4BE1/6- Wheel Truck/NKR58L	Engine: N/A			TRUCKS	O-1503	Oil Filter
3502	ISUZU	ISUZU 4BE1/6- Wheel Truck/NKR58LU5	Engine: N/A			TRUCKS	A-6012	Air Filter
3503	ISUZU	ISUZU 4BE1/6- Wheel Truck/NKR58LU5	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3504	ISUZU	ISUZU 4BE1/6- Wheel Truck/NKR58LU5	Engine: N/A			TRUCKS	O-1503	Oil Filter
3505	ISUZU	ISUZU 4BE1/6- Wheel Truck/NKR58LX5	Engine: N/A			TRUCKS	A-6012	Air Filter
3506	ISUZU	ISUZU 4BE1/6- Wheel Truck/NKR58LX5	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3507	ISUZU	ISUZU 4BE1/6- Wheel Truck/NKR58LX5	Engine: N/A			TRUCKS	O-1503	Oil Filter

Sakura Filter				ENGINE APPLICATION				
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
3508	ISUZU	ISUZU 4FC1 1993-1995/KD-WFR62	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3509	ISUZU	ISUZU 4FC1T 1984-1987/QWFR51	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3510	ISUZU	ISUZU 4FC1T 1987-1990/QWFR51	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3511	ISUZU	ISUZU 4FC1T 1987-1990/QWFS51	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3512	ISUZU	ISUZU 4FC1T 1991/QWFR51	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3513	ISUZU	ISUZU 4FD1 1983-1990/NWFS53	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3514	ISUZU	ISUZU 4FD1 1983-1991/NWFR53	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3515	ISUZU	ISUZU 4FD1 1987-1990/QWFS62	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3516	ISUZU	ISUZU 4FD1 1990-1991/QWFS51	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3517	ISUZU	ISUZU 4FD1 DIESEL/WFR 2.2L 4X4	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3518	ISUZU	ISUZU 4FG1 1987-1988/NWFR53	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3519	ISUZU	ISUZU 4FG1 1988-1990/U-NGS62	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3520	ISUZU	ISUZU 4FG1 1988-1995/U-NFR62	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3521	ISUZU	ISUZU 4FG1 1990-1995/QWFS62	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3522	ISUZU	ISUZU 4FG1 1990-1995/SWFS62	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3523	ISUZU	ISUZU 4FG1 1990-1995/U-WFS62	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3524	ISUZU	ISUZU 4FG1T 1991-1993/QWFR62	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3525	ISUZU	ISUZU 4FG1T 1993-1995/KD-WFR62	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3526	ISUZU	ISUZU 4HE1-TC/6- Wheel Truck/NQR70	Engine: N/A			TRUCKS	A-1019	Air Filter
3527	ISUZU	ISUZU 4HE1-TC/6- Wheel Truck/NQR70	Engine: N/A			TRUCKS	C-1515	Oil Filter
3528	ISUZU	ISUZU 4HE1-TC/6- Wheel Truck/NQR70	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3529	ISUZU	ISUZU 4HE1-TC/6- Wheel Truck/NQR70LY52 EURO 2	Engine: N/A			TRUCKS	A-1019	Air Filter
3530	ISUZU	ISUZU 4HE1-TC/6- Wheel Truck/NQR70LY52 EURO 2	Engine: N/A			TRUCKS	C-1534	Oil Filter
3531	ISUZU	ISUZU 4HE1-TC/6- Wheel Truck/NQR70LY52 EURO 2	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3532	ISUZU	ISUZU 4HE1-TC/6- Wheel Truck/NQR70RY52 EURO 2	Engine: N/A			TRUCKS	A-1019	Air Filter
3533	ISUZU	ISUZU 4HE1-TC/6- Wheel Truck/NQR70RY52 EURO 2	Engine: N/A			TRUCKS	C-1534	Oil Filter
3534	ISUZU	ISUZU 4HE1-TC/6- Wheel Truck/NQR70RY52 EURO 2	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3535	ISUZU	ISUZU 4HF1/6- Wheel Truck/NKR66LX5	Engine: N/A			TRUCKS	A-6012	Air Filter
3536	ISUZU	ISUZU 4HF1/6- Wheel Truck/NKR66LX5	Engine: N/A			TRUCKS	C-1515	Oil Filter
3537	ISUZU	ISUZU 4HF1/6- Wheel Truck/NKR66LX5	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3538	ISUZU	ISUZU 4HF1/6- Wheel Truck/NPR66LX5	Engine: N/A			TRUCKS	A-6012	Air Filter
3539	ISUZU	ISUZU 4HF1/6- Wheel Truck/NPR66LX5	Engine: N/A			TRUCKS	C-1515	Oil Filter
3540	ISUZU	ISUZU 4HF1/6- Wheel Truck/NPR66LX5	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3541	ISUZU	ISUZU 4HF1/6- Wheel Truck/NPR66PX5	Engine: N/A			TRUCKS	A-6012	Air Filter
3542	ISUZU	ISUZU 4HF1/6- Wheel Truck/NPR66PX5	Engine: N/A			TRUCKS	C-1515	Oil Filter
3543	ISUZU	ISUZU 4HF1/6- Wheel Truck/NPR66PX5	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3544	ISUZU	ISUZU 4HF1/6- Wheel Truck/NQR66LX5	Engine: N/A			TRUCKS	A-6012	Air Filter
3545	ISUZU	ISUZU 4HF1/6- Wheel Truck/NQR66LX5	Engine: N/A			TRUCKS	C-1515	Oil Filter
3546	ISUZU	ISUZU 4HF1/6- Wheel Truck/NQR66LX5	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3547	ISUZU	ISUZU 4HF1/6- Wheel Truck/NQR66RX5	Engine: N/A			TRUCKS	A-6012	Air Filter
3548	ISUZU	ISUZU 4HF1/6- Wheel Truck/NQR66RX5	Engine: N/A			TRUCKS	C-1515	Oil Filter
3549	ISUZU	ISUZU 4HF1/6- Wheel Truck/NQR66RX5	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3550	ISUZU	ISUZU 4HG1-T/6- Wheel Truck/NKR71 EURO 2	Engine: N/A			TRUCKS	C-1515	Oil Filter
3551	ISUZU	ISUZU 4HG1-T/6- Wheel Truck/NKR71 EURO 2	Engine: N/A			TRUCKS	FC-1505	Fuel Filter
3552	ISUZU	ISUZU 4HG1-T/6- Wheel Truck/NPR71 EURO 2	Engine: N/A			TRUCKS	C-1515	Oil Filter
3553	ISUZU	ISUZU 4HG1-T/6- Wheel Truck/NPR71 EURO 2	Engine: N/A			TRUCKS	FC-1505	Fuel Filter
3554	ISUZU	ISUZU 4HG1-T/6- Wheel Truck/NQR71 EURO 2	Engine: N/A			TRUCKS	C-1515	Oil Filter
3555	ISUZU	ISUZU 4HG1-T/6- Wheel Truck/NQR71 EURO 2	Engine: N/A			TRUCKS	FC-1505	Fuel Filter
3556	ISUZU	ISUZU 4HK1-TCS/6- Wheel Truck/NQR75RY52E EURO 3	Engine: N/A			TRUCKS	A-1019	Air Filter
3557	ISUZU	ISUZU 4HK1-TCS/6- Wheel Truck/NQR75RY52E EURO 3	Engine: N/A			TRUCKS	C-1534	Oil Filter
3558	ISUZU	ISUZU 4JB1-TC/6- Wheel Truck/NKR55E12 EURO 2	Engine: N/A			TRUCKS	A-6012	Air Filter
3559	ISUZU	ISUZU 4JB1-TC/6- Wheel Truck/NKR55E12 EURO 2	Engine: N/A			TRUCKS	C-1712	Oil Filter
3560	ISUZU	ISUZU 4JB1-TC/6- Wheel Truck/NKR55E12 EURO 2	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3561	ISUZU	ISUZU 4JB1-TC/6- Wheel Truck/NKR55E52 EURO 2	Engine: N/A			TRUCKS	A-6012	Air Filter
3562	ISUZU	ISUZU 4JB1-TC/6- Wheel Truck/NKR55E52 EURO 2	Engine: N/A			TRUCKS	C-1712	Oil Filter

Sakura Filter				ENGINE APPLICATION				
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
3563	ISUZU	ISUZU 4JB1-TC/6- Wheel Truck/NKR55E52 EURO 2	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3564	ISUZU	ISUZU 4JB1-TC/6- Wheel Truck/NKR55E52A EURO 2	Engine: N/A			TRUCKS	A-6012	Air Filter
3565	ISUZU	ISUZU 4JB1-TC/6- Wheel Truck/NKR55E52A EURO 2	Engine: N/A			TRUCKS	C-1712	Oil Filter
3566	ISUZU	ISUZU 4JB1-TC/6- Wheel Truck/NKR55E52A EURO 2	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3567	ISUZU	ISUZU 4JB1-TC/6- Wheel Truck/NKR55EY52 EURO 2	Engine: N/A			TRUCKS	A-6012	Air Filter
3568	ISUZU	ISUZU 4JB1-TC/6- Wheel Truck/NKR55EY52 EURO 2	Engine: N/A			TRUCKS	C-1712	Oil Filter
3569	ISUZU	ISUZU 4JB1-TC/6- Wheel Truck/NKR55EY52 EURO 2	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3570	ISUZU	ISUZU 4JB1-TC/6- Wheel Truck/NKR55EY52A EURO 2	Engine: N/A			TRUCKS	A-6012	Air Filter
3571	ISUZU	ISUZU 4JB1-TC/6- Wheel Truck/NKR55EY52A EURO 2	Engine: N/A			TRUCKS	C-1712	Oil Filter
3572	ISUZU	ISUZU 4JB1-TC/6- Wheel Truck/NKR55EY52A EURO 2	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3573	ISUZU	ISUZU 4JB1/4- Wheel Truck/NKR552EU1	Engine: N/A			TRUCKS	A-1502	Air Filter
3574	ISUZU	ISUZU 4JB1/4- Wheel Truck/NKR552EU1	Engine: N/A			TRUCKS	AS-1502	Air Filter
3575	ISUZU	ISUZU 4JB1/4- Wheel Truck/NKR552EU1	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3576	ISUZU	ISUZU 4JB1/4- Wheel Truck/NKR552EU1	Engine: N/A			TRUCKS	O-1502	Oil Filter
3577	ISUZU	ISUZU 4JB1/4- Wheel Truck/NKR552U1	Engine: N/A			TRUCKS	A-1502	Air Filter
3578	ISUZU	ISUZU 4JB1/4- Wheel Truck/NKR552U1	Engine: N/A			TRUCKS	AS-1502	Air Filter
3579	ISUZU	ISUZU 4JB1/4- Wheel Truck/NKR552U1	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3580	ISUZU	ISUZU 4JB1/4- Wheel Truck/NKR552U1	Engine: N/A			TRUCKS	O-1502	Oil Filter
3581	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR552U5	Engine: N/A			TRUCKS	A-1502	Air Filter
3582	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR552U5	Engine: N/A			TRUCKS	AS-1502	Air Filter
3583	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR552U5	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3584	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR552U5	Engine: N/A			TRUCKS	O-1502	Oil Filter
3585	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR555U5	Engine: N/A			TRUCKS	A-1502	Air Filter
3586	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR555U5	Engine: N/A			TRUCKS	AS-1502	Air Filter
3587	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR555U5	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3588	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR555U5	Engine: N/A			TRUCKS	O-1502	Oil Filter
3589	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR55EU5	Engine: N/A			TRUCKS	A-1502	Air Filter
3590	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR55EU5	Engine: N/A			TRUCKS	AS-1502	Air Filter
3591	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR55EU5	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3592	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR55EU5	Engine: N/A			TRUCKS	O-1502	Oil Filter
3593	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR55EX1	Engine: N/A			TRUCKS	A-1502	Air Filter
3594	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR55EX1	Engine: N/A			TRUCKS	AS-1502	Air Filter
3595	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR55EX1	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3596	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR55EX1	Engine: N/A			TRUCKS	O-1502	Oil Filter
3597	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR55EX5	Engine: N/A			TRUCKS	A-1502	Air Filter
3598	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR55EX5	Engine: N/A			TRUCKS	AS-1502	Air Filter
3599	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR55EX5	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3600	ISUZU	ISUZU 4JB1/6- Wheel Truck/NKR55EX5	Engine: N/A			TRUCKS	O-1502	Oil Filter
3601	ISUZU	ISUZU 4ZC1 1990-1995/LWFR12	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3602	ISUZU	ISUZU 4ZC1 1990-1995/TWFR12	Engine: N/A			TRUCKS	FC-1006	Fuel Filter
3603	ISUZU	ISUZU 6 SA1/P-FSR13-([1985/1986])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3604	ISUZU	ISUZU 6.494L DIESEL/FSR-([1988/1991])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3605	ISUZU	ISUZU 6.494L DIESEL/NRR-([1988/1991])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3606	ISUZU	ISUZU 6.494L/NRR-([1993/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3607	ISUZU	ISUZU 6BB1/6- Wheel Truck/SBR372	Engine: N/A			TRUCKS	AS-5628	Air Filter
3608	ISUZU	ISUZU 6BB1/6- Wheel Truck/SBR372	Engine: N/A			TRUCKS	O-1301	Oil Filter
3609	ISUZU	ISUZU 6BB1/6- Wheel Truck/SBR422	Engine: N/A			TRUCKS	AS-5628	Air Filter
3610	ISUZU	ISUZU 6BB1/6- Wheel Truck/SBR422	Engine: N/A			TRUCKS	O-1301	Oil Filter
3611	ISUZU	ISUZU 6BB1/6- Wheel Truck/SCR550	Engine: N/A			TRUCKS	AS-5628	Air Filter
3612	ISUZU	ISUZU 6BB1/6- Wheel Truck/SCR550	Engine: N/A			TRUCKS	O-1301	Oil Filter
3613	ISUZU	ISUZU 6BD1 -	Engine: N/A			ENGINES, GENSETS, COOLING UNITS	FC-1503	Fuel Filter
3614	ISUZU	ISUZU 6BD1-T 353 CID 5.785L/FSR-([1987/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3615	ISUZU	ISUZU 6BD1-T 353 CID 5.785L/FTR-([1987/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3616	ISUZU	ISUZU 6BD1-T DIESEL/EVR-([1986/1991])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3617	ISUZU	ISUZU 6BD1/10- Wheel Truck/JCM490Y	Engine: N/A			TRUCKS	AS-5628	Air Filter
3618	ISUZU	ISUZU 6BD1/10- Wheel Truck/JCM490Y	Engine: N/A			TRUCKS	O-1301	Oil Filter
3619	ISUZU	ISUZU 6BD1/10- Wheel Truck/JCM530YX	Engine: N/A			TRUCKS	AS-5628	Air Filter
3620	ISUZU	ISUZU 6BD1/10- Wheel Truck/JCM530YX	Engine: N/A			TRUCKS	O-1301	Oil Filter

Sakura Filter					ENGINE APPLICATION			
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
3621	ISUZU	ISUZU 6BD1/10- Wheel Truck/JCZ520Y	Engine: N/A			TRUCKS	AS-5628	Air Filter
3622	ISUZU	ISUZU 6BD1/10- Wheel Truck/JCZ520Y	Engine: N/A			TRUCKS	O-1301	Oil Filter
3623	ISUZU	ISUZU 6BD1/10- Wheel Truck/JCZ520YX	Engine: N/A			TRUCKS	AS-5628	Air Filter
3624	ISUZU	ISUZU 6BD1/10- Wheel Truck/JCZ520YX	Engine: N/A			TRUCKS	O-1301	Oil Filter
3625	ISUZU	ISUZU 6BD1/10- Wheel Truck/JZZ	Engine: N/A			TRUCKS	AS-5628	Air Filter
3626	ISUZU	ISUZU 6BD1/10- Wheel Truck/JZZ	Engine: N/A			TRUCKS	O-1301	Oil Filter
3627	ISUZU	ISUZU 6BD1/6- Wheel Truck/JCR360Y	Engine: N/A			TRUCKS	AS-5628	Air Filter
3628	ISUZU	ISUZU 6BD1/6- Wheel Truck/JCR360Y	Engine: N/A			TRUCKS	O-1301	Oil Filter
3629	ISUZU	ISUZU 6BD1/6- Wheel Truck/JCR400Y	Engine: N/A			TRUCKS	AS-5628	Air Filter
3630	ISUZU	ISUZU 6BD1/6- Wheel Truck/JCR400Y	Engine: N/A			TRUCKS	O-1301	Oil Filter
3631	ISUZU	ISUZU 6BD1/6- Wheel Truck/JCR460Y	Engine: N/A			TRUCKS	AS-5628	Air Filter
3632	ISUZU	ISUZU 6BD1/6- Wheel Truck/JCR460Y	Engine: N/A			TRUCKS	O-1301	Oil Filter
3633	ISUZU	ISUZU 6BD1/6- Wheel Truck/JCR500Y	Engine: N/A			TRUCKS	AS-5628	Air Filter
3634	ISUZU	ISUZU 6BD1/6- Wheel Truck/JCR500Y	Engine: N/A			TRUCKS	O-1301	Oil Filter
3635	ISUZU	ISUZU 6BD1/6- Wheel Truck/JCS	Engine: N/A			TRUCKS	AS-5628	Air Filter
3636	ISUZU	ISUZU 6BD1/6- Wheel Truck/JCS	Engine: N/A			TRUCKS	O-1301	Oil Filter
3637	ISUZU	ISUZU 6BD1/ISUZU 6BD1	Engine: N/A			ENGINES,GENSETS,COOLIN G UNITS	FC-2701	Fuel Filter
3638	ISUZU	ISUZU 6BD1T/F SERIES P-FS11	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3639	ISUZU	ISUZU 6BD1T/F SERIES P-FTR11	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3640	ISUZU	ISUZU 6BD1T/P-ESR 11-([1985/1989])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3641	ISUZU	ISUZU 6BD1T/P-FRD11-([1984/1985])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3642	ISUZU	ISUZU 6BD1T/P-FRD11-([1985/1990])	Engine: N/A			TRUCKS	FC-5701	Fuel Filter
3643	ISUZU	ISUZU 6BD1T/P-FRG11-([1984/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3644	ISUZU	ISUZU 6BD1T/P-FRR11-([1985/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3645	ISUZU	ISUZU 6BD1T/P-FSD12-([1988/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3646	ISUZU	ISUZU 6BD1T/P-FSR11-([1984/1985])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3647	ISUZU	ISUZU 6BD1T/P-FSR11-([1985/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3648	ISUZU	ISUZU 6BD1T/P-FSR12-([1985/2007])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3649	ISUZU	ISUZU 6BD1T/P-FTR11-([1984/1985])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3650	ISUZU	ISUZU 6BD1T/P-FTR11-([1985/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3651	ISUZU	ISUZU 6BG1-NA 396 CID/FSR-([1988/1991])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3652	ISUZU	ISUZU 6BG1-NA 396 CID/NRR-([1988/1991])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3653	ISUZU	ISUZU 6BG1-TC 396 6.5L/ISUZU 6BG1-TC 396 6.5L	Engine: N/A			MARINE	FC-2701	Fuel Filter
3654	ISUZU	ISUZU 6BG1-TC/NRR-([1993/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3655	ISUZU	ISUZU 6BG1/EXR 12-([1990/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3656	ISUZU	ISUZU 6BG1/P-ERS12-([1989/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3657	ISUZU	ISUZU 6BG1/P-ESR12-([1985/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3658	ISUZU	ISUZU 6BG1/P-FRD12-([1984/1985])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3659	ISUZU	ISUZU 6BG1/P-FRD12-([1985/1986])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3660	ISUZU	ISUZU 6BG1/P-FRR12-([1984/1984])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3661	ISUZU	ISUZU 6BG1/P-FRR12-([1985/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3662	ISUZU	ISUZU 6BG1/P-FRS12 4WD-([1984/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3663	ISUZU	ISUZU 6BG1/P-FRS12 4WD-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3664	ISUZU	ISUZU 6BG1/P-FSD12-([1998/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3665	ISUZU	ISUZU 6BG1/P-FSR12-([1985/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3666	ISUZU	ISUZU 6BG1/P-FSS12 4WD-([1986/1995])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3667	ISUZU	ISUZU 6BG1/P-FTR12-([1985/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3668	ISUZU	ISUZU 6BG1/P-NRR12-([1985/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3669	ISUZU	ISUZU 6BG1/U-ETR13-([1990/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3670	ISUZU	ISUZU 6BG1/U-FTR21-([1990/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3671	ISUZU	ISUZU 6BG1/W-EXR12-([1990/1984])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3672	ISUZU	ISUZU 6BG1-TC 396 6.5L -	Engine: N/A			MARINE	FC-1503	Fuel Filter
3673	ISUZU	ISUZU 6BG1T/ESR12-([1990/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3674	ISUZU	ISUZU 6BG1T/F SERIES U-FTR12 4WD	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3675	ISUZU	ISUZU 6BG1T/P-ESR12-([1990/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3676	ISUZU	ISUZU 6BG1T/P-FSR12-([1985/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3677	ISUZU	ISUZU 6BG1T/U-ESR12-([1990/1994])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3678	ISUZU	ISUZU 6BG1T/U-ESR32-([1990/1994])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3679	ISUZU	ISUZU 6BG1T/U-FRR12-([1990/1994])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3680	ISUZU	ISUZU 6BG1T/U-FSR12-([1994/2000])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3681	ISUZU	ISUZU 6BG1T/U-FTR12-([1990/1994])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3682	ISUZU	ISUZU 6BG1T/W-ESR12-([1990/1994])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter



Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
3683	ISUZU	ISUZU 6BG1T/W-ETR12-([1989/1994])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3684	ISUZU	ISUZU 6GB1/P-FRD12-([1985/1986])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3685	ISUZU	ISUZU 6HA1/KK-LR233F1-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3686	ISUZU	ISUZU 6HA1/NEFSR87-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3687	ISUZU	ISUZU 6HE1/KK-ESR33-([1990/1995])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3688	ISUZU	ISUZU 6HE1/KK-FRD33-([1990/1995])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3689	ISUZU	ISUZU 6HE1/KK-FRD33-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3690	ISUZU	ISUZU 6HE1T/KK-ESR34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3691	ISUZU	ISUZU 6HH1/KC-GR433F-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3692	ISUZU	ISUZU 6HH1/KK-FRR33-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3693	ISUZU	ISUZU 6HH1/KK-FRS33 4WD-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3694	ISUZU	ISUZU 6HH1/KK-FSD33-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3695	ISUZU	ISUZU 6HH1/KK-FSR33-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3696	ISUZU	ISUZU 6HH1/KK-FSS33 4WD-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3697	ISUZU	ISUZU 6HH1/KK-FTR33-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3698	ISUZU	ISUZU 6HH1/KK-GR433-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3699	ISUZU	ISUZU 6HH1/KK-LR233-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3700	ISUZU	ISUZU 6HH1/KK-LR233E1-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3701	ISUZU	ISUZU 6HH1/KK-LR233F1-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3702	ISUZU	ISUZU 6HH1/KK-LR233J1-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3703	ISUZU	ISUZU 6HH1/KK-LR333E1-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3704	ISUZU	ISUZU 6HH1/KK-LR333F1-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3705	ISUZU	ISUZU 6HH1/KK-LR333J1-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3706	ISUZU	ISUZU 6HH1/KK-LT233-([1988/1991])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3707	ISUZU	ISUZU 6HH1/KK-LT233J1-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3708	ISUZU	ISUZU 6HH1/KK-LT333-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3709	ISUZU	ISUZU 6HH1/KK-LT333J1-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3710	ISUZU	ISUZU 6HH1/KL-FSD33-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3711	ISUZU	ISUZU 6HH1/KL-FSR33-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3712	ISUZU	ISUZU 6HH1/KL-FSS33-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3713	ISUZU	ISUZU 6HH1/KL-FTR33-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3714	ISUZU	ISUZU 6HH1S/KK-FFR33G4-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3715	ISUZU	ISUZU 6HH1S/KK-FSR33G4-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3716	ISUZU	ISUZU 6HH1S/KK-FTR33G4-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3717	ISUZU	ISUZU 6HK1T/KK-FFR34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3718	ISUZU	ISUZU 6HK1T/KK-FRD34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3719	ISUZU	ISUZU 6HK1T/KK-FRR34-([1993/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3720	ISUZU	ISUZU 6HK1T/KK-FRR34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3721	ISUZU	ISUZU 6HK1T/KK-FSD34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3722	ISUZU	ISUZU 6HK1T/KK-FSR34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3723	ISUZU	ISUZU 6HK1T/KK-FTR34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3724	ISUZU	ISUZU 6HK1T/KK-FTS34 4WD-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3725	ISUZU	ISUZU 6HK1T/KK-GSR34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3726	ISUZU	ISUZU 6HK1T/KL-FSD34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3727	ISUZU	ISUZU 6HK1T/KL-FSR34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3728	ISUZU	ISUZU 6HK1T/KL-FTR34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3729	ISUZU	ISUZU 6HK1T/KL-FTS34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3730	ISUZU	ISUZU 6HK1T/KL-FTZ34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3731	ISUZU	ISUZU 6HK1T/KL-FVZ34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3732	ISUZU	ISUZU 6HK1T/KL-GTR34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3733	ISUZU	ISUZU 6HK1T/KL-LV834-([2000/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3734	ISUZU	ISUZU 6HK1TC/FSR-([2003/2004])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3735	ISUZU	ISUZU 6HK1TC/FTR-([2003/2004])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3736	ISUZU	ISUZU 6HK1TC/FVR-([2003/2004])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3737	ISUZU	ISUZU 6HK1TC/FXR-([2003/2004])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3738	ISUZU	ISUZU 6HK1TCC/KK-FRR34G4-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3739	ISUZU	ISUZU 6HK1TCC/KK-FSR34G4-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3740	ISUZU	ISUZU 6HK1TCC/KK-FTR34G4-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3741	ISUZU	ISUZU 6HK1TCN/FRR-([2002/2004])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3742	ISUZU	ISUZU 6HK1TCN/KK-FRR34G4-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter



Sakura Filter				ENGINE APPLICATION				
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
3743	ISUZU	ISUZU 6HK1TCN/KK-FSR34G4-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3744	ISUZU	ISUZU 6HKR34/KL-FTR34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3745	ISUZU	ISUZU 6HKT1T/KK-FTS34-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3746	ISUZU	ISUZU 6SA1-T 513 CID/EVR-([1988/1988])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3747	ISUZU	ISUZU 6SA1-T 513 CID/FVR-([1988/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3748	ISUZU	ISUZU 6SA1/10- Wheel Truck/FXM13NY	Engine: N/A			TRUCKS	O-1301	Oil Filter
3749	ISUZU	ISUZU 6SA1/10- Wheel Truck/FXM13NY	Engine: N/A			TRUCKS	O-1511	Oil Filter
3750	ISUZU	ISUZU 6SA1/10- Wheel Truck/FXZ13KFY	Engine: N/A			TRUCKS	O-1301	Oil Filter
3751	ISUZU	ISUZU 6SA1/10- Wheel Truck/FXZ13KFY	Engine: N/A			TRUCKS	O-1511	Oil Filter
3752	ISUZU	ISUZU 6SA1/10- Wheel Truck/FXZ13NFY	Engine: N/A			TRUCKS	O-1301	Oil Filter
3753	ISUZU	ISUZU 6SA1/10- Wheel Truck/FXZ13NFY	Engine: N/A			TRUCKS	O-1511	Oil Filter
3754	ISUZU	ISUZU 6SA1/10- Wheel Truck/FXZ13NY	Engine: N/A			TRUCKS	O-1301	Oil Filter
3755	ISUZU	ISUZU 6SA1/10- Wheel Truck/FXZ13NY	Engine: N/A			TRUCKS	O-1511	Oil Filter
3756	ISUZU	ISUZU 6SA1/P-FRR13-([1985/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3757	ISUZU	ISUZU 6SA1/P-FSR13-([1986/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3758	ISUZU	ISUZU 6SA1/P-FTR13-([1985/1986])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3759	ISUZU	ISUZU 6SA1/P-FTR13-([1986/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3760	ISUZU	ISUZU 6SA1/U-FRR13-([1990/1994])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3761	ISUZU	ISUZU 6SA1/U-FTR13-([1990/1994])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3762	ISUZU	ISUZU 6SD1-TC/10- Wheel Tractor/FXZ23NZP	Engine: N/A			TRUCKS	A-1013	Air Filter
3763	ISUZU	ISUZU 6SD1-TC/10- Wheel Tractor/FXZ23NZP	Engine: N/A			TRUCKS	A-7607	Air Filter
3764	ISUZU	ISUZU 6SD1-TC/10- Wheel Tractor/FXZ23NZP	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3765	ISUZU	ISUZU 6SD1-TC/10- Wheel Tractor/FXZ23NZP	Engine: N/A			TRUCKS	O-1301	Oil Filter
3766	ISUZU	ISUZU 6SD1-TC/10- Wheel Tractor/FXZ23NZPF	Engine: N/A			TRUCKS	A-1013	Air Filter
3767	ISUZU	ISUZU 6SD1-TC/10- Wheel Tractor/FXZ23NZPF	Engine: N/A			TRUCKS	A-7607	Air Filter
3768	ISUZU	ISUZU 6SD1-TC/10- Wheel Tractor/FXZ23NZPF	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3769	ISUZU	ISUZU 6SD1-TC/10- Wheel Tractor/FXZ23NZPF	Engine: N/A			TRUCKS	O-1301	Oil Filter
3770	ISUZU	ISUZU 6SD1-TC/10- Wheel Tractor/GXZ23KZ EURO 2	Engine: N/A			TRUCKS	A-1013	Air Filter
3771	ISUZU	ISUZU 6SD1-TC/10- Wheel Tractor/GXZ23KZ EURO 2	Engine: N/A			TRUCKS	A-7607	Air Filter
3772	ISUZU	ISUZU 6SD1-TC/10- Wheel Tractor/GXZ23KZ EURO 2	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3773	ISUZU	ISUZU 6SD1-TC/10- Wheel Tractor/GXZ23KZ EURO 2	Engine: N/A			TRUCKS	O-1301	Oil Filter
3774	ISUZU	ISUZU 6SD1-TC/10- Wheel Tractor/GXZ23KZF EURO 2	Engine: N/A			TRUCKS	A-1013	Air Filter
3775	ISUZU	ISUZU 6SD1-TC/10- Wheel Tractor/GXZ23KZF EURO 2	Engine: N/A			TRUCKS	A-7607	Air Filter
3776	ISUZU	ISUZU 6SD1-TC/10- Wheel Tractor/GXZ23KZF EURO 2	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3777	ISUZU	ISUZU 6SD1-TC/10- Wheel Tractor/GXZ23KZF EURO 2	Engine: N/A			TRUCKS	O-1301	Oil Filter
3778	ISUZU	ISUZU 6SD1/10- Wheel Truck/FXZ23KF	Engine: N/A			TRUCKS	A-6006	Air Filter
3779	ISUZU	ISUZU 6SD1/10- Wheel Truck/FXZ23KF	Engine: N/A			TRUCKS	A-6007	Air Filter
3780	ISUZU	ISUZU 6SD1/10- Wheel Truck/FXZ23KF	Engine: N/A			TRUCKS	O-1301	Oil Filter
3781	ISUZU	ISUZU 6SD1/10- Wheel Truck/FXZ23NF	Engine: N/A			TRUCKS	A-6006	Air Filter
3782	ISUZU	ISUZU 6SD1/10- Wheel Truck/FXZ23NF	Engine: N/A			TRUCKS	A-6007	Air Filter
3783	ISUZU	ISUZU 6SD1/10- Wheel Truck/FXZ23NF	Engine: N/A			TRUCKS	O-1301	Oil Filter
3784	ISUZU	ISUZU 6SD1H-TC/10- Wheel Tractor/GXZ23KZH2 EURO 2	Engine: N/A			TRUCKS	A-1013	Air Filter
3785	ISUZU	ISUZU 6SD1H-TC/10- Wheel Tractor/GXZ23KZH2 EURO 2	Engine: N/A			TRUCKS	A-5631	Air Filter
3786	ISUZU	ISUZU 6SD1H-TC/10- Wheel Tractor/GXZ23KZH2 EURO 2	Engine: N/A			TRUCKS	O-1301	Oil Filter
3787	ISUZU	ISUZU 6SD1H-TC/10- Wheel Tractor/GXZ23KZHF2 EURO 2	Engine: N/A			TRUCKS	A-1013	Air Filter
3788	ISUZU	ISUZU 6SD1H-TC/10- Wheel Tractor/GXZ23KZHF2 EURO 2	Engine: N/A			TRUCKS	A-5631	Air Filter
3789	ISUZU	ISUZU 6SD1H-TC/10- Wheel Tractor/GXZ23KZHF2 EURO 2	Engine: N/A			TRUCKS	O-1301	Oil Filter
3790	ISUZU	ISUZU 6SD1H-TC/10- Wheel Truck/BU35K	Engine: N/A			TRUCKS	A-6006	Air Filter
3791	ISUZU	ISUZU 6SD1H-TC/10- Wheel Truck/BU35K	Engine: N/A			TRUCKS	A-6007	Air Filter
3792	ISUZU	ISUZU 6SD1H-TC/10- Wheel Truck/BU35K	Engine: N/A			TRUCKS	C-1506	Oil Filter
3793	ISUZU	ISUZU 6SD1H-TC/10- Wheel Truck/BU35K	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3794	ISUZU	ISUZU 6SD1H-TC/10- Wheel Truck/CPM	Engine: N/A			TRUCKS	A-6006	Air Filter

Sakura Filter				ENGINE APPLICATION				
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
3795	ISUZU	ISUZU 6SD1H-TC/10- Wheel Truck/CPM	Engine: N/A			TRUCKS	A-6007	Air Filter
3796	ISUZU	ISUZU 6SD1H-TC/10- Wheel Truck/CPM	Engine: N/A			TRUCKS	C-1506	Oil Filter
3797	ISUZU	ISUZU 6SD1H-TC/10- Wheel Truck/CPM	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3798	ISUZU	ISUZU 6SD1H-TC/10- Wheel Truck/SPM	Engine: N/A			TRUCKS	A-6006	Air Filter
3799	ISUZU	ISUZU 6SD1H-TC/10- Wheel Truck/SPM	Engine: N/A			TRUCKS	A-6007	Air Filter
3800	ISUZU	ISUZU 6SD1H-TC/10- Wheel Truck/SPM	Engine: N/A			TRUCKS	C-1506	Oil Filter
3801	ISUZU	ISUZU 6SD1H-TC/10- Wheel Truck/SPM	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3802	ISUZU	ISUZU 6SD1H-TC/10- Wheel Truck/SPZ	Engine: N/A			TRUCKS	A-6006	Air Filter
3803	ISUZU	ISUZU 6SD1H-TC/10- Wheel Truck/SPZ	Engine: N/A			TRUCKS	A-6007	Air Filter
3804	ISUZU	ISUZU 6SD1H-TC/10- Wheel Truck/SPZ	Engine: N/A			TRUCKS	C-1506	Oil Filter
3805	ISUZU	ISUZU 6SD1H-TC/10- Wheel Truck/SPZ	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3806	ISUZU	ISUZU 7.1L6HE1-TC/FRR-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3807	ISUZU	ISUZU 8.413L DIESEL/EVR-([1988/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3808	ISUZU	ISUZU 8.413L DIESEL/FVR-([1998/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3809	ISUZU	ISUZU C240/4- Wheel Truck/TLD11	Engine: N/A			TRUCKS	A-1502	Air Filter
3810	ISUZU	ISUZU C240/4- Wheel Truck/TLD11	Engine: N/A			TRUCKS	AS-1502	Air Filter
3811	ISUZU	ISUZU C240/4- Wheel Truck/TLD11	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3812	ISUZU	ISUZU C240/4- Wheel Truck/TLD11	Engine: N/A			TRUCKS	O-1502	Oil Filter
3813	ISUZU	ISUZU C240/4- Wheel Truck/TLD13	Engine: N/A			TRUCKS	A-1502	Air Filter
3814	ISUZU	ISUZU C240/4- Wheel Truck/TLD13	Engine: N/A			TRUCKS	AS-1502	Air Filter
3815	ISUZU	ISUZU C240/4- Wheel Truck/TLD13	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3816	ISUZU	ISUZU C240/4- Wheel Truck/TLD13	Engine: N/A			TRUCKS	O-1502	Oil Filter
3817	ISUZU	ISUZU C240/4- Wheel Truck/TLD23	Engine: N/A			TRUCKS	A-1502	Air Filter
3818	ISUZU	ISUZU C240/4- Wheel Truck/TLD23	Engine: N/A			TRUCKS	AS-1502	Air Filter
3819	ISUZU	ISUZU C240/4- Wheel Truck/TLD23	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3820	ISUZU	ISUZU C240/4- Wheel Truck/TLD23	Engine: N/A			TRUCKS	O-1502	Oil Filter
3821	ISUZU	ISUZU C240/4- Wheel Truck/TLD33	Engine: N/A			TRUCKS	A-1502	Air Filter
3822	ISUZU	ISUZU C240/4- Wheel Truck/TLD33	Engine: N/A			TRUCKS	AS-1502	Air Filter
3823	ISUZU	ISUZU C240/4- Wheel Truck/TLD33	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3824	ISUZU	ISUZU C240/4- Wheel Truck/TLD33	Engine: N/A			TRUCKS	O-1502	Oil Filter
3825	ISUZU	ISUZU C240/6- Wheel Truck/TLD43	Engine: N/A			TRUCKS	A-1502	Air Filter
3826	ISUZU	ISUZU C240/6- Wheel Truck/TLD43	Engine: N/A			TRUCKS	AS-1502	Air Filter
3827	ISUZU	ISUZU C240/6- Wheel Truck/TLD43	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3828	ISUZU	ISUZU C240/6- Wheel Truck/TLD43	Engine: N/A			TRUCKS	O-1502	Oil Filter
3829	ISUZU	ISUZU C240/6- Wheel Truck/TLD53	Engine: N/A			TRUCKS	A-1502	Air Filter
3830	ISUZU	ISUZU C240/6- Wheel Truck/TLD53	Engine: N/A			TRUCKS	AS-1502	Air Filter
3831	ISUZU	ISUZU C240/6- Wheel Truck/TLD53	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3832	ISUZU	ISUZU C240/6- Wheel Truck/TLD53	Engine: N/A			TRUCKS	O-1502	Oil Filter
3833	ISUZU	ISUZU C240/6- Wheel Truck/TLD63	Engine: N/A			TRUCKS	A-1502	Air Filter
3834	ISUZU	ISUZU C240/6- Wheel Truck/TLD63	Engine: N/A			TRUCKS	AS-1502	Air Filter
3835	ISUZU	ISUZU C240/6- Wheel Truck/TLD63	Engine: N/A			TRUCKS	FC-1501	Fuel Filter
3836	ISUZU	ISUZU C240/6- Wheel Truck/TLD63	Engine: N/A			TRUCKS	O-1502	Oil Filter
3837	ISUZU	ISUZU DA120/10- Wheel Truck/TWD20	Engine: N/A			TRUCKS	O-1505	Oil Filter
3838	ISUZU	ISUZU DA120/10- Wheel Truck/TWD50	Engine: N/A			TRUCKS	O-1505	Oil Filter
3839	ISUZU	ISUZU DA120/10- Wheel Truck/TWD80	Engine: N/A			TRUCKS	O-1505	Oil Filter
3840	ISUZU	ISUZU DA120/6- Wheel Truck/TSD40	Engine: N/A			TRUCKS	O-1505	Oil Filter
3841	ISUZU	ISUZU DA120/6- Wheel Truck/TXD20	Engine: N/A			TRUCKS	O-1505	Oil Filter
3842	ISUZU	ISUZU DA120/6- Wheel Truck/TXD40	Engine: N/A			TRUCKS	O-1505	Oil Filter
3843	ISUZU	ISUZU DA120/6- Wheel Truck/TXD45	Engine: N/A			TRUCKS	O-1505	Oil Filter
3844	ISUZU	ISUZU DA120/6- Wheel Truck/TXD50	Engine: N/A			TRUCKS	O-1505	Oil Filter
3845	ISUZU	ISUZU DA640/SFR SERIES	Engine: N/A			TRUCKS	A-1010	Air Filter
3846	ISUZU	ISUZU DIESEL/FSR-([1987/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3847	ISUZU	ISUZU DIESEL/FTR-([1987/1990])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3848	ISUZU	ISUZU F SERIES 4 CYL 77 MOTOR	N/A			TRUCKS	EF-15130	Fuel Filter
3849	ISUZU	Isuzu FI026 -([N/A])	N/A			TRUCKS	EF-1509	Fuel Filter
3850	ISUZU	ISUZU MYY-5T -([N/A])	N/A			TRUCKS	EF-1509	Fuel Filter
3851	ISUZU	ISUZU MYY-6S -([N/A])	N/A			TRUCKS	EF-1509	Fuel Filter
3852	ISUZU	Isuzu R045. -([N/A])	N/A			TRUCKS	EF-1509	Fuel Filter
3853	ISUZU	ISUZU-6BG1/MR112-([1984/1985])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
3854	ISUZU	ISUZU/FVR950 -([N/A])	N/A			TRUCKS	FC-1509	Fuel Filter
3855	ISUZU	JCR360 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
3856	ISUZU	JCR360 - ISUZU 6BG1 1985 -1986	Engine: N/A			TRUCKS	A-6007	Air Filter
3857	ISUZU	JCR360 - ISUZU 6D1T	Engine: N/A			TRUCKS	A-6007	Air Filter
3858	ISUZU	JCR420 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter

Sakura Filter							ENGINE APPLICATION	
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
3859	ISUZU	JCR420 - ISUZU 6BD1 1980 -1982	Engine: N/A			TRUCKS	A-6007	Air Filter
3860	ISUZU	JCR420 - ISUZU 6BG1 1985 -1986	Engine: N/A			TRUCKS	A-6007	Air Filter
3861	ISUZU	JCR420 - ISUZU 6D1T	Engine: N/A			TRUCKS	A-6007	Air Filter
3862	ISUZU	JCR420B - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
3863	ISUZU	JCR420B - ISUZU 6D1T	Engine: N/A			TRUCKS	A-6007	Air Filter
3864	ISUZU	JCR500 - ISUZU 6BD1 1980 -1984	Engine: N/A			TRUCKS	A-6007	Air Filter
3865	ISUZU	JCR500 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
3866	ISUZU	JCR500 - ISUZU 6BD1 1980 -1982	Engine: N/A			TRUCKS	A-6007	Air Filter
3867	ISUZU	JCR500 - ISUZU 6BG1 1985 -1986	Engine: N/A			TRUCKS	A-6007	Air Filter
3868	ISUZU	JCR500 - ISUZU 6D1T	Engine: N/A			TRUCKS	A-6007	Air Filter
3869	ISUZU	JCR500 S - ISUZU 6BD1T 1984	Engine: N/A			TRUCKS	A-6007	Air Filter
3870	ISUZU	JCR500 TURBO - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
3871	ISUZU	JCR500S - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
3872	ISUZU	JCR500S - ISUZU 6D1T	Engine: N/A			TRUCKS	A-6007	Air Filter
3873	ISUZU	JCR500W - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
3874	ISUZU	JCR500W - ISUZU 6D1T	Engine: N/A			TRUCKS	A-6007	Air Filter
3875	ISUZU	JCS420 4X4 - ISUZU 6BD1 1983 -1984	Engine: N/A			TRUCKS	A-6007	Air Filter
3876	ISUZU	JCS420(4X4) - ISUZU 6BG1 1986	Engine: N/A			TRUCKS	A-6007	Air Filter
3877	ISUZU	JOURNEY	J05D-T			BUSES	A-1156	Air Filter
3878	ISUZU	JOURNEY	J05D-T			BUSES	A-1156	Air Filter
3879	ISUZU	JOURNEY	TD42			BUSES	A-6012	Air Filter
3880	ISUZU	JOURNEY	TD42			BUSES	A-6012	Air Filter
3881	ISUZU	JOURNEY	TD42			BUSES	A-6012	Air Filter
3882	ISUZU	JOURNEY	TD42			BUSES	A-6012	Air Filter
3883	ISUZU	JOURNEY	TD42			BUSES	A-6012	Air Filter
3884	ISUZU	JOURNEY	TD42			BUSES	A-6012	Air Filter
3885	ISUZU	JOURNEY	TD42			BUSES	A-6012	Air Filter
3886	ISUZU	JOURNEY	TD42			BUSES	A-6012	Air Filter
3887	ISUZU	JOURNEY	TD42			BUSES	A-6012	Air Filter
3888	ISUZU	JOURNEY	TD42			BUSES	A-6012	Air Filter
3889	ISUZU	JOURNEY	TD42			BUSES	A-6012	Air Filter
3890	ISUZU	JOURNEY	TD42			BUSES	A-6012	Air Filter
3891	ISUZU	JOURNEY	TD42-T			BUSES	A-6012	Air Filter
3892	ISUZU	JOURNEY	TD42-T			BUSES	A-6012	Air Filter
3893	ISUZU	JOURNEY	TD42-T			BUSES	A-6012	Air Filter
3894	ISUZU	JOURNEY	TD42-T			BUSES	A-6012	Air Filter
3895	ISUZU	JOURNEY	TD42-T			BUSES	A-6012	Air Filter
3896	ISUZU	JOURNEY	TD42-T			BUSES	A-6012	Air Filter
3897	ISUZU	JOURNEY M - 1971	Engine: N/A			TRUCKS	A-1817	Air Filter
3898	ISUZU	JSC420 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
3899	ISUZU	JSC420 - ISUZU 6BD1T	Engine: N/A			TRUCKS	A-6007	Air Filter
3900	ISUZU	K-CPA/CPM520 550 -	Engine: N/A			TRUCKS	O-1510	Oil Filter
3901	ISUZU	K-KAD41 - ISUZU C190 1975 -1984	Engine: N/A			TRUCKS	A-1817	Air Filter
3902	ISUZU	K-KAD42 - ISUZU C190 1981 -1984	Engine: N/A			TRUCKS	A-1817	Air Filter
3903	ISUZU	K-KAD42 - ISUZU C240 1978 -1984	Engine: N/A			TRUCKS	A-1817	Air Filter
3904	ISUZU	K-KAD51 - ISUZU C190 1975 -1984	Engine: N/A			TRUCKS	A-1817	Air Filter
3905	ISUZU	K-KAD52 - ISUZU C240 1978 -1982	Engine: N/A			TRUCKS	A-1817	Air Filter
3906	ISUZU	K-KAD52 - ISUZU C240 1983 -1984	Engine: N/A			TRUCKS	A-1817	Air Filter
3907	ISUZU	K-KAD52 - ISUZU C240 1985 -1987	Engine: N/A			TRUCKS	A-1817	Air Filter
3908	ISUZU	K-KAD52V - ISUZU C240 1978 -1984	Engine: N/A			TRUCKS	A-1817	Air Filter
3909	ISUZU	K-KT15 - ISUZU 4BC1 1980 -1981	Engine: N/A			TRUCKS	A-1505	Air Filter
3910	ISUZU	K-KT16 - ISUZU 4BC2 1981 -1983	Engine: N/A			TRUCKS	A-1505	Air Filter
3911	ISUZU	K-KT24 - ISUZU 4BC1 1980 -1981	Engine: N/A			TRUCKS	A-1505	Air Filter
3912	ISUZU	K-KT25 - ISUZU 4BC1 1980 -1981	Engine: N/A			TRUCKS	A-1505	Air Filter
3913	ISUZU	K-KT26 - ISUZU 4BC2 1981 -1983	Engine: N/A			TRUCKS	A-1505	Air Filter
3914	ISUZU	K-KT35 - ISUZU 4BC1 1980 -1981	Engine: N/A			TRUCKS	A-1505	Air Filter
3915	ISUZU	K-KT36 - ISUZU 4BC2 1981 -1983	Engine: N/A			TRUCKS	A-1505	Air Filter
3916	ISUZU	K-KT45 - ISUZU 4BC1 1980 -1981	Engine: N/A			TRUCKS	A-1505	Air Filter
3917	ISUZU	K-KT46 - ISUZU 4BC2 1981 -1983	Engine: N/A			TRUCKS	A-1505	Air Filter
3918	ISUZU	K-SMG481 - ISUZU 8PB1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3919	ISUZU	K-SMG521 - ISUZU 8PB1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3920	ISUZU	K-SMG571 - ISUZU 8PB1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3921	ISUZU	K-SMG631 - ISUZU 8PB1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3922	ISUZU	K-SMG701 - ISUZU 8PB1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter

Sakura Filter							ENGINE APPLICATION	
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
3923	ISUZU	K-SMG761 - ISUZU 8PB1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3924	ISUZU	K-SMK551 - ISUZU 8PB1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3925	ISUZU	K-SMK601 - ISUZU 8PB1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3926	ISUZU	K-SMK641 - ISUZU 8PB1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3927	ISUZU	K-SMK701 - ISUZU 8PB1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3928	ISUZU	K-SMR360 - ISUZU 8PB1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3929	ISUZU	K-SMR401 - ISUZU 8PB1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3930	ISUZU	K-SMR461 - ISUZU 8PB1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3931	ISUZU	K-SMR531 - ISUZU 8PB1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3932	ISUZU	K-SMR601 - ISUZU 8PB1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3933	ISUZU	K-SMR671 - ISUZU 8PB1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3934	ISUZU	K-SPM681.701 - ISUZU E120	Engine: N/A			TRUCKS	O-1510	Oil Filter
3935	ISUZU	K-SRG571 - ISUZU 10PA1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3936	ISUZU	K-SRG631 - ISUZU 10PA1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3937	ISUZU	K-SRG701 - ISUZU 10PA1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3938	ISUZU	K-SRG761 - ISUZU 10PA1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3939	ISUZU	K-SRK701 - ISUZU 10PA1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3940	ISUZU	K-SRM521 - ISUZU 10PA1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3941	ISUZU	K-SRM521.571.6 - ISUZU 10PA1	Engine: N/A			TRUCKS	O-1510	Oil Filter
3942	ISUZU	K-SRM571 - ISUZU 10PA1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3943	ISUZU	K-SRM601 - ISUZU 10PA1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3944	ISUZU	K-SRM651 - ISUZU 10PA1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3945	ISUZU	K-SRM681 - ISUZU 10PA1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3946	ISUZU	K-SRM701 - ISUZU 10PA1 1979 -1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
3947	ISUZU	K-TDJ50 - ISUZU 6QA1 1979 -1984	Engine: N/A			TRUCKS	AS-1024	Air Filter
3948	ISUZU	K-TDJ62 - ISUZU 6QA1 1979 -1984	Engine: N/A			TRUCKS	AS-1024	Air Filter
3949	ISUZU	K-TDJ72 - ISUZU 6QA1 1979 -1984	Engine: N/A			TRUCKS	AS-1024	Air Filter
3950	ISUZU	K-TLD23 - ISUZU C240 1975 -1981	Engine: N/A			TRUCKS	A-1817	Air Filter
3951	ISUZU	K-TLD24 - ISUZU 4BA1 1980 -1981	Engine: N/A			TRUCKS	A-1817	Air Filter
3952	ISUZU	K-TLD26 - ISUZU 4BC2 1981 -1983	Engine: N/A			TRUCKS	A-1505	Air Filter
3953	ISUZU	K-TLD26 - ISUZU 4BC2 1983 -1984	Engine: N/A			TRUCKS	A-1505	Air Filter
3954	ISUZU	K-TLD34 - ISUZU 4BA1 1980 -1981	Engine: N/A			TRUCKS	A-1817	Air Filter
3955	ISUZU	K-TLD45 - ISUZU 4BC1 1978 -1981	Engine: N/A			TRUCKS	A-1505	Air Filter
3956	ISUZU	K-TLD54 - ISUZU 4BA1 1980 -1981	Engine: N/A			TRUCKS	A-1817	Air Filter
3957	ISUZU	K-TLD55 - ISUZU 4BC1 1978 -1981	Engine: N/A			TRUCKS	A-1505	Air Filter
3958	ISUZU	K-TLD56 - ISUZU 4BC2 1983 -1984	Engine: N/A			TRUCKS	A-1505	Air Filter
3959	ISUZU	K-TLD64 - ISUZU 4BA1 1980 -1981	Engine: N/A			TRUCKS	A-1817	Air Filter
3960	ISUZU	K-TLD65 - ISUZU 4BC1 1978 -1981	Engine: N/A			TRUCKS	A-1505	Air Filter
3961	ISUZU	K-TLD66 - ISUZU 4BC2 1983 -1984	Engine: N/A			TRUCKS	A-1505	Air Filter
3962	ISUZU	K-TLD76 - ISUZU 4BC2 1981 -1983	Engine: N/A			TRUCKS	A-1505	Air Filter
3963	ISUZU	K-TLD76 - ISUZU 4BC2 1983 -1984	Engine: N/A			TRUCKS	A-1505	Air Filter
3964	ISUZU	K-TMK67 - ISUZU E120 1971 -1984	Engine: N/A			TRUCKS	AS-1024	Air Filter
3965	ISUZU	K-TMK68 - ISUZU E120 1971 -1984	Engine: N/A			TRUCKS	AS-1024	Air Filter
3966	ISUZU	K-TMK78 - ISUZU E120 1971 -1984	Engine: N/A			TRUCKS	AS-1024	Air Filter
3967	ISUZU	KC-ASN2F23 - ISUZU TD25 1995	Engine: N/A			TRUCKS	C-8037	Oil Filter
3968	ISUZU	KC-ASN6F23 4WD - ISUZU TD25 1995	Engine: N/A			TRUCKS	C-8037	Oil Filter
3969	ISUZU	KC-ASP8F23 - ISUZU TD27 1995 -1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
3970	ISUZU	KC-DM370 - ISUZU 6BF1 1982	Engine: N/A			TRUCKS	O-1510	Oil Filter
3971	ISUZU	KC-DM410 - ISUZU 6BF1 1982	Engine: N/A			TRUCKS	O-1510	Oil Filter
3972	ISUZU	KC-GR433F - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
3973	ISUZU	KC-JBGW40 - ISUZU ED35 1995	Engine: N/A			TRUCKS	A-1505	Air Filter
3974	ISUZU	KC-JBW40 - ISUZU ED35 1995	Engine: N/A			TRUCKS	A-1505	Air Filter
3975	ISUZU	KC-JCRGE24 - ISUZU QD32 1996 -1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
3976	ISUZU	KC-JCRGE24 - ISUZU TD27 1995 -1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
3977	ISUZU	KC-JCWGE24 - ISUZU QD32 1996 -1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
3978	ISUZU	KC-JCWME24 - ISUZU QD32 1996 -1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
3979	ISUZU	KC-JDRGE24 - ISUZU TD27 1996 -1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
3980	ISUZU	KC-JGW40 - ISUZU ED35 1995	Engine: N/A			TRUCKS	A-1505	Air Filter
3981	ISUZU	KC-JVRE24 - ISUZU TD27 1995 -1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
3982	ISUZU	KC-JVRGE24 - ISUZU TD27 1995 -1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
3983	ISUZU	KC-JVWE24 - ISUZU QD32 1996 -1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
3984	ISUZU	KC-JVWGE24 - ISUZU QD32 1996 -1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
3985	ISUZU	KC-JVWME24 - ISUZU QD32 1996 -1997	Engine: N/A			TRUCKS	C-8037	Oil Filter



Sakura Filter				ENGINE APPLICATION				
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
3986	ISUZU	KC-LM470 -	Engine: N/A			TRUCKS	O-1510	Oil Filter
3987	ISUZU	KC-NKR66 - ISUZU 4HF1 1995 -1999	Engine: N/A			TRUCKS	A-1817	Air Filter
3988	ISUZU	KC-NKR66 - ISUZU 4HF1N 1997 -1999	Engine: N/A			TRUCKS	A-1817	Air Filter
3989	ISUZU	KD-WFR62 - ISUZU 4FC1 1993 -1995	Engine: N/A			TRUCKS	A-1817	Air Filter
3990	ISUZU	KD-WFR62 - ISUZU 4FG1T 1993 -1995	Engine: N/A			TRUCKS	A-1817	Air Filter
3991	ISUZU	KG-ASP2F23 - ISUZU TD27 1999	Engine: N/A			TRUCKS	C-8037	Oil Filter
3992	ISUZU	KG-ASR2F23 - ISUZU QD32 1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
3993	ISUZU	KG-ASR4F23 - ISUZU QD32 1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
3994	ISUZU	KG-JCWMGE24 - ISUZU QD32 1995	Engine: N/A			TRUCKS	C-8037	Oil Filter
3995	ISUZU	KG-JCWMGE24 - ISUZU QD32 1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
3996	ISUZU	KG-JDWGE24 - ISUZU QD32 1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
3997	ISUZU	KG-JDWMGE24 - ISUZU QD32 1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
3998	ISUZU	KG-JVWE24 - ISUZU QD32 1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
3999	ISUZU	KG-JVWGE24 - ISUZU QD32 1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
4000	ISUZU	KG-JVWMGE24 - ISUZU QD32 1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
4001	ISUZU	KK-AD52 - ISUZU C240 1979 -1981	Engine: N/A			TRUCKS	A-1817	Air Filter
4002	ISUZU	KK-ASR8F23 - ISUZU QD32 1997	Engine: N/A			TRUCKS	C-8037	Oil Filter
4003	ISUZU	KK-ESR33 - ISUZU 6HE1 1990 -1995	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4004	ISUZU	KK-ESR34 - ISUZU 6HE1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4005	ISUZU	KK-FFR33G4 - ISUZU 6HH1S 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4006	ISUZU	KK-FFR34 - ISUZU 6HK1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4007	ISUZU	KK-FRD33 - ISUZU 6HE1 1990 -1995	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4008	ISUZU	KK-FRD33 - ISUZU 6HE1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4009	ISUZU	KK-FRD34 - ISUZU 6HK1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4010	ISUZU	KK-FRR33 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4011	ISUZU	KK-FRR34 - ISUZU 6HK1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4012	ISUZU	KK-FRR34G4 - ISUZU 6HK1TCC 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4013	ISUZU	KK-FRR34G4 - ISUZU 6HK1TCN 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4014	ISUZU	KK-FRS33 4WD - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4015	ISUZU	KK-FSD33 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4016	ISUZU	KK-FSD34 - ISUZU 6HK1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4017	ISUZU	KK-FSR33 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4018	ISUZU	KK-FSR33G4 - ISUZU 6HH1S 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4019	ISUZU	KK-FSR34 - ISUZU 6HK1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4020	ISUZU	KK-FSR34G4 - ISUZU 6HK1TCC 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4021	ISUZU	KK-FSR34G4 - ISUZU 6HK1TCN 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4022	ISUZU	KK-FSS33 4WD - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4023	ISUZU	KK-FTR33 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4024	ISUZU	KK-FTR33G4 - ISUZU 6HH1S 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4025	ISUZU	KK-FTR34 - ISUZU 6HK1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4026	ISUZU	KK-FTR34G4 - ISUZU 6HK1TCC 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4027	ISUZU	KK-FTR34G4 - ISUZU 6HK1TCN 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4028	ISUZU	KK-FTS34 - ISUZU 6HK1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4029	ISUZU	KK-FTS34 4WD - ISUZU 6HK1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4030	ISUZU	KK-GR433 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4031	ISUZU	KK-GSR34 - ISUZU 6HK1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4032	ISUZU	KK-LR233 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4033	ISUZU	KK-LR233E1 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4034	ISUZU	KK-LR233F1 - ISUZU 6HA1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4035	ISUZU	KK-LR233F1 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4036	ISUZU	KK-LR233J1 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4037	ISUZU	KK-LR333E1 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4038	ISUZU	KK-LR333F1 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4039	ISUZU	KK-LR333J1 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4040	ISUZU	KK-LT233 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4041	ISUZU	KK-LT233J1 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4042	ISUZU	KK-LT333 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4043	ISUZU	KK-LT333J1 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4044	ISUZU	KL-FSD33 - ISUZU 6HK1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4045	ISUZU	KL-FSD34 - ISUZU 6HK1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4046	ISUZU	KL-FSR33 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4047	ISUZU	KL-FSR34 - ISUZU 6HK1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4048	ISUZU	KL-FSS33 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4049	ISUZU	KL-FTR33 - ISUZU 6HH1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter



## Sakura Filter

## ENGINE APPLICATION

NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
4050	ISUZU	KL-FTR34 - ISUZU 6HK1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4051	ISUZU	KL-FTR34 - ISUZU 6HKR34 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4052	ISUZU	KL-FTS34 - ISUZU 6HK1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4053	ISUZU	KL-FTZ34 - ISUZU 6HK1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4054	ISUZU	KL-FVZ34 - ISUZU 6HK1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4055	ISUZU	KL-GTR34 - ISUZU 6HK1T 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4056	ISUZU	KL-LV834 - ISUZU 6HK1T 2000	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4057	ISUZU	KR-NKS81G - ([2002])	ISUZU 4HL1	2002		CONSTRUCTION & MINING	C-5812	Oil Filter
4058	ISUZU	KR-NKS81L - ([2002])	ISUZU 4HL1	2002		TRUCKS	C-5812	Oil Filter
4059	ISUZU	KR-NKS81G - ISUZU 4HL1 2002	Engine: N/A			TRUCKS	C-2702	Oil Filter
4060	ISUZU	KR-NKS81L - ISUZU 4HL1 2002	Engine: N/A			TRUCKS	C-2702	Oil Filter
4061	ISUZU	KS32 - ISUZU 2.8 L TURBO	Engine: N/A			TRUCKS	A-1505	Air Filter
4062	ISUZU	KS32 - ISUZU 2.8 L TURBO	Engine: N/A			TRUCKS	A-1817	Air Filter
4063	ISUZU	KS32 - ISUZU 3.0L	Engine: N/A			TRUCKS	A-1505	Air Filter
4064	ISUZU	KS32 - ISUZU 3.0L	Engine: N/A			TRUCKS	A-1817	Air Filter
4065	ISUZU	KS32 - ISUZU 3.3L	Engine: N/A			TRUCKS	A-1505	Air Filter
4066	ISUZU	KS32 - ISUZU 3.3L	Engine: N/A			TRUCKS	A-1817	Air Filter
4067	ISUZU	KS32 - ISUZU 4BC2 1984	Engine: N/A			TRUCKS	A-1505	Air Filter
4068	ISUZU	KT25 - ISUZU 2.8 L TURBO	Engine: N/A			TRUCKS	A-1505	Air Filter
4069	ISUZU	KT25 - ISUZU 2.8 L TURBO	Engine: N/A			TRUCKS	A-1817	Air Filter
4070	ISUZU	KT25 - ISUZU 3.0L	Engine: N/A			TRUCKS	A-1505	Air Filter
4071	ISUZU	KT25 - ISUZU 3.0L	Engine: N/A			TRUCKS	A-1817	Air Filter
4072	ISUZU	KT25 - ISUZU 3.3L	Engine: N/A			TRUCKS	A-1505	Air Filter
4073	ISUZU	KT25 - ISUZU 3.3L	Engine: N/A			TRUCKS	A-1817	Air Filter
4074	ISUZU	KT25 - ISUZU 4BC1	Engine: N/A			TRUCKS	A-1505	Air Filter
4075	ISUZU	KT26 - ISUZU 2.8 L TURBO	Engine: N/A			TRUCKS	A-1505	Air Filter
4076	ISUZU	KT26 - ISUZU 2.8 L TURBO	Engine: N/A			TRUCKS	A-1817	Air Filter
4077	ISUZU	KT26 - ISUZU 3.0L	Engine: N/A			TRUCKS	A-1505	Air Filter
4078	ISUZU	KT26 - ISUZU 3.0L	Engine: N/A			TRUCKS	A-1817	Air Filter
4079	ISUZU	KT26 - ISUZU 3.3L	Engine: N/A			TRUCKS	A-1505	Air Filter
4080	ISUZU	KT26 - ISUZU 3.3L	Engine: N/A			TRUCKS	A-1817	Air Filter
4081	ISUZU	KT26 - ISUZU 4BC2	Engine: N/A			TRUCKS	A-1505	Air Filter
4082	ISUZU	LWFR12 - ISUZU 4ZC1 1990 -1995	Engine: N/A			TRUCKS	A-1817	Air Filter
4083	ISUZU	Mitsubishi 4M403 4- Wheel Truck FB511	Engine: N/A			TRUCKS	C-5816	Oil Filter
4084	ISUZU	MR112 - ISUZU 6BG1 1984 -1985	Engine: N/A			TRUCKS	C-1009	Oil Filter
4085	ISUZU	MR112 - ISUZU 6BG1 1984 -1985	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4086	ISUZU	NEFSR87 - ISUZU 6HA1 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4087	ISUZU	NFR62 - ISUZU 4FG1 1988 -1990	Engine: N/A			TRUCKS	A-1817	Air Filter
4088	ISUZU	NFR62 - ISUZU 4FG1 1988 -1990	Engine: N/A			TRUCKS	C-1605	Oil Filter
4089	ISUZU	NFS62 AT - ISUZU 4FG1 1990	Engine: N/A			TRUCKS	A-1817	Air Filter
4090	ISUZU	NFS62 AT - ISUZU 4FG1 1990	Engine: N/A			TRUCKS	C-1605	Oil Filter
4091	ISUZU	NFS62 MT - ISUZU 4FG1 1990	Engine: N/A			TRUCKS	A-1817	Air Filter
4092	ISUZU	NFS62 MT - ISUZU 4FG1 1990	Engine: N/A			TRUCKS	C-1605	Oil Filter
4093	ISUZU	NHSS55 - ISUZU 4JB1 1991	Engine: N/A			TRUCKS	A-1817	Air Filter
4094	ISUZU	NKR150 - ISUZU 3.6L 4BE1	Engine: N/A			TRUCKS	A-1817	Air Filter
4095	ISUZU	NKR150 - ISUZU 3.9L 4BD1	Engine: N/A			TRUCKS	A-1817	Air Filter
4096	ISUZU	NKR200 - ISUZU 3.6L 4BE1	Engine: N/A			TRUCKS	A-1817	Air Filter
4097	ISUZU	NKR200 - ISUZU 3.9L 4BD1	Engine: N/A			TRUCKS	A-1817	Air Filter
4098	ISUZU	NKR250 - ISUZU 3.6L 4BE1	Engine: N/A			TRUCKS	A-1817	Air Filter
4099	ISUZU	NKR250 - ISUZU 3.9L 4BD1	Engine: N/A			TRUCKS	A-1817	Air Filter
4100	ISUZU	NKR300 - ISUZU 3.6L 4BE1	Engine: N/A			TRUCKS	A-1817	Air Filter
4101	ISUZU	NKR300 - ISUZU 3.9L 4BD1	Engine: N/A			TRUCKS	A-1817	Air Filter
4102	ISUZU	NKR400 - ISUZU 3.6L 4BE1	Engine: N/A			TRUCKS	A-1817	Air Filter
4103	ISUZU	NKR400 - ISUZU 3.9L 4BD1	Engine: N/A			TRUCKS	A-1817	Air Filter
4104	ISUZU	NKR57E - ISUZU 4BC2 1985 -1987	Engine: N/A			TRUCKS	A-1817	Air Filter
4105	ISUZU	NKR57L - ISUZU 4BC2 1985 -1987	Engine: N/A			TRUCKS	A-1817	Air Filter
4106	ISUZU	NKR58-1E - ISUZU 3.6L 4BE1	Engine: N/A			TRUCKS	A-1817	Air Filter
4107	ISUZU	NKR58-1E - ISUZU 3.9L 4BD1	Engine: N/A			TRUCKS	A-1817	Air Filter
4108	ISUZU	NKR58-5E - ISUZU 3.6L 4BE1	Engine: N/A			TRUCKS	A-1817	Air Filter
4109	ISUZU	NKR58-5E - ISUZU 3.9L 4BD1	Engine: N/A			TRUCKS	A-1817	Air Filter
4110	ISUZU	NKR58E - ISUZU 3.6L 4BE1	Engine: N/A			TRUCKS	A-1817	Air Filter
4111	ISUZU	NKR58E - ISUZU 3.9L 4BD1	Engine: N/A			TRUCKS	A-1817	Air Filter
4112	ISUZU	NKR58L - ISUZU 3.6L 4BE1	Engine: N/A			TRUCKS	A-1817	Air Filter
4113	ISUZU	NKR58L - ISUZU 3.9L 4BD1	Engine: N/A			TRUCKS	A-1817	Air Filter

Sakura Filter					ENGINE APPLICATION			
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
4114	ISUZU	NLR 200 -([N/A])	3 Litre turbo diesel.			TRUCKS	EF-1509	Fuel Filter
4115	ISUZU	NPR	4 cyl. 3.9L Turbo Diesel (4BD1-T)			TRUCKS	C-1123	Oil Filter
4116	ISUZU	NPR	4 cyl. 3.9L Turbo Diesel (4BD1-T)			TRUCKS	C-1149	Oil Filter
4117	ISUZU	NPR	4 cyl. 3.9L Turbo Diesel (4BD1-T)			TRUCKS	FC-1113	Fuel Filter
4118	ISUZU	NPR	4 cyl. 3.9L Turbo Diesel (4BD1-T)			TRUCKS	FC-1113	Fuel Filter
4119	ISUZU	NPR	4 cyl. 3.9L Turbo Diesel (4BD2-T)			TRUCKS	FC-1113	Fuel Filter
4120	ISUZU	NPR	4 CYL. 3.9L TURBO DIESEL (VIN K) (4BD2-TC)			TRUCKS	A-1019	Air Filter
4121	ISUZU	NPR	4 CYL. 3.9L TURBO DIESEL (VIN K) (4BD2-TC)			TRUCKS	FC-1113	Fuel Filter
4122	ISUZU	NPR	4 cyl. 4.8L Turbo Diesel (4HE1-TC)			TRUCKS	A-1019	Air Filter
4123	ISUZU	NPR	4 cyl. 4.8L Turbo Diesel (4HE1-TC)			TRUCKS	FC-1509	Fuel Filter
4124	ISUZU	NPR	4 cyl. 4.8L Turbo Diesel (4HE1-XS)			TRUCKS	A-1019	Air Filter
4125	ISUZU	NPR	4 cyl. 4.8L Turbo Diesel (4HE1-XS)			TRUCKS	FC-1509	Fuel Filter
4126	ISUZU	NPR	4 cyl. 5.2L Turbo Diesel (4HK1-TC)			TRUCKS	A-1019	Air Filter
4127	ISUZU	NPR	4 cyl. 5.2L Turbo Diesel (4HK1-TC)			TRUCKS	A-1019	Air Filter
4128	ISUZU	NPR	V8 350 5.7L F.I. (VIN A)			TRUCKS	AR-65100	Air Filter
4129	ISUZU	NPR	V8 350 5.7L F.I. (VIN A)			TRUCKS	C-6519	Oil Filter
4130	ISUZU	NPR	V8 350 5.7L F.I. (VIN R)			TRUCKS	A-1019	Air Filter
4131	ISUZU	NPR	V8 350 5.7L F.I. (VIN R)			TRUCKS	C-6519	Oil Filter
4132	ISUZU	NPR	V8 364 6.0L F.I. (VIN U)			TRUCKS	A-1019	Air Filter
4133	ISUZU	NPR	V8 364 6.0L F.I. (VIN U)			TRUCKS	C-6526	Oil Filter
4134	ISUZU	NPR	V8 364 6.0L F.I. (VIN U)			TRUCKS	C-6526	Oil Filter
4135	ISUZU	NPR	V8 364 6.0L F.I. (VIN U)			TRUCKS	C-7971	Oil Filter
4136	ISUZU	NPR - ISUZU 4BD2-T 1993	Engine: N/A			TRUCKS	C-1522	Oil Filter
4137	ISUZU	NPR - ISUZU 4BD2-TC 1993	Engine: N/A			TRUCKS	C-1522	Oil Filter
4138	ISUZU	NPR -([1987 - 1991])	4 cyl. 3.9L Turbo Diesel (4BD1-T)	1987	1991	TRUCKS	A-1019	Air Filter
4139	ISUZU	NPR -([1987 - 1991])	4 cyl. 3.9L Turbo Diesel (4BD1-T)	1987	1991	TRUCKS	FC-1101	Fuel Filter
4140	ISUZU	NPR -([1987 - 1991])	4 cyl. 3.9L Turbo Diesel (4BD1-T)	1987	1991	TRUCKS	FC-1301	Fuel Filter
4141	ISUZU	NPR -([1987-1991])	4 cyl. 3.9L Turbo Diesel (4BD1-T)	1987	1991	TRUCKS	FC-1113	Fuel Filter
4142	ISUZU	NPR -([1989 - 1991])	4 cyl. 3.9L Turbo Diesel (4BD1-T)	1989	1991	TRUCKS	C-1212	Oil Filter
4143	ISUZU	NPR -([1991 - 1991])	4 cyl. 3.9L Turbo Diesel (4BD2-T)	1991	1991	TRUCKS	A-1019	Air Filter
4144	ISUZU	NPR -([1991 - 1991])	4 cyl. 3.9L Turbo Diesel (4BD2-T)	1991	1991	TRUCKS	FC-1301	Fuel Filter
4145	ISUZU	NPR -([1991-1994])	4 cyl. 3.9L Turbo Diesel (4BD2-T)	1991	1994	TRUCKS	FC-1113	Fuel Filter
4146	ISUZU	NPR -([1992 - 1994])	4 cyl. 3.9L Turbo Diesel (4BD2-T)	1992	1994	TRUCKS	A-1019	Air Filter
4147	ISUZU	NPR -([1992 - 1994])	4 cyl. 3.9L Turbo Diesel (4BD2-T)	1992	1994	TRUCKS	FC-1101	Fuel Filter
4148	ISUZU	NPR -([1992 - 1994])	4 cyl. 3.9L Turbo Diesel (4BD2-T)	1992	1994	TRUCKS	FC-1301	Fuel Filter
4149	ISUZU	NPR -([1995 - 1997])	(VIN K) 4 cyl. 3.9L Turbo Diesel (4BD2-TC)	1995	1997	TRUCKS	A-1019	Air Filter
4150	ISUZU	NPR -([1995 - 1997])	(VIN K) 4 cyl. 3.9L Turbo Diesel (4BD2-TC)	1995	1997	TRUCKS	FC-1101	Fuel Filter
4151	ISUZU	NPR -([1995 - 1997])	(VIN K) 4 cyl. 3.9L Turbo Diesel (4BD2-TC)	1995	1997	TRUCKS	FC-1301	Fuel Filter
4152	ISUZU	NPR -([1995-1997])	4 cyl. 3.9L Turbo Diesel (VIN K) (4BD2-TC)	1995	1997	TRUCKS	FC-1113	Fuel Filter
4153	ISUZU	NPR -([1996 - 1998])	(VIN R) V8 350 5.7L F.I.	1996	1998	TRUCKS	A-1019	Air Filter
4154	ISUZU	NPR -([1998 - 2003])	4 cyl. 4.8L Turbo Diesel (4HE1-TC)	1998	2003	TRUCKS	A-1019	Air Filter
4155	ISUZU	NPR -([1999 - 2002])	(VIN R) V8 350 5.7L F.I.	1999	2002	TRUCKS	A-1019	Air Filter
4156	ISUZU	NPR -([1999 - 2003])	4 cyl. 4.8L Turbo Diesel (4HE1-XS)	1999	2003	TRUCKS	A-1019	Air Filter
4157	ISUZU	NPR -([2003 - 2004])	(VIN U) V8 364 6.0L F.I.	2003	2004	TRUCKS	A-1019	Air Filter
4158	ISUZU	NPR -([2004 - 2008])	4 cyl. 5.2L Turbo Diesel (4HK1-TC)	2004	2008	TRUCKS	A-1019	Air Filter
4159	ISUZU	NPR -([2007-2009])	V8 364 6.0L F.I. (VIN U)	2007	2009	TRUCKS	C-7971	Oil Filter
4160	ISUZU	NPR DIESEL - ISUZU 4.8L 4HE1-TC 1999	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4161	ISUZU	NPR EFI - GMC 5.7 L GAS	Engine: N/A			TRUCKS	C-6504	Oil Filter

Sakura Filter				ENGINE APPLICATION				
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
4162	ISUZU	NPR HD	4 cyl. 4.8L Turbo Diesel (4HE1-TC)			TRUCKS	A-1019	Air Filter
4163	ISUZU	NPR HD	4 cyl. 4.8L Turbo Diesel (4HE1-TC)			TRUCKS	FC-1509	Fuel Filter
4164	ISUZU	NPR HD	4 cyl. 4.8L Turbo Diesel (4HE1-TCJ)			TRUCKS	A-1019	Air Filter
4165	ISUZU	NPR HD	4 cyl. 4.8L Turbo Diesel (4HE1-TCJ)			TRUCKS	FC-1509	Fuel Filter
4166	ISUZU	NPR HD	4 cyl. 4.8L Turbo Diesel (4HE1-XS)			TRUCKS	A-1019	Air Filter
4167	ISUZU	NPR HD	4 cyl. 4.8L Turbo Diesel (4HE1-XS)			TRUCKS	FC-1509	Fuel Filter
4168	ISUZU	NPR HD	4 cyl. 5.2L Turbo Diesel (4HK1-TC)			TRUCKS	A-1019	Air Filter
4169	ISUZU	NPR HD	4 cyl. 5.2L Turbo Diesel (4HK1-TC)			TRUCKS	A-1019	Air Filter
4170	ISUZU	NPR HD	V8 350 5.7L F.I. (VIN R)			TRUCKS	A-1019	Air Filter
4171	ISUZU	NPR HD	V8 350 5.7L F.I. (VIN R)			TRUCKS	C-6519	Oil Filter
4172	ISUZU	NPR HD	V8 364 6.0L F.I. (VIN U)			TRUCKS	A-1019	Air Filter
4173	ISUZU	NPR HD	V8 364 6.0L F.I. (VIN U)			TRUCKS	C-6526	Oil Filter
4174	ISUZU	NPR HD	V8 364 6.0L F.I. (VIN U)			TRUCKS	C-6526	Oil Filter
4175	ISUZU	NPR HD	V8 364 6.0L F.I. (VIN U)			TRUCKS	C-7971	Oil Filter
4176	ISUZU	NPR HD -([1998 - 1998])	(VIN R) V8 350 5.7L F.I.	1998	1998	TRUCKS	A-1019	Air Filter
4177	ISUZU	NPR HD -([1998 - 2003])	4 cyl. 4.8L Turbo Diesel (4HE1-TC)	1998	2003	TRUCKS	A-1019	Air Filter
4178	ISUZU	NPR HD -([1999 - 2002])	(VIN R) V8 350 5.7L F.I.	1999	2002	TRUCKS	A-1019	Air Filter
4179	ISUZU	NPR HD -([1999 - 2003])	4 cyl. 4.8L Turbo Diesel (4HE1-XS)	1999	2003	TRUCKS	A-1019	Air Filter
4180	ISUZU	NPR HD -([2003 - 2004])	(VIN U) V8 364 6.0L F.I.	2003	2004	TRUCKS	A-1019	Air Filter
4181	ISUZU	NPR HD -([2004 - 2008])	4 cyl. 5.2L Turbo Diesel (4HK1-TC)	2004	2008	TRUCKS	A-1019	Air Filter
4182	ISUZU	NPR HD -([2007-2009])	V8 364 6.0L F.I. (VIN U)	2007	2009	TRUCKS	C-7971	Oil Filter
4183	ISUZU	NPR200 -([01/03/2006-N/A])	4.8L 4Cyl	2006	N/A	TRUCKS	C-1515	Oil Filter
4184	ISUZU	NPR200 -([01/03/2006-N/A])	4.8L 4Cyl	2006	N/A	TRUCKS	C-1562	Oil Filter
4185	ISUZU	NPR200 -([01/03/2006-N/A])	4.8L 4Cyl	2006	N/A	TRUCKS	FC-1301	Fuel Filter
4186	ISUZU	NPR250 -([01/03/2006-N/A])	4.8L 4Cyl	2006	N/A	TRUCKS	C-1515	Oil Filter
4187	ISUZU	NPR250 -([01/03/2006-N/A])	4.8L 4Cyl	2006	N/A	TRUCKS	C-1562	Oil Filter
4188	ISUZU	NPR250 -([01/03/2006-N/A])	4.8L 4Cyl	2006	N/A	TRUCKS	FC-1301	Fuel Filter
4189	ISUZU	NPR300 -([01/03/2006-N/A])	4.8L 4Cyl	2006	N/A	TRUCKS	C-1515	Oil Filter
4190	ISUZU	NPR300 -([01/03/2006-N/A])	4.8L 4Cyl	2006	N/A	TRUCKS	C-1562	Oil Filter
4191	ISUZU	NPR300 -([01/03/2006-N/A])	4.8L 4Cyl	2006	N/A	TRUCKS	FC-1301	Fuel Filter
4192	ISUZU	NPR350 -([01/03/2006-N/A])	4.8L 4Cyl	2006	N/A	TRUCKS	C-1515	Oil Filter
4193	ISUZU	NPR350 -([01/03/2006-N/A])	4.8L 4Cyl	2006	N/A	TRUCKS	C-1562	Oil Filter
4194	ISUZU	NPR350 -([01/03/2006-N/A])	4.8L 4Cyl	2006	N/A	TRUCKS	FC-1301	Fuel Filter
4195	ISUZU	NPR400 (DIESEL TURBO) -([01/03/2006-N/A])	4.8L 4Cyl	2006	N/A	TRUCKS	C-1562	Oil Filter
4196	ISUZU	NPR400 (DIESEL TURBO) -([01/03/2006-N/A])	4.8L 4Cyl	2006	N/A	TRUCKS	FC-1301	Fuel Filter
4197	ISUZU	NPR400 (DIESEL TURBO)-([01/03/2006-N/A])	4.8L 4Cyl	2006	N/A	TRUCKS	C-1515	Oil Filter
4198	ISUZU	NPR57L - ISUZU 4BC2 1985 -1987	Engine: N/A			TRUCKS	A-1817	Air Filter
4199	ISUZU	NPR58 - ISUZU 4BE1 1987 -1990	Engine: N/A			TRUCKS	A-1505	Air Filter
4200	ISUZU	NPR58 - ISUZU 4BE1 1990 -1993	Engine: N/A			TRUCKS	A-1505	Air Filter
4201	ISUZU	NPR61 - ISUZU 4BG1 1988 -1993	Engine: N/A			TRUCKS	A-1505	Air Filter
4202	ISUZU	NPR75 -([2008-N/A])	5200 cc	2008	N/A	TRUCKS	EF-1509	Fuel Filter
4203	ISUZU	NPRW4 -	Engine: N/A			TRUCKS	C-6504	Oil Filter
4204	ISUZU	NQR -	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4205	ISUZU	NQR/NQR-([1999/N/A])	Engine: N/A			TRUCKS	FC-2701	Fuel Filter
4206	ISUZU	NRR - ISUZU 6.494L DIESEL 1988 -1991	Engine: N/A			TRUCKS	A-6007	Air Filter
4207	ISUZU	NRR - ISUZU 6.494L DIESEL 1988 -1991	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4208	ISUZU	NRR - ISUZU 6.494L DIESEL 1993	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4209	ISUZU	NRR - ISUZU 6BG1-NA 396 CID 1988 -1991	Engine: N/A			TRUCKS	A-6007	Air Filter
4210	ISUZU	NRR - ISUZU 6BG1-NA 396 CID 1988 -1991	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4211	ISUZU	NRR - ISUZU 6BG1-TC 1993	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4212	ISUZU	NTLD23 - ISUZU C240 1981 -1985	Engine: N/A			TRUCKS	A-1817	Air Filter
4213	ISUZU	NTLD24 - ISUZU 4BA1 1981 -1984	Engine: N/A			TRUCKS	A-1817	Air Filter
4214	ISUZU	NTLD34 - ISUZU 4BA1 1981 -1984	Engine: N/A			TRUCKS	A-1817	Air Filter
4215	ISUZU	NTLD34 - ISUZU 4JA1 1982 -1984	Engine: N/A			TRUCKS	A-1817	Air Filter
4216	ISUZU	NTLD54 - ISUZU 4BA1 1981 -1984	Engine: N/A			TRUCKS	A-1817	Air Filter
4217	ISUZU	NTLD54 - ISUZU 4JA1 1982 -1984	Engine: N/A			TRUCKS	A-1817	Air Filter
4218	ISUZU	NTLD64 - ISUZU 4BA1 1981 -1984	Engine: N/A			TRUCKS	A-1817	Air Filter

Sakura Filter				ENGINE APPLICATION				
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
4219	ISUZU	NWFR53 - ISUZU 4FD1 1983 -1991	Engine: N/A			TRUCKS	A-1817	Air Filter
4220	ISUZU	NWFS53 - ISUZU 4FD1 1983 -1990	Engine: N/A			TRUCKS	A-1817	Air Filter
4221	ISUZU	NWFS53 - ISUZU 4FD1 1983 -1990	Engine: N/A			TRUCKS	C-1605	Oil Filter
4222	ISUZU	NWFS53 - ISUZU 4FG1 1985 -1988	Engine: N/A			TRUCKS	C-1605	Oil Filter
4223	ISUZU	P-CVR17 - ISUZU 8PC1 1986 -1989	Engine: N/A			TRUCKS	A-7967	Air Filter
4224	ISUZU	P-CVS17 - ISUZU 8PC1 1987 -1989	Engine: N/A			TRUCKS	A-7967	Air Filter
4225	ISUZU	P-CVS19J - ISUZU 10PC1 1985 -1990	Engine: N/A			TRUCKS	A-7967	Air Filter
4226	ISUZU	P-CXG17 - ISUZU 8PC1 1983 -1986	Engine: N/A			TRUCKS	A-7967	Air Filter
4227	ISUZU	P-CXG19 - ISUZU 10PC1 1986 -1987	Engine: N/A			TRUCKS	A-7967	Air Filter
4228	ISUZU	P-CXH19 - ISUZU 10PC1 1986 -1989	Engine: N/A			TRUCKS	A-7967	Air Filter
4229	ISUZU	P-CXK19 - ISUZU 10PC1 1986 -1989	Engine: N/A			TRUCKS	A-7967	Air Filter
4230	ISUZU	P-CXL19 - ISUZU 10PC1 1987 -1989	Engine: N/A			TRUCKS	A-7967	Air Filter
4231	ISUZU	P-CXM19 - ISUZU 10PC1 1986 -1989	Engine: N/A			TRUCKS	A-7967	Air Filter
4232	ISUZU	P-CXW17M - ISUZU 8PC1 1987 -1990	Engine: N/A			TRUCKS	A-7967	Air Filter
4233	ISUZU	P-CXW19P - ISUZU 10PC1S 1985 -1990	Engine: N/A			TRUCKS	A-7967	Air Filter
4234	ISUZU	P-CXZ19 - ISUZU 10PC1 1986 -1989	Engine: N/A			TRUCKS	A-7967	Air Filter
4235	ISUZU	P-ERS12 - ISUZU 6BG1 1989 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4236	ISUZU	P-ESR11 - ISUZU 6BD1T 1985 -1989	Engine: N/A			TRUCKS	C-1009	Oil Filter
4237	ISUZU	P-ESR11 - ISUZU 6BD1T 1985 -1989	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4238	ISUZU	P-ESR12 - ISUZU 6BG1 1985 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4239	ISUZU	P-ESR12 - ISUZU 6BG1T 1990	Engine: N/A			TRUCKS	C-1009	Oil Filter
4240	ISUZU	P-ESR12 - ISUZU 6BG1T 1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4241	ISUZU	P-FRD11 - ISUZU 6BD1T 1984 -1985	Engine: N/A			TRUCKS	C-1009	Oil Filter
4242	ISUZU	P-FRD11 - ISUZU 6BD1T 1984 -1985	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4243	ISUZU	P-FRD11 - ISUZU 6BD1T 1985 -1990	Engine: N/A			TRUCKS	C-1009	Oil Filter
4244	ISUZU	P-FRD11 - ISUZU 6BD1T 1985 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4245	ISUZU	P-FRD12 - ISUZU 6BG1 1984 -1985	Engine: N/A			TRUCKS	C-1009	Oil Filter
4246	ISUZU	P-FRD12 - ISUZU 6BG1 1984 -1985	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4247	ISUZU	P-FRD12 - ISUZU 6BG1 1985 -1986	Engine: N/A			TRUCKS	C-1009	Oil Filter
4248	ISUZU	P-FRD12 - ISUZU 6BG1 1985 -1986	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4249	ISUZU	P-FRD12 - ISUZU 6GB1 1985 -1986	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4250	ISUZU	P-FRG11 - ISUZU 6BD1T 1984 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4251	ISUZU	P-FRR11 - ISUZU 6BD1T 1984 -1985	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4252	ISUZU	P-FRR11 - ISUZU 6BD1T 1985 -1990	Engine: N/A			TRUCKS	C-1009	Oil Filter
4253	ISUZU	P-FRR11 - ISUZU 6BD1T 1985 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4254	ISUZU	P-FRR12 - ISUZU 6BG1 1984 -1985	Engine: N/A			TRUCKS	C-1009	Oil Filter
4255	ISUZU	P-FRR12 - ISUZU 6BG1 1984 -1985	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4256	ISUZU	P-FRR12 - ISUZU 6BG1 1985 -1990	Engine: N/A			TRUCKS	C-1009	Oil Filter
4257	ISUZU	P-FRR12 - ISUZU 6BG1 1985 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4258	ISUZU	P-FRR13 - ISUZU 6SA1 1985 -1990	Engine: N/A			TRUCKS	C-1009	Oil Filter
4259	ISUZU	P-FRR13 - ISUZU 6SA1 1985 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4260	ISUZU	P-FRS12 - ISUZU 6BD1T 1985	Engine: N/A			TRUCKS	C-1009	Oil Filter
4261	ISUZU	P-FRS12 - ISUZU 6BD1T 1985	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4262	ISUZU	P-FRS12 4WD - ISUZU 6BG1 1984 -1990	Engine: N/A			TRUCKS	C-1009	Oil Filter
4263	ISUZU	P-FRS12 4WD - ISUZU 6BG1 1984 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4264	ISUZU	P-FSD12 - ISUZU 6BD1T 1988 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4265	ISUZU	P-FSD12 - ISUZU 6BG1 1988	Engine: N/A			TRUCKS	C-1009	Oil Filter
4266	ISUZU	P-FSD12 - ISUZU 6BG1 1988	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4267	ISUZU	P-FSR11 - ISUZU 6BD1T 1984 -1985	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4268	ISUZU	P-FSR11 - ISUZU 6BD1T 1985 -1990	Engine: N/A			TRUCKS	C-1009	Oil Filter
4269	ISUZU	P-FSR11 - ISUZU 6BD1T 1985 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4270	ISUZU	P-FSR12 - ISUZU 6BG1 1985 -1990	Engine: N/A			TRUCKS	C-1009	Oil Filter
4271	ISUZU	P-FSR12 - ISUZU 6BG1 1985 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4272	ISUZU	P-FSR12 - ISUZU 6BG1T 1985 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4273	ISUZU	P-FSR13 - ISUZU 6SA1 1985 -1986	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4274	ISUZU	P-FSR13 - ISUZU 6SA1 1986 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4275	ISUZU	P-FSS12 4WD - ISUZU 6BG1 1986 -1995	Engine: N/A			TRUCKS	C-1009	Oil Filter
4276	ISUZU	P-FSS12 4WD - ISUZU 6BG1 1986 -1995	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4277	ISUZU	P-FTR11 - ISUZU 6BD1T 1984 -1985	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4278	ISUZU	P-FTR11 - ISUZU 6BD1T 1985 -1990	Engine: N/A			TRUCKS	C-1009	Oil Filter
4279	ISUZU	P-FTR11 - ISUZU 6BD1T 1985 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4280	ISUZU	P-FTR12 - ISUZU 6BG1 1985 -1990	Engine: N/A			TRUCKS	C-1009	Oil Filter
4281	ISUZU	P-FTR12 - ISUZU 6BG1 1985 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4282	ISUZU	P-FTR13 - ISUZU 6SA1 1985 -1986	Engine: N/A			TRUCKS	C-1009	Oil Filter



Sakura Filter							ENGINE APPLICATION	
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
4283	ISUZU	P-FTR13 - ISUZU 6SA1 1985 -1986	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4284	ISUZU	P-FTR13 - ISUZU 6SA1 1986 -1990	Engine: N/A			TRUCKS	C-1009	Oil Filter
4285	ISUZU	P-FTR13 - ISUZU 6SA1 1986 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4286	ISUZU	P-KT16 - ISUZU 4BC2 1983 -1984	Engine: N/A			TRUCKS	A-1505	Air Filter
4287	ISUZU	P-KT26 - ISUZU 4BC2 1983 -1984	Engine: N/A			TRUCKS	A-1505	Air Filter
4288	ISUZU	P-KT36 - ISUZU 4BC2 1983 -1984	Engine: N/A			TRUCKS	A-1505	Air Filter
4289	ISUZU	P-KT46 - ISUZU 4BC2 1983 -1984	Engine: N/A			TRUCKS	A-1505	Air Filter
4290	ISUZU	P-NHR54 - ISUZU 4JA1 1984 -1988	Engine: N/A			TRUCKS	A-1817	Air Filter
4291	ISUZU	P-NHR55 - ISUZU 4JB1 1984 -1988	Engine: N/A			TRUCKS	A-1817	Air Filter
4292	ISUZU	P-NKR55 - ISUZU 4JB1 1984 -1988	Engine: N/A			TRUCKS	A-1817	Air Filter
4293	ISUZU	P-NKR56 - ISUZU 4BA1 1985 -1988	Engine: N/A			TRUCKS	A-1817	Air Filter
4294	ISUZU	P-NKR57 - ISUZU 4BC2 1984 -1990	Engine: N/A			TRUCKS	A-1817	Air Filter
4295	ISUZU	P-NKR58 - ISUZU 4BE1 1985 -1990	Engine: N/A			TRUCKS	A-1817	Air Filter
4296	ISUZU	P-NKR63 - ISUZU 4BE2 1988 -1993	Engine: N/A			TRUCKS	A-1817	Air Filter
4297	ISUZU	P-NKS58 - ISUZU 4BE1 1987 -1990	Engine: N/A			TRUCKS	A-1505	Air Filter
4298	ISUZU	P-NKS58 - ISUZU 4BE1 1987 -1990	Engine: N/A			TRUCKS	A-1817	Air Filter
4299	ISUZU	P-NPR57 - ISUZU 4BC2 1984 -1993	Engine: N/A			TRUCKS	A-1505	Air Filter
4300	ISUZU	P-NPR58 - ISUZU 4BE1 1987 -1990	Engine: N/A			TRUCKS	A-1817	Air Filter
4301	ISUZU	P-NPR59 - ISUZU 4BD1 1984 -1993	Engine: N/A			TRUCKS	A-1505	Air Filter
4302	ISUZU	P-NRR12 - ISUZU 6BG1 1985 -1990	Engine: N/A			TRUCKS	C-1009	Oil Filter
4303	ISUZU	P-NRR12 - ISUZU 6BG1 1985 -1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4304	ISUZU	P-TLD26 - ISUZU 4BC2 1983	Engine: N/A			TRUCKS	A-1505	Air Filter
4305	ISUZU	P-TLD76 - ISUZU 4BC2 1983	Engine: N/A			TRUCKS	A-1505	Air Filter
4306	ISUZU	P-WHR55 - ISUZU 4JB1 1985 -1988	Engine: N/A			TRUCKS	A-1817	Air Filter
4307	ISUZU	P-WKR55 - ISUZU 4JB1 1985 -1988	Engine: N/A			TRUCKS	A-1817	Air Filter
4308	ISUZU	PAVELINE/FVD950HD -(I/N/A)	N/A			TRUCKS	C-1505	Oil Filter
4309	ISUZU	PAVELINE/FVD950HD -(I/N/A)	N/A			TRUCKS	C-5505	Oil Filter
4310	ISUZU	QWFR62 - ISUZU 4FG1T 1991 -1993	Engine: N/A			TRUCKS	A-1817	Air Filter
4311	ISUZU	QWFS51 - ISUZU 4FC1T 1987 -1990	Engine: N/A			TRUCKS	C-1605	Oil Filter
4312	ISUZU	QWFS51 - ISUZU 4FD1 1990 -1991	Engine: N/A			TRUCKS	C-1605	Oil Filter
4313	ISUZU	QWFS62 - ISUZU 4FG1 1990 -1995	Engine: N/A			TRUCKS	A-1817	Air Filter
4314	ISUZU	QWFS62 - ISUZU 4FG1 1990 -1995	Engine: N/A			TRUCKS	C-1605	Oil Filter
4315	ISUZU	SBR372 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
4316	ISUZU	SBR420A - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
4317	ISUZU	SBR422 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
4318	ISUZU	SBR422A - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
4319	ISUZU	SBR422W - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
4320	ISUZU	SBR482 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
4321	ISUZU	SCE420B - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
4322	ISUZU	SCE420B - ISUZU 6BD1T	Engine: N/A			TRUCKS	A-6007	Air Filter
4323	ISUZU	SCR360 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
4324	ISUZU	SCR370 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
4325	ISUZU	SCR370 - ISUZU 6BG1 1985 -1986	Engine: N/A			TRUCKS	A-6007	Air Filter
4326	ISUZU	SCR420 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
4327	ISUZU	SCR420B -	Engine: N/A			TRUCKS	A-6007	Air Filter
4328	ISUZU	SCR420B - ISUZU 6BD1 1982 -1983	Engine: N/A			TRUCKS	A-6007	Air Filter
4329	ISUZU	SCR480 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
4330	ISUZU	SCR480 - ISUZU 6BG1 1985 -1986	Engine: N/A			TRUCKS	A-6007	Air Filter
4331	ISUZU	SCR480B - ISUZU 6BD1 1984	Engine: N/A			TRUCKS	A-6007	Air Filter
4332	ISUZU	SCR500 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
4333	ISUZU	SHG541S - ISUZU E120	Engine: N/A			TRUCKS	A-5408	Air Filter
4334	ISUZU	SHG541S - ISUZU E120	Engine: N/A			TRUCKS	O-1510	Oil Filter
4335	ISUZU	SHG541S - ISUZU E120T	Engine: N/A			TRUCKS	A-5408	Air Filter
4336	ISUZU	SHG541S - ISUZU E120T	Engine: N/A			TRUCKS	O-1510	Oil Filter
4337	ISUZU	SHH711S - ISUZU E120	Engine: N/A			TRUCKS	A-5408	Air Filter
4338	ISUZU	SHH711S - ISUZU E120	Engine: N/A			TRUCKS	O-1510	Oil Filter
4339	ISUZU	SHH711S - ISUZU E120T	Engine: N/A			TRUCKS	A-5408	Air Filter
4340	ISUZU	SHH711S - ISUZU E120T	Engine: N/A			TRUCKS	O-1510	Oil Filter
4341	ISUZU	SHR361 - ISUZU E120	Engine: N/A			TRUCKS	A-5408	Air Filter
4342	ISUZU	SHR361 - ISUZU E120	Engine: N/A			TRUCKS	O-1510	Oil Filter
4343	ISUZU	SHR361 - ISUZU E120T	Engine: N/A			TRUCKS	A-5408	Air Filter
4344	ISUZU	SHR361 - ISUZU E120T	Engine: N/A			TRUCKS	O-1510	Oil Filter
4345	ISUZU	SHZ451S - ISUZU E120	Engine: N/A			TRUCKS	A-5408	Air Filter
4346	ISUZU	SHZ451S - ISUZU E120	Engine: N/A			TRUCKS	O-1510	Oil Filter



Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
4347	ISUZU	SHZ451S - ISUZU E120T	Engine: N/A			TRUCKS	A-5408	Air Filter
4348	ISUZU	SHZ451S - ISUZU E120T	Engine: N/A			TRUCKS	O-1510	Oil Filter
4349	ISUZU	SITEC SERIES II 150 (ISUZU 4JJ1-TCS) -([N/A])	4 cylinder 16 valve with chain driven DOHC 2999 c			TRUCKS	EF-1509	Fuel Filter
4350	ISUZU	SNHR54 - ISUZU 4JA1 1988 -1993	Engine: N/A			TRUCKS	A-1817	Air Filter
4351	ISUZU	SNHR55 - ISUZU 4JB1 1988 -1993	Engine: N/A			TRUCKS	A-1817	Air Filter
4352	ISUZU	SPECIALISED & CRANE/816 -([N/A])0	N/A			TRUCKS	EF-1112	Fuel Filter
4353	ISUZU	SPG541S - ISUZU E120T 1981	Engine: N/A			TRUCKS	A-5408	Air Filter
4354	ISUZU	SPG541S - ISUZU E120T 1981	Engine: N/A			TRUCKS	O-1510	Oil Filter
4355	ISUZU	SPH710 - ISUZU E120 1980	Engine: N/A			TRUCKS	A-5408	Air Filter
4356	ISUZU	SPH710 - ISUZU E120 1980	Engine: N/A			TRUCKS	O-1510	Oil Filter
4357	ISUZU	SPH7115 - ISUZU E120	Engine: N/A			TRUCKS	A-5408	Air Filter
4358	ISUZU	SPH7115 - ISUZU E120	Engine: N/A			TRUCKS	O-1510	Oil Filter
4359	ISUZU	SPH7115 - ISUZU E120T	Engine: N/A			TRUCKS	A-5408	Air Filter
4360	ISUZU	SPH7115 - ISUZU E120T	Engine: N/A			TRUCKS	O-1510	Oil Filter
4361	ISUZU	SPZ440 - ISUZU E120 1980	Engine: N/A			TRUCKS	A-5408	Air Filter
4362	ISUZU	SPZ440 - ISUZU E120 1980	Engine: N/A			TRUCKS	O-1510	Oil Filter
4363	ISUZU	SPZ515 - ISUZU E120	Engine: N/A			TRUCKS	A-5408	Air Filter
4364	ISUZU	SPZ515 - ISUZU E120	Engine: N/A			TRUCKS	O-1510	Oil Filter
4365	ISUZU	SPZ515 - ISUZU E120T	Engine: N/A			TRUCKS	A-5408	Air Filter
4366	ISUZU	SPZ515 - ISUZU E120T	Engine: N/A			TRUCKS	O-1510	Oil Filter
4367	ISUZU	SRZ450 - ISUZU 10PA1 1974 -1979	Engine: N/A			TRUCKS	O-1510	Oil Filter
4368	ISUZU	SRZ580 - ISUZU 10PA1 1974 -1979	Engine: N/A			TRUCKS	O-1510	Oil Filter
4369	ISUZU	SRZ650 - ISUZU 10PA1 1974 -1979	Engine: N/A			TRUCKS	O-1510	Oil Filter
4370	ISUZU	SSZ450.580.650 - ISUZU 10PB1 1979	Engine: N/A			TRUCKS	O-1510	Oil Filter
4371	ISUZU	SVG - ISUZU 12PB1 1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
4372	ISUZU	SVZ - ISUZU 12PB1 1983	Engine: N/A			TRUCKS	O-1510	Oil Filter
4373	ISUZU	SWFS62 - ISUZU 4FG1 1990 -1995	Engine: N/A			TRUCKS	A-1817	Air Filter
4374	ISUZU	SWFS62 - ISUZU 4FG1 1990 -1995	Engine: N/A			TRUCKS	C-1605	Oil Filter
4375	ISUZU	T/TOP SEWER CLEANING/NQR450 -([N/A])	N/A			TRUCKS	A-1019	Air Filter
4376	ISUZU	TABLE TOP & CRANE/NPR200 -([N/A])	N/A			TRUCKS	C-1515	Oil Filter
4377	ISUZU	TLD24 - ISUZU 2.8 L TURBO	Engine: N/A			TRUCKS	A-1505	Air Filter
4378	ISUZU	TLD24 - ISUZU 2.8 L TURBO	Engine: N/A			TRUCKS	A-1817	Air Filter
4379	ISUZU	TLD24 - ISUZU 3.0L	Engine: N/A			TRUCKS	A-1505	Air Filter
4380	ISUZU	TLD24 - ISUZU 3.0L	Engine: N/A			TRUCKS	A-1817	Air Filter
4381	ISUZU	TLD24 - ISUZU 3.3L	Engine: N/A			TRUCKS	A-1505	Air Filter
4382	ISUZU	TLD24 - ISUZU 3.3L	Engine: N/A			TRUCKS	A-1817	Air Filter
4383	ISUZU	TLD24 - ISUZU 4BA1 1975 -1980	Engine: N/A			TRUCKS	A-1817	Air Filter
4384	ISUZU	TLD24 - ISUZU 4BA1 1981 -1984	Engine: N/A			TRUCKS	A-1817	Air Filter
4385	ISUZU	TLD34 - ISUZU 4BA1 1975 -1980	Engine: N/A			TRUCKS	A-1817	Air Filter
4386	ISUZU	TLD44 - ISUZU 2.8 L TURBO	Engine: N/A			TRUCKS	A-1505	Air Filter
4387	ISUZU	TLD44 - ISUZU 2.8 L TURBO	Engine: N/A			TRUCKS	A-1817	Air Filter
4388	ISUZU	TLD44 - ISUZU 3.0L	Engine: N/A			TRUCKS	A-1505	Air Filter
4389	ISUZU	TLD44 - ISUZU 3.0L	Engine: N/A			TRUCKS	A-1817	Air Filter
4390	ISUZU	TLD44 - ISUZU 3.3L	Engine: N/A			TRUCKS	A-1505	Air Filter
4391	ISUZU	TLD44 - ISUZU 3.3L	Engine: N/A			TRUCKS	A-1817	Air Filter
4392	ISUZU	TLD44 - ISUZU 4BA1 1981 -1984	Engine: N/A			TRUCKS	A-1817	Air Filter
4393	ISUZU	TLD54 - ISUZU 4BA1 1975 -1980	Engine: N/A			TRUCKS	A-1817	Air Filter
4394	ISUZU	TLD54 - ISUZU 4BA1 1981 -1984	Engine: N/A			TRUCKS	A-1817	Air Filter
4395	ISUZU	TLD54 - ISUZU 4BA1 1983 -1984	Engine: N/A			TRUCKS	A-1817	Air Filter
4396	ISUZU	TLD56 - ISUZU 2.8 L TURBO	Engine: N/A			TRUCKS	A-1505	Air Filter
4397	ISUZU	TLD56 - ISUZU 2.8 L TURBO	Engine: N/A			TRUCKS	A-1817	Air Filter
4398	ISUZU	TLD56 - ISUZU 3.0L	Engine: N/A			TRUCKS	A-1505	Air Filter
4399	ISUZU	TLD56 - ISUZU 3.0L	Engine: N/A			TRUCKS	A-1817	Air Filter
4400	ISUZU	TLD56 - ISUZU 3.3L	Engine: N/A			TRUCKS	A-1505	Air Filter
4401	ISUZU	TLD56 - ISUZU 3.3L	Engine: N/A			TRUCKS	A-1817	Air Filter
4402	ISUZU	TLD56 - ISUZU 4BC2 1983 -1984	Engine: N/A			TRUCKS	A-1505	Air Filter
4403	ISUZU	TLD64 - ISUZU 4BA1 1975 -1980	Engine: N/A			TRUCKS	A-1817	Air Filter
4404	ISUZU	TRACTOR GIGA	BUS			TRUCKS	O-1532	Oil Filter
4405	ISUZU	TRACTOR GIGA	EX SERIES			TRUCKS	O-1532	Oil Filter
4406	ISUZU	TRACTOR GIGA	FORWARD PJ SERIES			TRUCKS	O-1532	Oil Filter
4407	ISUZU	TRACTOR/6210 -([N/A])	N/A			TRUCKS	C-1522	Oil Filter
4408	ISUZU	TRUCK 810 CV#, CX# [ 83/08 - 86/01 ]	P-CVR14 [ 6QA1 ]	1983	1986	TRUCKS	A-1307	Air Filter

Sakura Filter					ENGINE APPLICATION			
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
4409	ISUZU	TRUCK 810 CV#, CX# [ 83/08 - 86/01 ]	P-CVR14 [ 6QA1 ]	1983	1986	TRUCKS	A-1313	Air Filter
4410	ISUZU	TRUCK 810 CV#, CX# [ 83/08 - 86/01 ]	P-CVR14 [ 6QA1 ]	1983	1986	TRUCKS	O-1512	Oil Filter
4411	ISUZU	TRUCK 810 CV#, CX# [ 83/08 - 86/01 ]	P-CVR14 [ 6QA1 ]	1983	1986	TRUCKS	O-1514	Oil Filter
4412	ISUZU	TRUCK 811 CV#, CX# [ 86/02 - 89/10 ]	P-CVR14 [ 6QA1 ]	1986	1989	TRUCKS	A-1307	Air Filter
4413	ISUZU	TRUCK 811 CV#, CX# [ 86/02 - 89/10 ]	P-CVR14 [ 6QA1 ]	1986	1989	TRUCKS	A-1313	Air Filter
4414	ISUZU	TRUCK 811 CV#, CX# [ 86/02 - 89/10 ]	P-CVR14 [ 6QA1 ]	1986	1989	TRUCKS	O-1512	Oil Filter
4415	ISUZU	TRUCK 811 CV#, CX# [ 86/02 - 89/10 ]	P-CVR14 [ 6QA1 ]	1986	1989	TRUCKS	O-1514	Oil Filter
4416	ISUZU	TRUCK 812 CV#, CX# [ 83/08 - 86/01 ]	P-CVR17 [ 8PC1 ]	1983	1986	TRUCKS	A-1013	Air Filter
4417	ISUZU	TRUCK 812 CV#, CX# [ 83/08 - 86/01 ]	P-CVR17 [ 8PC1 ]	1983	1986	TRUCKS	A-5631	Air Filter
4418	ISUZU	TRUCK 812 CV#, CX# [ 83/08 - 86/01 ]	P-CVR17 [ 8PC1 ]	1983	1986	TRUCKS	O-1512	Oil Filter
4419	ISUZU	TRUCK 812 CV#, CX# [ 83/08 - 86/01 ]	P-CVR17 [ 8PC1 ]	1983	1986	TRUCKS	O-1514	Oil Filter
4420	ISUZU	TRUCK 813 CV#, CX# [ 86/02 - 89/10 ]	P-CVR17 [ 8PC1 ]	1986	1989	TRUCKS	A-1828	Air Filter
4421	ISUZU	TRUCK 813 CV#, CX# [ 86/02 - 89/10 ]	P-CVR17 [ 8PC1 ]	1986	1989	TRUCKS	A-7967	Air Filter
4422	ISUZU	TRUCK 813 CV#, CX# [ 86/02 - 89/10 ]	P-CVR17 [ 8PC1 ]	1986	1989	TRUCKS	O-1512	Oil Filter
4423	ISUZU	TRUCK 813 CV#, CX# [ 86/02 - 89/10 ]	P-CVR17 [ 8PC1 ]	1986	1989	TRUCKS	O-1514	Oil Filter
4424	ISUZU	TRUCK 814 CV#, CX# [ 89/11 - 95/04 ]	U-CVR70 [ 8PD1 ]	1989	1995	TRUCKS	A-1828	Air Filter
4425	ISUZU	TRUCK 814 CV#, CX# [ 89/11 - 95/04 ]	U-CVR70 [ 8PD1 ]	1989	1995	TRUCKS	A-7967	Air Filter
4426	ISUZU	TRUCK 814 CV#, CX# [ 89/11 - 95/04 ]	U-CVR70 [ 8PD1 ]	1989	1995	TRUCKS	O-1522	Oil Filter
4427	ISUZU	TRUCK 814 CV#, CX# [ 89/11 - 95/04 ]	U-CVR70 [ 8PD1 ]	1989	1995	TRUCKS	O-1529	Oil Filter
4428	ISUZU	TRUCK 815 CV#, CX# [ 87/05 - 89/10 ]	P-CVS17 [ 8PC1 ]	1987	1989	TRUCKS	A-1828	Air Filter
4429	ISUZU	TRUCK 815 CV#, CX# [ 87/05 - 89/10 ]	P-CVS17 [ 8PC1 ]	1987	1989	TRUCKS	A-7967	Air Filter
4430	ISUZU	TRUCK 815 CV#, CX# [ 87/05 - 89/10 ]	P-CVS17 [ 8PC1 ]	1987	1989	TRUCKS	O-1512	Oil Filter
4431	ISUZU	TRUCK 815 CV#, CX# [ 87/05 - 89/10 ]	P-CVS17 [ 8PC1 ]	1987	1989	TRUCKS	O-1514	Oil Filter
4432	ISUZU	TRUCK 816 CV#, CX# [ 85/02 - 90/04 ]	ALL WHEEL DRIVE P-CVS19J [ 10PC1 ]	1985	1990	TRUCKS	A-1828	Air Filter
4433	ISUZU	TRUCK 816 CV#, CX# [ 85/02 - 90/04 ]	ALL WHEEL DRIVE P-CVS19J [ 10PC1 ]	1985	1990	TRUCKS	A-7967	Air Filter
4434	ISUZU	TRUCK 816 CV#, CX# [ 85/02 - 90/04 ]	ALL WHEEL DRIVE P-CVS19J [ 10PC1 ]	1985	1990	TRUCKS	O-1512	Oil Filter
4435	ISUZU	TRUCK 816 CV#, CX# [ 85/02 - 90/04 ]	ALL WHEEL DRIVE P-CVS19J [ 10PC1 ]	1985	1990	TRUCKS	O-1513	Oil Filter
4436	ISUZU	TRUCK 817 CV#, CX# [ 90/04 - 95/04 ]	ALL WHEEL DRIVE U-CVS71? [ 10PD1 ]	1990	1995	TRUCKS	A-1828	Air Filter
4437	ISUZU	TRUCK 817 CV#, CX# [ 90/04 - 95/04 ]	ALL WHEEL DRIVE U-CVS71? [ 10PD1 ]	1990	1995	TRUCKS	A-7967	Air Filter
4438	ISUZU	TRUCK 817 CV#, CX# [ 90/04 - 95/04 ]	ALL WHEEL DRIVE U-CVS71? [ 10PD1 ]	1990	1995	TRUCKS	O-1522	Oil Filter
4439	ISUZU	TRUCK 817 CV#, CX# [ 90/04 - 95/04 ]	ALL WHEEL DRIVE U-CVS71? [ 10PD1 ]	1990	1995	TRUCKS	O-1529	Oil Filter
4440	ISUZU	TRUCK 818 CV#, CX# [ 89/08 - 95/04 ]	U-CVZ70 [ 8PD1 ]	1989	1995	TRUCKS	A-1828	Air Filter
4441	ISUZU	TRUCK 818 CV#, CX# [ 89/08 - 95/04 ]	U-CVZ70 [ 8PD1 ]	1989	1995	TRUCKS	A-7967	Air Filter
4442	ISUZU	TRUCK 818 CV#, CX# [ 89/08 - 95/04 ]	U-CVZ70 [ 8PD1 ]	1989	1995	TRUCKS	O-1522	Oil Filter
4443	ISUZU	TRUCK 818 CV#, CX# [ 89/08 - 95/04 ]	U-CVZ70 [ 8PD1 ]	1989	1995	TRUCKS	O-1529	Oil Filter
4444	ISUZU	TRUCK 819 CV#, CX# [ 89/08 - 95/04 ]	U-CVZ71 [ 10PD1 ]	1989	1995	TRUCKS	A-1828	Air Filter
4445	ISUZU	TRUCK 819 CV#, CX# [ 89/08 - 95/04 ]	U-CVZ71 [ 10PD1 ]	1989	1995	TRUCKS	A-7967	Air Filter
4446	ISUZU	TRUCK 819 CV#, CX# [ 89/08 - 95/04 ]	U-CVZ71 [ 10PD1 ]	1989	1995	TRUCKS	O-1522	Oil Filter
4447	ISUZU	TRUCK 819 CV#, CX# [ 89/08 - 95/04 ]	U-CVZ71 [ 10PD1 ]	1989	1995	TRUCKS	O-1529	Oil Filter
4448	ISUZU	TRUCK 820 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXG16 [ 6RA1(T) ]	1983	1986	TRUCKS	A-6010	Air Filter
4449	ISUZU	TRUCK 820 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXG16 [ 6RA1(T) ]	1983	1986	TRUCKS	A-6011	Air Filter
4450	ISUZU	TRUCK 820 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXG16 [ 6RA1(T) ]	1983	1986	TRUCKS	O-1512	Oil Filter
4451	ISUZU	TRUCK 820 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXG16 [ 6RA1(T) ]	1983	1986	TRUCKS	O-1514	Oil Filter
4452	ISUZU	TRUCK 821 CV#, CX# [ 83/08 - 85/01 ]	P-CXG17 [ 8PC1 ]	1983	1985	TRUCKS	A-1013	Air Filter
4453	ISUZU	TRUCK 821 CV#, CX# [ 83/08 - 85/01 ]	P-CXG17 [ 8PC1 ]	1983	1985	TRUCKS	A-5631	Air Filter
4454	ISUZU	TRUCK 821 CV#, CX# [ 83/08 - 85/01 ]	P-CXG17 [ 8PC1 ]	1983	1985	TRUCKS	O-1512	Oil Filter
4455	ISUZU	TRUCK 821 CV#, CX# [ 83/08 - 85/01 ]	P-CXG17 [ 8PC1 ]	1983	1985	TRUCKS	O-1514	Oil Filter
4456	ISUZU	TRUCK 822 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXG17 [ 8PC1(T) ]	1983	1986	TRUCKS	A-6010	Air Filter
4457	ISUZU	TRUCK 822 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXG17 [ 8PC1(T) ]	1983	1986	TRUCKS	A-6011	Air Filter
4458	ISUZU	TRUCK 822 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXG17 [ 8PC1(T) ]	1983	1986	TRUCKS	O-1512	Oil Filter
4459	ISUZU	TRUCK 822 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXG17 [ 8PC1(T) ]	1983	1986	TRUCKS	O-1514	Oil Filter
4460	ISUZU	TRUCK 823 CV#, CX# [ 85/02 - 86/01 ]	P-CXG17 [ 8PC1 ]	1985	1986	TRUCKS	A-1828	Air Filter
4461	ISUZU	TRUCK 823 CV#, CX# [ 85/02 - 86/01 ]	P-CXG17 [ 8PC1 ]	1985	1986	TRUCKS	A-7967	Air Filter
4462	ISUZU	TRUCK 823 CV#, CX# [ 85/02 - 86/01 ]	P-CXG17 [ 8PC1 ]	1985	1986	TRUCKS	O-1512	Oil Filter
4463	ISUZU	TRUCK 823 CV#, CX# [ 85/02 - 86/01 ]	P-CXG17 [ 8PC1 ]	1985	1986	TRUCKS	O-1514	Oil Filter
4464	ISUZU	TRUCK 824 CV#, CX# [ 83/08 - 890/8 ]	P-CXG18 [ 6RB1 ]	1983	1989	TRUCKS	A-1307	Air Filter
4465	ISUZU	TRUCK 824 CV#, CX# [ 83/08 - 890/8 ]	P-CXG18 [ 6RB1 ]	1983	1989	TRUCKS	A-1313	Air Filter

Sakura Filter					ENGINE APPLICATION			
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
4466	ISUZU	TRUCK 824 CV#, CX# [ 83/08 - 89/08 ]	P-CXG18 [ 6RB1 ]	1983	1989	TRUCKS	O-1512	Oil Filter
4467	ISUZU	TRUCK 824 CV#, CX# [ 83/08 - 89/08 ]	P-CXG18 [ 6RB1 ]	1983	1989	TRUCKS	O-1514	Oil Filter
4468	ISUZU	TRUCK 825 CV#, CX# [ 89/09 - 92/04 ]	TURBO U-CXG18 [ 6RB1(T) ]	1989	1992	TRUCKS	A-6010	Air Filter
4469	ISUZU	TRUCK 825 CV#, CX# [ 89/09 - 92/04 ]	TURBO U-CXG18 [ 6RB1(T) ]	1989	1992	TRUCKS	A-6011	Air Filter
4470	ISUZU	TRUCK 825 CV#, CX# [ 89/09 - 92/04 ]	TURBO U-CXG18 [ 6RB1(T) ]	1989	1992	TRUCKS	O-1525	Oil Filter
4471	ISUZU	TRUCK 825 CV#, CX# [ 89/09 - 92/04 ]	TURBO U-CXG18 [ 6RB1(T) ]	1989	1992	TRUCKS	O-1526	Oil Filter
4472	ISUZU	TRUCK 826 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXG19 [ 10PC1-N ]	1983	1986	TRUCKS	A-1013	Air Filter
4473	ISUZU	TRUCK 826 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXG19 [ 10PC1-N ]	1983	1986	TRUCKS	A-5631	Air Filter
4474	ISUZU	TRUCK 826 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXG19 [ 10PC1-N ]	1983	1986	TRUCKS	O-1512	Oil Filter
4475	ISUZU	TRUCK 826 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXG19 [ 10PC1-N ]	1983	1986	TRUCKS	O-1513	Oil Filter
4476	ISUZU	TRUCK 827 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXG19 [ 10PC1-S ]	1983	1986	TRUCKS	A-1828	Air Filter
4477	ISUZU	TRUCK 827 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXG19 [ 10PC1-S ]	1983	1986	TRUCKS	A-7967	Air Filter
4478	ISUZU	TRUCK 827 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXG19 [ 10PC1-S ]	1983	1986	TRUCKS	O-1512	Oil Filter
4479	ISUZU	TRUCK 827 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXG19 [ 10PC1-S ]	1983	1986	TRUCKS	O-1513	Oil Filter
4480	ISUZU	TRUCK 828 CV#, CX# [ 86/02 - 87/08 ]	P-CXG19 [ 10PC1 ]	1986	1987	TRUCKS	A-1828	Air Filter
4481	ISUZU	TRUCK 828 CV#, CX# [ 86/02 - 87/08 ]	P-CXG19 [ 10PC1 ]	1986	1987	TRUCKS	A-7967	Air Filter
4482	ISUZU	TRUCK 828 CV#, CX# [ 86/02 - 87/08 ]	P-CXG19 [ 10PC1 ]	1986	1987	TRUCKS	O-1512	Oil Filter
4483	ISUZU	TRUCK 828 CV#, CX# [ 86/02 - 87/08 ]	P-CXG19 [ 10PC1 ]	1986	1987	TRUCKS	O-1513	Oil Filter
4484	ISUZU	TRUCK 829 CV#, CX# [ 83/08 - 87/08 ]	P-CXG21 [ 12PC1 ]	1983	1987	TRUCKS	A-6010	Air Filter
4485	ISUZU	TRUCK 829 CV#, CX# [ 83/08 - 87/08 ]	P-CXG21 [ 12PC1 ]	1983	1987	TRUCKS	A-6011	Air Filter
4486	ISUZU	TRUCK 829 CV#, CX# [ 83/08 - 87/08 ]	P-CXG21 [ 12PC1 ]	1983	1987	TRUCKS	O-1512	Oil Filter
4487	ISUZU	TRUCK 829 CV#, CX# [ 83/08 - 87/08 ]	P-CXG21 [ 12PC1 ]	1983	1987	TRUCKS	O-1513	Oil Filter
4488	ISUZU	TRUCK 830 CV#, CX# [ 86/02 - 89/10 ]	TURBO P-CXG23 [ 6SD1(T) ]	1986	1989	TRUCKS	A-6010	Air Filter
4489	ISUZU	TRUCK 830 CV#, CX# [ 86/02 - 89/10 ]	TURBO P-CXG23 [ 6SD1(T) ]	1986	1989	TRUCKS	A-6011	Air Filter
4490	ISUZU	TRUCK 830 CV#, CX# [ 86/02 - 89/10 ]	TURBO P-CXG23 [ 6SD1(T) ]	1986	1989	TRUCKS	O-1512	Oil Filter
4491	ISUZU	TRUCK 831 CV#, CX# [ 89/11 - 92/04 ]	TURBO P-CXG23 [ 6SD1(T) ]	1989	1992	TRUCKS	A-6010	Air Filter
4492	ISUZU	TRUCK 831 CV#, CX# [ 89/11 - 92/04 ]	TURBO P-CXG23 [ 6SD1(T) ]	1989	1992	TRUCKS	A-6011	Air Filter
4493	ISUZU	TRUCK 831 CV#, CX# [ 89/11 - 92/04 ]	TURBO P-CXG23 [ 6SD1(T) ]	1989	1992	TRUCKS	O-1526	Oil Filter
4494	ISUZU	TRUCK 831 CV#, CX# [ 89/11 - 92/04 ]	TURBO P-CXG23 [ 6SD1(T) ]	1989	1992	TRUCKS	O-1529	Oil Filter
4495	ISUZU	TRUCK 832 CV#, CX# [ 92/05 - 94/09 ]	TURBO P-CXG23 [ 6SD1(T) ]	1992	1994	TRUCKS	A-6010	Air Filter
4496	ISUZU	TRUCK 832 CV#, CX# [ 92/05 - 94/09 ]	TURBO P-CXG23 [ 6SD1(T) ]	1992	1994	TRUCKS	A-6011	Air Filter
4497	ISUZU	TRUCK 832 CV#, CX# [ 92/05 - 94/09 ]	TURBO P-CXG23 [ 6SD1(T) ]	1992	1994	TRUCKS	O-1522	Oil Filter
4498	ISUZU	TRUCK 832 CV#, CX# [ 92/05 - 94/09 ]	TURBO P-CXG23 [ 6SD1(T) ]	1992	1994	TRUCKS	O-1529	Oil Filter
4499	ISUZU	TRUCK 833 CV#, CX# [ 92/05 - 94/09 ]	TURBO U-CXG50 [ 6WA1(T) ]	1992	1994	TRUCKS	A-6014	Air Filter
4500	ISUZU	TRUCK 833 CV#, CX# [ 92/05 - 94/09 ]	TURBO U-CXG50 [ 6WA1(T) ]	1992	1994	TRUCKS	O-1522	Oil Filter
4501	ISUZU	TRUCK 833 CV#, CX# [ 92/05 - 94/09 ]	TURBO U-CXG50 [ 6WA1(T) ]	1992	1994	TRUCKS	O-1529	Oil Filter
4502	ISUZU	TRUCK 834 CV#, CX# [ 89/09 - 94/09 ]	U-CXG70 [ 8PD1 ]	1989	1994	TRUCKS	A-1828	Air Filter
4503	ISUZU	TRUCK 834 CV#, CX# [ 89/09 - 94/09 ]	U-CXG70 [ 8PD1 ]	1989	1994	TRUCKS	A-7967	Air Filter
4504	ISUZU	TRUCK 834 CV#, CX# [ 89/09 - 94/09 ]	U-CXG70 [ 8PD1 ]	1989	1994	TRUCKS	O-1522	Oil Filter
4505	ISUZU	TRUCK 834 CV#, CX# [ 89/09 - 94/09 ]	U-CXG70 [ 8PD1 ]	1989	1994	TRUCKS	O-1529	Oil Filter
4506	ISUZU	TRUCK 835 CV#, CX# [ 89/09 - 94/09 ]	U-CXG71 [ 10PD1 ]	1989	1994	TRUCKS	A-1828	Air Filter
4507	ISUZU	TRUCK 835 CV#, CX# [ 89/09 - 94/09 ]	U-CXG71 [ 10PD1 ]	1989	1994	TRUCKS	A-7967	Air Filter
4508	ISUZU	TRUCK 835 CV#, CX# [ 89/09 - 94/09 ]	U-CXG71 [ 10PD1 ]	1989	1994	TRUCKS	O-1522	Oil Filter
4509	ISUZU	TRUCK 835 CV#, CX# [ 89/09 - 94/09 ]	U-CXG71 [ 10PD1 ]	1989	1994	TRUCKS	O-1529	Oil Filter
4510	ISUZU	TRUCK 836 CV#, CX# [ 86/02 - 89/08 ]	P-CXH18 [ 6RB1 ]	1986	1989	TRUCKS	A-6010	Air Filter
4511	ISUZU	TRUCK 836 CV#, CX# [ 86/02 - 89/08 ]	P-CXH18 [ 6RB1 ]	1986	1989	TRUCKS	A-6011	Air Filter
4512	ISUZU	TRUCK 836 CV#, CX# [ 86/02 - 89/08 ]	P-CXH18 [ 6RB1 ]	1986	1989	TRUCKS	O-1512	Oil Filter
4513	ISUZU	TRUCK 836 CV#, CX# [ 86/02 - 89/08 ]	P-CXH18 [ 6RB1 ]	1986	1989	TRUCKS	O-1514	Oil Filter
4514	ISUZU	TRUCK 837 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXH19 [ 10PC1-N ]	1983	1986	TRUCKS	A-1013	Air Filter
4515	ISUZU	TRUCK 837 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXH19 [ 10PC1-N ]	1983	1986	TRUCKS	A-5631	Air Filter
4516	ISUZU	TRUCK 837 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXH19 [ 10PC1-N ]	1983	1986	TRUCKS	O-1512	Oil Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
4517	ISUZU	TRUCK 837 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXH19 [ 10PC1-N ]	1983	1986	TRUCKS	O-1513	Oil Filter
4518	ISUZU	TRUCK 838 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXH19 [ 10PC1-S ]	1983	1986	TRUCKS	A-1828	Air Filter
4519	ISUZU	TRUCK 838 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXH19 [ 10PC1-S ]	1983	1986	TRUCKS	A-7967	Air Filter
4520	ISUZU	TRUCK 838 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXH19 [ 10PC1-S ]	1983	1986	TRUCKS	O-1512	Oil Filter
4521	ISUZU	TRUCK 838 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXH19 [ 10PC1-S ]	1983	1986	TRUCKS	O-1513	Oil Filter
4522	ISUZU	TRUCK 839 CV#, CX# [ 86/02 - 89/08 ]	P-CXH19 [ 10PC1 ]	1986	1989	TRUCKS	A-1828	Air Filter
4523	ISUZU	TRUCK 839 CV#, CX# [ 86/02 - 89/08 ]	P-CXH19 [ 10PC1 ]	1986	1989	TRUCKS	A-7967	Air Filter
4524	ISUZU	TRUCK 839 CV#, CX# [ 86/02 - 89/08 ]	P-CXH19 [ 10PC1 ]	1986	1989	TRUCKS	O-1512	Oil Filter
4525	ISUZU	TRUCK 839 CV#, CX# [ 86/02 - 89/08 ]	P-CXH19 [ 10PC1 ]	1986	1989	TRUCKS	O-1513	Oil Filter
4526	ISUZU	TRUCK 840 CV#, CX# [ 83/08 - 87/08 ]	P-CXH21 [ 12PC1 ]	1983	1987	TRUCKS	A-6010	Air Filter
4527	ISUZU	TRUCK 840 CV#, CX# [ 83/08 - 87/08 ]	P-CXH21 [ 12PC1 ]	1983	1987	TRUCKS	A-6011	Air Filter
4528	ISUZU	TRUCK 840 CV#, CX# [ 83/08 - 87/08 ]	P-CXH21 [ 12PC1 ]	1983	1987	TRUCKS	O-1512	Oil Filter
4529	ISUZU	TRUCK 840 CV#, CX# [ 83/08 - 87/08 ]	P-CXH21 [ 12PC1 ]	1983	1987	TRUCKS	O-1513	Oil Filter
4530	ISUZU	TRUCK 841 CV#, CX# [ 89/11 - 92/04 ]	TURBO U-CXH23 [ 6SD1(T) ]	1989	1992	TRUCKS	A-6010	Air Filter
4531	ISUZU	TRUCK 841 CV#, CX# [ 89/11 - 92/04 ]	TURBO U-CXH23 [ 6SD1(T) ]	1989	1992	TRUCKS	A-6011	Air Filter
4532	ISUZU	TRUCK 841 CV#, CX# [ 89/11 - 92/04 ]	TURBO U-CXH23 [ 6SD1(T) ]	1989	1992	TRUCKS	O-1526	Oil Filter
4533	ISUZU	TRUCK 841 CV#, CX# [ 89/11 - 92/04 ]	TURBO U-CXH23 [ 6SD1(T) ]	1989	1992	TRUCKS	O-1529	Oil Filter
4534	ISUZU	TRUCK 842 CV#, CX# [ 92/05 - 94/09 ]	TURBO U-CXH23 [ 6SD1(T) ]	1992	1994	TRUCKS	A-6010	Air Filter
4535	ISUZU	TRUCK 842 CV#, CX# [ 92/05 - 94/09 ]	TURBO U-CXH23 [ 6SD1(T) ]	1992	1994	TRUCKS	A-6011	Air Filter
4536	ISUZU	TRUCK 842 CV#, CX# [ 92/05 - 94/09 ]	TURBO U-CXH23 [ 6SD1(T) ]	1992	1994	TRUCKS	O-1522	Oil Filter
4537	ISUZU	TRUCK 842 CV#, CX# [ 92/05 - 94/09 ]	TURBO U-CXH23 [ 6SD1(T) ]	1992	1994	TRUCKS	O-1529	Oil Filter
4538	ISUZU	TRUCK 843 CV#, CX# [ 92/07 - 94/09 ]	TURBO U-CXH50 [ 6WA1(T) ]	1992	1994	TRUCKS	A-6014	Air Filter
4539	ISUZU	TRUCK 843 CV#, CX# [ 92/07 - 94/09 ]	TURBO U-CXH50 [ 6WA1(T) ]	1992	1994	TRUCKS	O-1522	Oil Filter
4540	ISUZU	TRUCK 843 CV#, CX# [ 92/07 - 94/09 ]	TURBO U-CXH50 [ 6WA1(T) ]	1992	1994	TRUCKS	O-1529	Oil Filter
4541	ISUZU	TRUCK 844 CV#, CX# [ 89/09 - 94/09 ]	U-CXH71 [ 10PD1 ]	1989	1994	TRUCKS	A-1828	Air Filter
4542	ISUZU	TRUCK 844 CV#, CX# [ 89/09 - 94/09 ]	U-CXH71 [ 10PD1 ]	1989	1994	TRUCKS	A-7967	Air Filter
4543	ISUZU	TRUCK 844 CV#, CX# [ 89/09 - 94/09 ]	U-CXH71 [ 10PD1 ]	1989	1994	TRUCKS	O-1522	Oil Filter
4544	ISUZU	TRUCK 844 CV#, CX# [ 89/09 - 94/09 ]	U-CXH71 [ 10PD1 ]	1989	1994	TRUCKS	O-1529	Oil Filter
4545	ISUZU	TRUCK 845 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXK17 [ 8PC1(T) ]	1983	1986	TRUCKS	A-6010	Air Filter
4546	ISUZU	TRUCK 845 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXK17 [ 8PC1(T) ]	1983	1986	TRUCKS	A-6011	Air Filter
4547	ISUZU	TRUCK 845 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXK17 [ 8PC1(T) ]	1983	1986	TRUCKS	O-1512	Oil Filter
4548	ISUZU	TRUCK 845 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXK17 [ 8PC1(T) ]	1983	1986	TRUCKS	O-1514	Oil Filter
4549	ISUZU	TRUCK 846 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXK19 [ 10PC1-N ]	1983	1986	TRUCKS	A-1013	Air Filter
4550	ISUZU	TRUCK 846 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXK19 [ 10PC1-N ]	1983	1986	TRUCKS	A-5631	Air Filter
4551	ISUZU	TRUCK 846 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXK19 [ 10PC1-N ]	1983	1986	TRUCKS	O-1512	Oil Filter
4552	ISUZU	TRUCK 846 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXK19 [ 10PC1-N ]	1983	1986	TRUCKS	O-1513	Oil Filter
4553	ISUZU	TRUCK 847 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXK19 [ 10PC1-S ]	1983	1986	TRUCKS	A-1828	Air Filter
4554	ISUZU	TRUCK 847 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXK19 [ 10PC1-S ]	1983	1986	TRUCKS	A-7967	Air Filter
4555	ISUZU	TRUCK 847 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXK19 [ 10PC1-S ]	1983	1986	TRUCKS	O-1512	Oil Filter
4556	ISUZU	TRUCK 847 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXK19 [ 10PC1-S ]	1983	1986	TRUCKS	O-1513	Oil Filter
4557	ISUZU	TRUCK 848 CV#, CX# [ 86/02 - 89/08 ]	P-CXK19 [ 10PC1 ]	1986	1989	TRUCKS	A-1828	Air Filter
4558	ISUZU	TRUCK 848 CV#, CX# [ 86/02 - 89/08 ]	P-CXK19 [ 10PC1 ]	1986	1989	TRUCKS	A-7967	Air Filter
4559	ISUZU	TRUCK 848 CV#, CX# [ 86/02 - 89/08 ]	P-CXK19 [ 10PC1 ]	1986	1989	TRUCKS	O-1512	Oil Filter
4560	ISUZU	TRUCK 848 CV#, CX# [ 86/02 - 89/08 ]	P-CXK19 [ 10PC1 ]	1986	1989	TRUCKS	O-1513	Oil Filter
4561	ISUZU	TRUCK 849 CV#, CX# [ 86/02 - 89/10 ]	TURBO P-CXK23 [ 6SD1(T) ]	1986	1989	TRUCKS	A-6010	Air Filter
4562	ISUZU	TRUCK 849 CV#, CX# [ 86/02 - 89/10 ]	TURBO P-CXK23 [ 6SD1(T) ]	1986	1989	TRUCKS	A-6011	Air Filter
4563	ISUZU	TRUCK 849 CV#, CX# [ 86/02 - 89/10 ]	TURBO P-CXK23 [ 6SD1(T) ]	1986	1989	TRUCKS	O-1512	Oil Filter
4564	ISUZU	TRUCK 850 CV#, CX# [ 89/11 - 92/04 ]	TURBO U-CXK23 [ 6SD1(T) ]	1989	1992	TRUCKS	A-6010	Air Filter
4565	ISUZU	TRUCK 850 CV#, CX# [ 89/11 - 92/04 ]	TURBO U-CXK23 [ 6SD1(T) ]	1989	1992	TRUCKS	A-6011	Air Filter



Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
4566	ISUZU	TRUCK 850 CV#, CX# [ 89/11 - 92/04 ]	TURBO U-CXK23 [ 6SD1(T) ]	1989	1992	TRUCKS	O-1526	Oil Filter
4567	ISUZU	TRUCK 850 CV#, CX# [ 89/11 - 92/04 ]	TURBO U-CXK23 [ 6SD1(T) ]	1989	1992	TRUCKS	O-1529	Oil Filter
4568	ISUZU	TRUCK 851 CV#, CX# [ 92/05 - 94/09 ]	TURBO U-CXK23 [ 6SD1(T) ]	1992	1994	TRUCKS	A-6010	Air Filter
4569	ISUZU	TRUCK 851 CV#, CX# [ 92/05 - 94/09 ]	TURBO U-CXK23 [ 6SD1(T) ]	1992	1994	TRUCKS	A-6011	Air Filter
4570	ISUZU	TRUCK 851 CV#, CX# [ 92/05 - 94/09 ]	TURBO U-CXK23 [ 6SD1(T) ]	1992	1994	TRUCKS	O-1522	Oil Filter
4571	ISUZU	TRUCK 851 CV#, CX# [ 92/05 - 94/09 ]	TURBO U-CXK23 [ 6SD1(T) ]	1992	1994	TRUCKS	O-1529	Oil Filter
4572	ISUZU	TRUCK 852 CV#, CX# [ 92/10 - 94/09 ]	TURBO U-CXK50 [ 6WA1(T) ]	1992	1994	TRUCKS	A-6014	Air Filter
4573	ISUZU	TRUCK 852 CV#, CX# [ 92/10 - 94/09 ]	TURBO U-CXK50 [ 6WA1(T) ]	1992	1994	TRUCKS	O-1522	Oil Filter
4574	ISUZU	TRUCK 852 CV#, CX# [ 92/10 - 94/09 ]	TURBO U-CXK50 [ 6WA1(T) ]	1992	1994	TRUCKS	O-1529	Oil Filter
4575	ISUZU	TRUCK 853 CV#, CX# [ 92/10 - 94/09 ]	U-CXK71 [ 10PD1 ]	1992	1994	TRUCKS	A-1828	Air Filter
4576	ISUZU	TRUCK 853 CV#, CX# [ 92/10 - 94/09 ]	U-CXK71 [ 10PD1 ]	1992	1994	TRUCKS	A-7967	Air Filter
4577	ISUZU	TRUCK 853 CV#, CX# [ 92/10 - 94/09 ]	U-CXK71 [ 10PD1 ]	1992	1994	TRUCKS	O-1522	Oil Filter
4578	ISUZU	TRUCK 853 CV#, CX# [ 92/10 - 94/09 ]	U-CXK71 [ 10PD1 ]	1992	1994	TRUCKS	O-1529	Oil Filter
4579	ISUZU	TRUCK 854 CV#, CX# [ 87/07 - 89/12 ]	P-CXL19 [ 10PC1 ]	1987	1989	TRUCKS	A-1828	Air Filter
4580	ISUZU	TRUCK 854 CV#, CX# [ 87/07 - 89/12 ]	P-CXL19 [ 10PC1 ]	1987	1989	TRUCKS	A-7967	Air Filter
4581	ISUZU	TRUCK 854 CV#, CX# [ 87/07 - 89/12 ]	P-CXL19 [ 10PC1 ]	1987	1989	TRUCKS	O-1512	Oil Filter
4582	ISUZU	TRUCK 854 CV#, CX# [ 87/07 - 89/12 ]	P-CXL19 [ 10PC1 ]	1987	1989	TRUCKS	O-1513	Oil Filter
4583	ISUZU	TRUCK 855 CV#, CX# [ 89/09 - 94/09 ]	U-CXL71 [ 10PD1 ]	1989	1994	TRUCKS	A-1828	Air Filter
4584	ISUZU	TRUCK 855 CV#, CX# [ 89/09 - 94/09 ]	U-CXL71 [ 10PD1 ]	1989	1994	TRUCKS	A-7967	Air Filter
4585	ISUZU	TRUCK 855 CV#, CX# [ 89/09 - 94/09 ]	U-CXL71 [ 10PD1 ]	1989	1994	TRUCKS	O-1522	Oil Filter
4586	ISUZU	TRUCK 855 CV#, CX# [ 89/09 - 94/09 ]	U-CXL71 [ 10PD1 ]	1989	1994	TRUCKS	O-1529	Oil Filter
4587	ISUZU	TRUCK 856 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXM16 [ 6RA1(T) ]	1983	1986	TRUCKS	A-6010	Air Filter
4588	ISUZU	TRUCK 856 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXM16 [ 6RA1(T) ]	1983	1986	TRUCKS	A-6011	Air Filter
4589	ISUZU	TRUCK 856 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXM16 [ 6RA1(T) ]	1983	1986	TRUCKS	O-1512	Oil Filter
4590	ISUZU	TRUCK 856 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXM16 [ 6RA1(T) ]	1983	1986	TRUCKS	O-1514	Oil Filter
4591	ISUZU	TRUCK 857 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXM17 [ 8PC1(T) ]	1983	1986	TRUCKS	A-6010	Air Filter
4592	ISUZU	TRUCK 857 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXM17 [ 8PC1(T) ]	1983	1986	TRUCKS	A-6011	Air Filter
4593	ISUZU	TRUCK 857 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXM17 [ 8PC1(T) ]	1983	1986	TRUCKS	O-1512	Oil Filter
4594	ISUZU	TRUCK 857 CV#, CX# [ 83/08 - 86/01 ]	TURBO P-CXM17 [ 8PC1(T) ]	1983	1986	TRUCKS	O-1514	Oil Filter
4595	ISUZU	TRUCK 858 CV#, CX# [ 83/08 - 89/08 ]	P-CXM18 [ 6RB1 ]	1983	1989	TRUCKS	A-1307	Air Filter
4596	ISUZU	TRUCK 858 CV#, CX# [ 83/08 - 89/08 ]	P-CXM18 [ 6RB1 ]	1983	1989	TRUCKS	A-1313	Air Filter
4597	ISUZU	TRUCK 858 CV#, CX# [ 83/08 - 89/08 ]	P-CXM18 [ 6RB1 ]	1983	1989	TRUCKS	O-1512	Oil Filter
4598	ISUZU	TRUCK 858 CV#, CX# [ 83/08 - 89/08 ]	P-CXM18 [ 6RB1 ]	1983	1989	TRUCKS	O-1514	Oil Filter
4599	ISUZU	TRUCK 859 CV#, CX# [ 89/08 - 92/04 ]	TURBO U-CXM18 [ 6RB1(T) ]	1989	1992	TRUCKS	A-6010	Air Filter
4600	ISUZU	TRUCK 859 CV#, CX# [ 89/08 - 92/04 ]	TURBO U-CXM18 [ 6RB1(T) ]	1989	1992	TRUCKS	A-6011	Air Filter
4601	ISUZU	TRUCK 859 CV#, CX# [ 89/08 - 92/04 ]	TURBO U-CXM18 [ 6RB1(T) ]	1989	1992	TRUCKS	O-1525	Oil Filter
4602	ISUZU	TRUCK 859 CV#, CX# [ 89/08 - 92/04 ]	TURBO U-CXM18 [ 6RB1(T) ]	1989	1992	TRUCKS	O-1526	Oil Filter
4603	ISUZU	TRUCK 860 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXM19 [ 10PC1-N ]	1983	1986	TRUCKS	A-1013	Air Filter
4604	ISUZU	TRUCK 860 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXM19 [ 10PC1-N ]	1983	1986	TRUCKS	A-5631	Air Filter
4605	ISUZU	TRUCK 860 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXM19 [ 10PC1-N ]	1983	1986	TRUCKS	O-1512	Oil Filter
4606	ISUZU	TRUCK 860 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXM19 [ 10PC1-N ]	1983	1986	TRUCKS	O-1513	Oil Filter
4607	ISUZU	TRUCK 861 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXM19 [ 10PC1-S ]	1983	1986	TRUCKS	A-1828	Air Filter
4608	ISUZU	TRUCK 861 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXM19 [ 10PC1-S ]	1983	1986	TRUCKS	A-7967	Air Filter
4609	ISUZU	TRUCK 861 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXM19 [ 10PC1-S ]	1983	1986	TRUCKS	O-1512	Oil Filter
4610	ISUZU	TRUCK 861 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXM19 [ 10PC1-S ]	1983	1986	TRUCKS	O-1513	Oil Filter
4611	ISUZU	TRUCK 862 CV#, CX# [ 86/02 - 89/08 ]	P-CXM19 [ 10PC1 ]	1986	1989	TRUCKS	A-1828	Air Filter
4612	ISUZU	TRUCK 862 CV#, CX# [ 86/02 - 89/08 ]	P-CXM19 [ 10PC1 ]	1986	1989	TRUCKS	A-7967	Air Filter
4613	ISUZU	TRUCK 862 CV#, CX# [ 86/02 - 89/08 ]	P-CXM19 [ 10PC1 ]	1986	1989	TRUCKS	O-1512	Oil Filter
4614	ISUZU	TRUCK 862 CV#, CX# [ 86/02 - 89/08 ]	P-CXM19 [ 10PC1 ]	1986	1989	TRUCKS	O-1513	Oil Filter
4615	ISUZU	TRUCK 863 CV#, CX# [ 86/02 - 89/10 ]	TURBO P-CXM23 [ 6SD1(T) ]	1986	1989	TRUCKS	A-6010	Air Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
4616	ISUZU	TRUCK 863 CV#, CX# [ 86/02 - 89/10 ]	TURBO P-CXM23 [ 6SD1(T) ]	1986	1989	TRUCKS	A-6011	Air Filter
4617	ISUZU	TRUCK 863 CV#, CX# [ 86/02 - 89/10 ]	TURBO P-CXM23 [ 6SD1(T) ]	1986	1989	TRUCKS	O-1512	Oil Filter
4618	ISUZU	TRUCK 864 CV#, CX# [ 89/10 - 92/04 ]	TURBO U-CXM23 [ 6SD1(T) ]	1989	1992	TRUCKS	A-6010	Air Filter
4619	ISUZU	TRUCK 864 CV#, CX# [ 89/10 - 92/04 ]	TURBO U-CXM23 [ 6SD1(T) ]	1989	1992	TRUCKS	A-6011	Air Filter
4620	ISUZU	TRUCK 864 CV#, CX# [ 89/10 - 92/04 ]	TURBO U-CXM23 [ 6SD1(T) ]	1989	1992	TRUCKS	O-1526	Oil Filter
4621	ISUZU	TRUCK 864 CV#, CX# [ 89/10 - 92/04 ]	TURBO U-CXM23 [ 6SD1(T) ]	1989	1992	TRUCKS	O-1529	Oil Filter
4622	ISUZU	TRUCK 865 CV#, CX# [ 92/05 - 94/09 ]	TURBO U-CXM23 [ 6SD1(T) ]	1992	1994	TRUCKS	A-6010	Air Filter
4623	ISUZU	TRUCK 865 CV#, CX# [ 92/05 - 94/09 ]	TURBO U-CXM23 [ 6SD1(T) ]	1992	1994	TRUCKS	A-6011	Air Filter
4624	ISUZU	TRUCK 865 CV#, CX# [ 92/05 - 94/09 ]	TURBO U-CXM23 [ 6SD1(T) ]	1992	1994	TRUCKS	O-1522	Oil Filter
4625	ISUZU	TRUCK 865 CV#, CX# [ 92/05 - 94/09 ]	TURBO U-CXM23 [ 6SD1(T) ]	1992	1994	TRUCKS	O-1529	Oil Filter
4626	ISUZU	TRUCK 866 CV#, CX# [ 92/07 - 94/09 ]	TURBO U-CXM50 [ 6WA1(T) ]	1992	1994	TRUCKS	A-6014	Air Filter
4627	ISUZU	TRUCK 866 CV#, CX# [ 92/07 - 94/09 ]	TURBO U-CXM50 [ 6WA1(T) ]	1992	1994	TRUCKS	O-1522	Oil Filter
4628	ISUZU	TRUCK 866 CV#, CX# [ 92/07 - 94/09 ]	TURBO U-CXM50 [ 6WA1(T) ]	1992	1994	TRUCKS	O-1529	Oil Filter
4629	ISUZU	TRUCK 867 CV#, CX# [ 89/09 - 94/09 ]	U-CXM70 [ 8PD1 ]	1989	1994	TRUCKS	A-1828	Air Filter
4630	ISUZU	TRUCK 867 CV#, CX# [ 89/09 - 94/09 ]	U-CXM70 [ 8PD1 ]	1989	1994	TRUCKS	A-7967	Air Filter
4631	ISUZU	TRUCK 867 CV#, CX# [ 89/09 - 94/09 ]	U-CXM70 [ 8PD1 ]	1989	1994	TRUCKS	O-1522	Oil Filter
4632	ISUZU	TRUCK 867 CV#, CX# [ 89/09 - 94/09 ]	U-CXM70 [ 8PD1 ]	1989	1994	TRUCKS	O-1529	Oil Filter
4633	ISUZU	TRUCK 868 CV#, CX# [ 89/09 - 94/09 ]	U-CXM71 [ 10PD1 ]	1989	1994	TRUCKS	A-1828	Air Filter
4634	ISUZU	TRUCK 868 CV#, CX# [ 89/09 - 94/09 ]	U-CXM71 [ 10PD1 ]	1989	1994	TRUCKS	A-7967	Air Filter
4635	ISUZU	TRUCK 868 CV#, CX# [ 89/09 - 94/09 ]	U-CXM71 [ 10PD1 ]	1989	1994	TRUCKS	O-1522	Oil Filter
4636	ISUZU	TRUCK 868 CV#, CX# [ 89/09 - 94/09 ]	U-CXM71 [ 10PD1 ]	1989	1994	TRUCKS	O-1529	Oil Filter
4637	ISUZU	TRUCK 869 CV#, CX# [ 89/09 - 92/06 ]	U-CXM72 [ 12PD1 ]	1989	1992	TRUCKS	A-6010	Air Filter
4638	ISUZU	TRUCK 869 CV#, CX# [ 89/09 - 92/06 ]	U-CXM72 [ 12PD1 ]	1989	1992	TRUCKS	A-6011	Air Filter
4639	ISUZU	TRUCK 869 CV#, CX# [ 89/09 - 92/06 ]	U-CXM72 [ 12PD1 ]	1989	1992	TRUCKS	O-1529	Oil Filter
4640	ISUZU	TRUCK 870 CV#, CX# [ 92/07 - 94/09 ]	U-CXM72 [ 12PD1 ]	1992	1994	TRUCKS	A-6010	Air Filter
4641	ISUZU	TRUCK 870 CV#, CX# [ 92/07 - 94/09 ]	U-CXM72 [ 12PD1 ]	1992	1994	TRUCKS	A-6011	Air Filter
4642	ISUZU	TRUCK 870 CV#, CX# [ 92/07 - 94/09 ]	U-CXM72 [ 12PD1 ]	1992	1994	TRUCKS	O-1521	Oil Filter
4643	ISUZU	TRUCK 870 CV#, CX# [ 92/07 - 94/09 ]	U-CXM72 [ 12PD1 ]	1992	1994	TRUCKS	O-1529	Oil Filter
4644	ISUZU	TRUCK 871 CV#, CX# [ 87/05 - 90/04 ]	ALL WHEEL DRIVE P-CXW17M [ 8PC1 ]	1987	1990	TRUCKS	A-1828	Air Filter
4645	ISUZU	TRUCK 871 CV#, CX# [ 87/05 - 90/04 ]	ALL WHEEL DRIVE P-CXW17M [ 8PC1 ]	1987	1990	TRUCKS	A-7967	Air Filter
4646	ISUZU	TRUCK 871 CV#, CX# [ 87/05 - 90/04 ]	ALL WHEEL DRIVE P-CXW17M [ 8PC1 ]	1987	1990	TRUCKS	O-1512	Oil Filter
4647	ISUZU	TRUCK 871 CV#, CX# [ 87/05 - 90/04 ]	ALL WHEEL DRIVE P-CXW17M [ 8PC1 ]	1987	1990	TRUCKS	O-1514	Oil Filter
4648	ISUZU	TRUCK 872 CV#, CX# [ 85/02 - 90/04 ]	ALL WHEEL DRIVE P-CXW19P [ 10PC1-S ]	1985	1990	TRUCKS	A-1828	Air Filter
4649	ISUZU	TRUCK 872 CV#, CX# [ 85/02 - 90/04 ]	ALL WHEEL DRIVE P-CXW19P [ 10PC1-S ]	1985	1990	TRUCKS	A-7967	Air Filter
4650	ISUZU	TRUCK 872 CV#, CX# [ 85/02 - 90/04 ]	ALL WHEEL DRIVE P-CXW19P [ 10PC1-S ]	1985	1990	TRUCKS	O-1512	Oil Filter
4651	ISUZU	TRUCK 872 CV#, CX# [ 85/02 - 90/04 ]	ALL WHEEL DRIVE P-CXW19P [ 10PC1-S ]	1985	1990	TRUCKS	O-1513	Oil Filter
4652	ISUZU	TRUCK 873 CV#, CX# [ 90/06 - 94/09 ]	ALL WHEEL DRIVE U-CXW71 [ 10PD1 ]	1990	1994	TRUCKS	A-1828	Air Filter
4653	ISUZU	TRUCK 873 CV#, CX# [ 90/06 - 94/09 ]	ALL WHEEL DRIVE U-CXW71 [ 10PD1 ]	1990	1994	TRUCKS	A-7967	Air Filter
4654	ISUZU	TRUCK 873 CV#, CX# [ 90/06 - 94/09 ]	ALL WHEEL DRIVE U-CXW71 [ 10PD1 ]	1990	1994	TRUCKS	O-1522	Oil Filter
4655	ISUZU	TRUCK 873 CV#, CX# [ 90/06 - 94/09 ]	ALL WHEEL DRIVE U-CXW71 [ 10PD1 ]	1990	1994	TRUCKS	O-1529	Oil Filter
4656	ISUZU	TRUCK 874 CV#, CX# [ 83/08 - 89/08 ]	P-CXZ18 [ 4RB1 ]	1983	1989	TRUCKS	A-1307	Air Filter
4657	ISUZU	TRUCK 874 CV#, CX# [ 83/08 - 89/08 ]	P-CXZ18 [ 4RB1 ]	1983	1989	TRUCKS	A-1313	Air Filter
4658	ISUZU	TRUCK 874 CV#, CX# [ 83/08 - 89/08 ]	P-CXZ18 [ 4RB1 ]	1983	1989	TRUCKS	O-1512	Oil Filter
4659	ISUZU	TRUCK 874 CV#, CX# [ 83/08 - 89/08 ]	P-CXZ18 [ 4RB1 ]	1983	1989	TRUCKS	O-1514	Oil Filter
4660	ISUZU	TRUCK 875 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXZ19 [ 10PC1-N ]	1983	1986	TRUCKS	A-1013	Air Filter
4661	ISUZU	TRUCK 875 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXZ19 [ 10PC1-N ]	1983	1986	TRUCKS	A-5631	Air Filter
4662	ISUZU	TRUCK 875 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXZ19 [ 10PC1-N ]	1983	1986	TRUCKS	O-1512	Oil Filter
4663	ISUZU	TRUCK 875 CV#, CX# [ 83/08 - 86/01 ]	295PS P-CXZ19 [ 10PC1-N ]	1983	1986	TRUCKS	O-1513	Oil Filter
4664	ISUZU	TRUCK 876 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXZ19 [ 10PC1-S ]	1983	1986	TRUCKS	A-1828	Air Filter
4665	ISUZU	TRUCK 876 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXZ19 [ 10PC1-S ]	1983	1986	TRUCKS	A-7967	Air Filter

Sakura Filter				ENGINE APPLICATION				
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
4666	ISUZU	TRUCK 876 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXZ19 [ 10PC1-S ]	1983	1986	TRUCKS	O-1512	Oil Filter
4667	ISUZU	TRUCK 876 CV#, CX# [ 83/08 - 86/01 ]	330PS P-CXZ19 [ 10PC1-S ]	1983	1986	TRUCKS	O-1513	Oil Filter
4668	ISUZU	TRUCK 877 CV#, CX# [ 86/02 - 89/08 ]	P-CXZ19 [ 10PC1 ]	1986	1989	TRUCKS	A-1828	Air Filter
4669	ISUZU	TRUCK 877 CV#, CX# [ 86/02 - 89/08 ]	P-CXZ19 [ 10PC1 ]	1986	1989	TRUCKS	A-7967	Air Filter
4670	ISUZU	TRUCK 877 CV#, CX# [ 86/02 - 89/08 ]	P-CXZ19 [ 10PC1 ]	1986	1989	TRUCKS	O-1512	Oil Filter
4671	ISUZU	TRUCK 877 CV#, CX# [ 86/02 - 89/08 ]	P-CXZ19 [ 10PC1 ]	1986	1989	TRUCKS	O-1513	Oil Filter
4672	ISUZU	TRUCK 878 CV#, CX# [ 83/08 - 89/08 ]	P-CXZ21 [ 12PC1-N ]	1983	1989	TRUCKS	A-6010	Air Filter
4673	ISUZU	TRUCK 878 CV#, CX# [ 83/08 - 89/08 ]	P-CXZ21 [ 12PC1-N ]	1983	1989	TRUCKS	A-6011	Air Filter
4674	ISUZU	TRUCK 878 CV#, CX# [ 83/08 - 89/08 ]	P-CXZ21 [ 12PC1-N ]	1983	1989	TRUCKS	O-1512	Oil Filter
4675	ISUZU	TRUCK 878 CV#, CX# [ 83/08 - 89/08 ]	P-CXZ21 [ 12PC1-N ]	1983	1989	TRUCKS	O-1513	Oil Filter
4676	ISUZU	TRUCK 879 CV#, CX# [ 92/07 - 94/09 ]	TURBO U-CXZ50 [ 6WA1(T) ]	1992	1994	TRUCKS	A-6014	Air Filter
4677	ISUZU	TRUCK 879 CV#, CX# [ 92/07 - 94/09 ]	TURBO U-CXZ50 [ 6WA1(T) ]	1992	1994	TRUCKS	O-1522	Oil Filter
4678	ISUZU	TRUCK 879 CV#, CX# [ 92/07 - 94/09 ]	TURBO U-CXZ50 [ 6WA1(T) ]	1992	1994	TRUCKS	O-1529	Oil Filter
4679	ISUZU	TRUCK 880 CV#, CX# [ 89/09 - 94/09 ]	U-CXZ70 [ 8PD1 ]	1989	1994	TRUCKS	A-1828	Air Filter
4680	ISUZU	TRUCK 880 CV#, CX# [ 89/09 - 94/09 ]	U-CXZ70 [ 8PD1 ]	1989	1994	TRUCKS	A-7967	Air Filter
4681	ISUZU	TRUCK 880 CV#, CX# [ 89/09 - 94/09 ]	U-CXZ70 [ 8PD1 ]	1989	1994	TRUCKS	O-1522	Oil Filter
4682	ISUZU	TRUCK 880 CV#, CX# [ 89/09 - 94/09 ]	U-CXZ70 [ 8PD1 ]	1989	1994	TRUCKS	O-1529	Oil Filter
4683	ISUZU	TRUCK 881 CV#, CX# [ 89/09 - 94/09 ]	U-CXZ71 [ 10PD1 ]	1989	1994	TRUCKS	A-1828	Air Filter
4684	ISUZU	TRUCK 881 CV#, CX# [ 89/09 - 94/09 ]	U-CXZ71 [ 10PD1 ]	1989	1994	TRUCKS	A-7967	Air Filter
4685	ISUZU	TRUCK 881 CV#, CX# [ 89/09 - 94/09 ]	U-CXZ71 [ 10PD1 ]	1989	1994	TRUCKS	O-1522	Oil Filter
4686	ISUZU	TRUCK 881 CV#, CX# [ 89/09 - 94/09 ]	U-CXZ71 [ 10PD1 ]	1989	1994	TRUCKS	O-1529	Oil Filter
4687	ISUZU	TRUCK 882 CV#, CX# [ 89/09 - 92/06 ]	U-CXZ72 [ 12PD1 ]	1989	1992	TRUCKS	A-6010	Air Filter
4688	ISUZU	TRUCK 882 CV#, CX# [ 89/09 - 92/06 ]	U-CXZ72 [ 12PD1 ]	1989	1992	TRUCKS	A-6011	Air Filter
4689	ISUZU	TRUCK 882 CV#, CX# [ 89/09 - 92/06 ]	U-CXZ72 [ 12PD1 ]	1989	1992	TRUCKS	O-1529	Oil Filter
4690	ISUZU	TRUCK 883 CV#, CX# [ 92/07 - 94/09 ]	U-CXZ72 [ 12PD1 ]	1992	1994	TRUCKS	A-6010	Air Filter
4691	ISUZU	TRUCK 883 CV#, CX# [ 92/07 - 94/09 ]	U-CXZ72 [ 12PD1 ]	1992	1994	TRUCKS	A-6011	Air Filter
4692	ISUZU	TRUCK 883 CV#, CX# [ 92/07 - 94/09 ]	U-CXZ72 [ 12PD1 ]	1992	1994	TRUCKS	O-1521	Oil Filter
4693	ISUZU	TRUCK 883 CV#, CX# [ 92/07 - 94/09 ]	U-CXZ72 [ 12PD1 ]	1992	1994	TRUCKS	O-1529	Oil Filter
4694	ISUZU	TRUCK GIGA	CV SERIES			TRUCKS	O-1532	Oil Filter
4695	ISUZU	TRUCK GIGA	CX SERIES			TRUCKS	O-1532	Oil Filter
4696	ISUZU	TRUCK GIGA	CY SERIES			TRUCKS	O-1532	Oil Filter
4697	ISUZU	TRUCK/FRR500 -(N/A))	N/A			TRUCKS	A-6006	Air Filter
4698	ISUZU	TRUCK/FRR500 -(N/A))	N/A			TRUCKS	C-1533	Oil Filter
4699	ISUZU	TRUCK/FRR500 -(N/A))	N/A			TRUCKS	FC-2701	Fuel Filter
4700	ISUZU	TRUCK/FRR90Q -(N/A))	4HK1-UP			TRUCKS	A-5538	Air Filter
4701	ISUZU	TRUCK/FV950 -(N/A))	N/A			TRUCKS	A-6006	Air Filter
4702	ISUZU	TRUCK/FVR950 -(N/A))	N/A			TRUCKS	A-1013	Air Filter
4703	ISUZU	TRUCK/FVR950 -(N/A))	N/A			TRUCKS	A-1019	Air Filter
4704	ISUZU	TRUCK/FVR950 -(N/A))	N/A			TRUCKS	A-6006	Air Filter
4705	ISUZU	TRUCK/FVR950 -(N/A))	N/A			TRUCKS	C-1513	Oil Filter
4706	ISUZU	TRUCK/FVR950 -(N/A))	N/A			TRUCKS	C-1533	Oil Filter
4707	ISUZU	TRUCK/FVR950 -(N/A))	N/A			TRUCKS	FC-1509	Fuel Filter
4708	ISUZU	TRUCK/FVR950 -(N/A))	N/A			TRUCKS	FC-1510	Fuel Filter
4709	ISUZU	TRUCK/FVR950 -(N/A))	N/A			TRUCKS	FC-2701	Fuel Filter
4710	ISUZU	TRUCK/NPR300 (MEDIUM) -(N/A))	N/A			TRUCKS	A-1019	Air Filter
4711	ISUZU	TRUCK/NPR300 (MEDIUM) -(N/A))	N/A			TRUCKS	C-1515	Oil Filter
4712	ISUZU	TRUCK/NPR300 (MEDIUM) -(N/A))	N/A			TRUCKS	FC-1509	Fuel Filter
4713	ISUZU	TRUCK/NPR300 -(N/A))	N/A			TRUCKS	C-1515	Oil Filter
4714	ISUZU	TRUCK/NPR300 -(N/A))	N/A			TRUCKS	FC-1509	Fuel Filter
4715	ISUZU	TRUCK/NPR400 -(N/A))	N/A			TRUCKS	A-1019	Air Filter
4716	ISUZU	TRUCK/NPR400 -(N/A))	N/A			TRUCKS	C-1515	Oil Filter
4717	ISUZU	TRUCK/NPR400 -(N/A))	N/A			TRUCKS	FC-1503	Fuel Filter
4718	ISUZU	TRUCK/NPR400 -(N/A))	N/A			TRUCKS	FC-1505	Fuel Filter
4719	ISUZU	TRUCK/NPR400 -(N/A))	N/A			TRUCKS	FC-1509	Fuel Filter
4720	ISUZU	TRUCK/NPR400 -(N/A))	N/A			TRUCKS	FC-1510	Fuel Filter
4721	ISUZU	TRUCK/NPR400 -(NPR400))	N/A			TRUCKS	FC-1505	Fuel Filter
4722	ISUZU	TRUCKS/FRR500 -(N/A))	N/A			TRUCKS	C-1522	Oil Filter
4723	ISUZU	TSD45 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
4724	ISUZU	TSD45 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter
4725	ISUZU	TSD45 4X4 - ISUZU 6BD1 1981	Engine: N/A			TRUCKS	A-6007	Air Filter
4726	ISUZU	TWD25 - ISUZU 6BD1	Engine: N/A			TRUCKS	A-6007	Air Filter
4727	ISUZU	TWD25 - ISUZU 6BG1	Engine: N/A			TRUCKS	A-6007	Air Filter

Sakura Filter						ENGINE APPLICATION		
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
4728	ISUZU	TWD25 6X6 - ISUZU 6BD1 1981	Engine: N/A			TRUCKS	A-6007	Air Filter
4729	ISUZU	TWFR12 - ISUZU 4ZC1 1990 -1995	Engine: N/A			TRUCKS	A-1817	Air Filter
4730	ISUZU	U-CVR70 - ISUZU 8PD1 1983 -1995	Engine: N/A			TRUCKS	A-7967	Air Filter
4731	ISUZU	U-CVS71J - ISUZU 10PD1 1990 -1995	Engine: N/A			TRUCKS	A-7967	Air Filter
4732	ISUZU	U-CVZ70 - ISUZU 8PD1 1989 -1994	Engine: N/A			TRUCKS	A-7967	Air Filter
4733	ISUZU	U-CVZ71 - ISUZU 10PD1 1989 -1995	Engine: N/A			TRUCKS	A-7967	Air Filter
4734	ISUZU	U-CXG70 - ISUZU 10PD1 1989 -1994	Engine: N/A			TRUCKS	A-7967	Air Filter
4735	ISUZU	U-CXG70 - ISUZU 8PD1 1989 -1994	Engine: N/A			TRUCKS	A-7967	Air Filter
4736	ISUZU	U-CXG71 - ISUZU 10PD1 1989 -1994	Engine: N/A			TRUCKS	A-7967	Air Filter
4737	ISUZU	U-CXH71 - ISUZU 10PD1 1989 -1994	Engine: N/A			TRUCKS	A-7967	Air Filter
4738	ISUZU	U-CXK71 - ISUZU 10PD1 1992 -1994	Engine: N/A			TRUCKS	A-7967	Air Filter
4739	ISUZU	U-CXL71 - ISUZU 10PD1 1989 -1994	Engine: N/A			TRUCKS	A-7967	Air Filter
4740	ISUZU	U-CXM70 - ISUZU 8PD1 1989 -1994	Engine: N/A			TRUCKS	A-7967	Air Filter
4741	ISUZU	U-CXW71 - ISUZU 10PD1 1990 -1994	Engine: N/A			TRUCKS	A-7967	Air Filter
4742	ISUZU	U-CXZ70 - ISUZU 8PD1 1989 -1994	Engine: N/A			TRUCKS	A-7967	Air Filter
4743	ISUZU	U-CXZ71 - ISUZU 10PD1 1989 -1994	Engine: N/A			TRUCKS	A-7967	Air Filter
4744	ISUZU	U-ESR12 - ISUZU 6BG1T 1990 -1994	Engine: N/A			TRUCKS	C-1009	Oil Filter
4745	ISUZU	U-ESR12 - ISUZU 6BG1T 1990 -1994	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4746	ISUZU	U-ESR32 - ISUZU 6BG1T 1990 -1994	Engine: N/A			TRUCKS	C-1009	Oil Filter
4747	ISUZU	U-ESR32 - ISUZU 6BG1T 1990 -1994	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4748	ISUZU	U-ETR13 - ISUZU 6BG1 1990	Engine: N/A			TRUCKS	C-1009	Oil Filter
4749	ISUZU	U-ETR13 - ISUZU 6BG1 1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4750	ISUZU	U-FRR12 - ISUZU 6BG1T 1990 -1994	Engine: N/A			TRUCKS	C-1009	Oil Filter
4751	ISUZU	U-FRR12 - ISUZU 6BG1T 1990 -1994	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4752	ISUZU	U-FRR13 - ISUZU 6SA1 1990 -1994	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4753	ISUZU	U-FSR12 - ISUZU 6BG1T 1994 -2000	Engine: N/A			TRUCKS	C-1009	Oil Filter
4754	ISUZU	U-FSR12 - ISUZU 6BG1T 1994 -2000	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4755	ISUZU	U-FTR12 - ISUZU 6BG1T 1990 -1994	Engine: N/A			TRUCKS	C-1009	Oil Filter
4756	ISUZU	U-FTR12 - ISUZU 6BG1T 1990 -1994	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4757	ISUZU	U-FTR13 - ISUZU 6SA1 1990 -1994	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4758	ISUZU	U-FTR21 - ISUZU 6BG1 1990	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4759	ISUZU	U-JBGW40 - ISUZU ED35 1993 -1995	Engine: N/A			TRUCKS	A-1505	Air Filter
4760	ISUZU	U-JBW40 - ISUZU ED35 1993 -1995	Engine: N/A			TRUCKS	A-1505	Air Filter
4761	ISUZU	U-NFR62 - ISUZU 4FG1 1988 -1995	Engine: N/A			TRUCKS	C-1605	Oil Filter
4762	ISUZU	U-NGS62 - ISUZU 4FG1 1988 -1990	Engine: N/A			TRUCKS	C-1605	Oil Filter
4763	ISUZU	U-NHR54 - ISUZU 4JA1 1990	Engine: N/A			TRUCKS	A-1817	Air Filter
4764	ISUZU	U-NHR55 - ISUZU 4JB1 1988 -1993	Engine: N/A			TRUCKS	A-1817	Air Filter
4765	ISUZU	U-NKR55 - ISUZU 4JB1 1988 -1993	Engine: N/A			TRUCKS	A-1817	Air Filter
4766	ISUZU	U-NKR58 - ISUZU 4BE1 1990 -1995	Engine: N/A			TRUCKS	A-1817	Air Filter
4767	ISUZU	U-NKR61 - ISUZU 4BG1 1988	Engine: N/A			TRUCKS	A-1817	Air Filter
4768	ISUZU	U-NKR61 - ISUZU 4BG1 1989 -1990	Engine: N/A			TRUCKS	A-1817	Air Filter
4769	ISUZU	U-NKR63 - ISUZU 4BE2 1988 -1993	Engine: N/A			TRUCKS	A-1817	Air Filter
4770	ISUZU	U-NKR66 - ISUZU 4HF1 1990 -1995	Engine: N/A			TRUCKS	A-1817	Air Filter
4771	ISUZU	U-NKS58 - ISUZU 4BE1 1988	Engine: N/A			TRUCKS	A-1505	Air Filter
4772	ISUZU	U-NKS58 - ISUZU 4BE1 1990 -1993	Engine: N/A			TRUCKS	A-1817	Air Filter
4773	ISUZU	U-NPR58 - ISUZU 4BE1 1988	Engine: N/A			TRUCKS	A-1817	Air Filter
4774	ISUZU	U-NPR58 - ISUZU 4BE1 1990 -1993	Engine: N/A			TRUCKS	A-1505	Air Filter
4775	ISUZU	U-NPR59 - ISUZU 4BD1 1990	Engine: N/A			TRUCKS	A-1505	Air Filter
4776	ISUZU	U-NPR61 - ISUZU 4BG1 1988 -1990	Engine: N/A			TRUCKS	A-1505	Air Filter
4777	ISUZU	U-WFS53 - ISUZU 4FD1 1991	Engine: N/A			TRUCKS	A-1817	Air Filter
4778	ISUZU	U-WFS53 - ISUZU 4FD1 1991	Engine: N/A			TRUCKS	C-1605	Oil Filter
4779	ISUZU	U-WFS62 - ISUZU 4FG1 1990 -1995	Engine: N/A			TRUCKS	A-1817	Air Filter
4780	ISUZU	U-WFS62 - ISUZU 4FG1 1990 -1995	Engine: N/A			TRUCKS	C-1605	Oil Filter
4781	ISUZU	U-WKR55 - ISUZU 4JB1 1988 -1993	Engine: N/A			TRUCKS	A-1817	Air Filter
4782	ISUZU	VPZ290 - ISUZU 10PA1 1974 -1978	Engine: N/A			TRUCKS	O-1510	Oil Filter
4783	ISUZU	VRR290 - ISUZU 10PA1 1974 -1978	Engine: N/A			TRUCKS	O-1510	Oil Filter
4784	ISUZU	W-ESR12 - ISUZU 6BG1T 1990 -1994	Engine: N/A			TRUCKS	C-1009	Oil Filter
4785	ISUZU	W-ESR12 - ISUZU 6BG1T 1990 -1994	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4786	ISUZU	W-ETR12 - ISUZU 6BG1T 1989 -1994	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4787	ISUZU	W-EXR12 - ISUZU 6BG1 1990 -1994	Engine: N/A			TRUCKS	C-1009	Oil Filter
4788	ISUZU	W-EXR12 - ISUZU 6BG1 1990 -1994	Engine: N/A			TRUCKS	FC-1503	Fuel Filter
4789	ISUZU	WATERCART/FVD950 -(N/A)	N/A			TRUCKS	C-5505	Oil Filter
4790	ISUZU	WATERCART/FVZ1400 -(N/A)	N/A			TRUCKS	A-6006	Air Filter
4791	ISUZU	WATERCART/FVZ1400 -(N/A)	N/A			TRUCKS	C-5505	Oil Filter



Sakura Filter				ENGINE APPLICATION				
NO	Vehicle Manufacture Name	Model Name	Engine Name	Year 1	Year 2	Type Name	Sakura No	Filter Type Name
4792	ISUZU	WATERCART/TRUCK -(N/A)	N/A			TRUCKS	A-1013	Air Filter
4793	ISUZU	WFR53 - ISUZU 4FD1 1991	Engine: N/A			TRUCKS	A-1817	Air Filter